

D

Е

CONTENTS

BASIC INSPECTION	VQ25DE, VQ35DE	IDLE AIR VOLUME LEARNING16
Requirement	·	
MIXTURE RATIO SELF-LEARNING VALUE CLEAR MIXTURE RATIO SELF-LEARNING VALUE CLEAR CLEAR MIXTURE RATIO SELF-LEARNING VALUE CLEAR	BASIC INSPECTION7	·
Mixture Ratio Self-Learning Value Clear Mixture Ratio Self-Learning Value Clear Mixture Ratio Self-Learning Value Clear Clear Mixture Ratio Self-Learning Value Clear Clea	DIAGNOSIS AND DEDAID WODKELOW 7	Requirement16 G
Diagnostic Work Sheet		MIXTURE RATIO SELE-LEARNING VALUE
INSPECTION AND ADJUSTMENT		
SASIC INSPECTION	-	
CLEAR : Special Repair Requirement	INSPECTION AND ADJUSTMENT11	
BASIC INSPECTION : Special Repair Requirement	DASIC INSPECTION 44	
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT 14 ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT Description 14 DILE SPEED Description 14 IDLE SPEED Description 14 IDLE SPEED Special Repair Requirement 14 IDLE SPEED Special Repair Requirement 15 IGNITION TIMING Description 15 IGNITION TIMING Description 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION ACCELERATO		CLEAR : Special Repair Requirement18
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	·	FUNCTION DIA ONO DIO
CONTROL UNIT 14 ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description 14 ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement 14 IDLE SPEED Description 14 IDLE SPEED Description 14 IDLE SPEED : Special Repair Requirement 14 IDLE SPEED : Special Repair Requirement 15 IGNITION TIMING Description 15 IGNITION TIMING : Special Repair Requirement 15 IGNITION TIMING : Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING : Description 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING : Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING : Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING : Description 16 ACCELERATOR PEDAL RELEASED POSITION 16 ACCELERATOR PEDAL RELEASED POSITION LEARNING : Description 15 ACCELERATOR PEDAL RELEASED POSITION 15 ACCELERATOR PEDAL RELEASED POSITION 15 ACCELERATOR PEDAL RELEASE	ment	FUNCTION DIAGNOSIS19
CONTROL UNIT 14 ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Description 14 System Diagram 19 System Description 20 Component Parts Location 20 Component Parts Location 20 Component Description 21 System Description 27 System Description 28 Aureur Parts Location 28 Aureur Parts Location 28 Aureur Par		ENGINE CONTROL SYSTEM19
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Description		
CONTROL UNIT : Description		
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement		
IDLE SPEED 14 IDLE SPEED : Description 14 IDLE SPEED : Special Repair Requirement 14 IDLE SPEED : Description 27 System Diagram 27 System Description 36 IGNITION TIMING : Description 36 IGNITION TIMING : Special Repair Requirement 15 IGNITION TIMING : Special Repair Requirement 15 IGNITION TIMING : Description 36 ACCELERATOR PEDAL RELEASED POSITION LEARNING : Description 37 ACCELERATOR PEDAL RELEASED POSITION LEARNING : Special Repair Requirement 15 ACCELERATOR PEDAL RELEASED POSITION LEARNING : Special Repair Requirement 15 THROTTLE VALVE CLOSED POSITION LEARNING : Description 44 Component Parts Location 45 Component Parts Location 50 Comp		
IDLE SPEED 14 14 1DLE SPEED : Description 14 1DLE SPEED : Description 14 1DLE SPEED : Special Repair Requirement 15 1GNITION TIMING : Description 15 1GNITION TIMING : Special Repair Requirement 15 15 15 15 15 15 15 1	CONTROL UNIT: Special Repair Requirement14	MULTIPORT FUEL IN JECTION CYCTEM
IDLE SPEED : Description	IDLE SPEED14	T. Control of the Con
IGNITION TIMING	IDLE SPEED : Description14	System Diagram27
IGNITION TIMING15Component Description36MIGNITION TIMING : Description15IGNITION TIMING : Special Repair Requirement15IGNITION TIMING : Special Repair Requirement15System Diagram37ACCELERATOR PEDAL RELEASED POSITION LEARNING : Description15Component Description37LEARNING : Description15Component Description38ACCELERATOR PEDAL RELEASED POSITION LEARNING : Special Repair Requirement15AIR CONDITIONING CUT CONTROL44LEARNING : Description15System Diagram44System Description44Component Parts Location45Component Parts Location45Component Parts Location45Component Description50THROTTLE VALVE CLOSED POSITION LEARNING : Description16AUTOMATIC SPEED CONTROL DEVICE (ASCD)AUTOMATIC SPEED CONTROL DEVICE (ASCD)51System Diagram51	IDLE SPEED : Special Repair Requirement14	
IGNITION TIMING : Description	IGNITION TIMING 15	
IGNITION TIMING : Special Repair Requirement15 ACCELERATOR PEDAL RELEASED POSITION LEARNING		·
ACCELERATOR PEDAL RELEASED POSITION LEARNING	• • • • • • • • • • • • • • • • • • •	
ACCELERATOR PEDAL RELEASED POSITION LEARNING	TOTALLION THAINS : Oposial Ropali Roquitomonici To	
ACCELERATOR PEDAL RELEASED POSITION LEARNING: Description		System Description37
LEARNING : Description		
ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement		· · · · · · · · · · · · · · · · · · ·
LEARNING : Special Repair Requirement		
THROTTLE VALVE CLOSED POSITION LEARN- ING		
THROTTLE VALVE CLOSED POSITION LEARN- ING	LEARNING . Special Repair Requirement	System Description 44
THROTTLE VALVE CLOSED POSITION LEARNING : Description	THROTTLE VALVE CLOSED POSITION LEARN-	
LEARNING : Description		
THROTTLE VALVE CLOSED POSITION LEARNING : Description		AUTOMATIC CREED CONTROL DEVICE
LEARNING : Special Repair Requirement		
		•
	LEARNING : Special Repair Requirement16	System Diagram51 System Description 51

Component Parts Location		Component Inspection	138
Component Description	58	P0031, P0032, P0051, P0052 A/F SENSO)R 1
CAN COMMUNICATION	59	HEATER	
System Description		Description	
·		DTC Logic	
COOLING FAN CONTROL	60	Diagnosis Procedure	
System Diagram	60	Component Inspection	
System Description		Component mopositori	
Component Parts Location		P0037, P0038, P0057, P0058 HO2S2 HE	AT-
Component Description	67	ER	143
ELECTRONIC CONTROLLED ENGINE		Description	143
	20	DTC Logic	
MOUNT		Diagnosis Procedure	
System Diagram		Component Inspection	145
System Description Component Parts Location		P0075, P0081 IVT CONTROL SOLENOID	`
Component Description			
Component Description	73	VALVE	
EVAPORATIVE EMISSION SYSTEM	76	Description	
System Diagram	76	DTC Logic	
System Description		Diagnosis Procedure	
Component Parts Location	80	Component Inspection	147
Component Description	85	P0102, P0103 MAF SENSOR	149
INITAL/E VALVE TIMINO CONTROL		Description	
INTAKE VALVE TIMING CONTROL		DTC Logic	149
System Diagram		Diagnosis Procedure	
System Description		Component Inspection	
Component Parts Location			
Component Description	92	P0112, P0113 IAT SENSOR	
VARIABLE INDUCTION AIR SYSTEM	93	Description	
System Diagram		DTC Logic	
System Description		Diagnosis Procedure	
Component Parts Location		Component Inspection	155
Component Description		P0117, P0118 ECT SENSOR	157
·		Description	
ON BOARD DIAGNOSTIC (OBD) SYSTEM		DTC Logic	
Diagnosis Description		Diagnosis Procedure	
CONSULT-III Function		Component Inspection	
Diagnosis Tool Function	122	·	
COMPONENT DIAGNOSIS	124	P0122, P0123 TP SENSOR	
COMI CITEITI DIAGNOSIS	124	Description	
TROUBLE DIAGNOSIS - SPECIFICATION	I	DTC Logic	
VALUE		Diagnosis Procedure	
Description		Component Inspection	
Component Function Check		Special Repair Requirement	162
Diagnosis Procedure		P0130, P0150 A/F SENSOR 1	162
· ·		Description	
POWER SUPPLY AND GROUND CIRCUIT	Γ 132	DTC Logic	
Diagnosis Procedure	132	Component Function Check	
HARRIST CAN COMM CIRCUIT		Diagnosis Procedure	
U1000, U1001 CAN COMM CIRCUIT		Diagnosis Frocedure	105
Description		P0131, P0151 A/F SENSOR 1	167
DTC Logic		Description	
Diagnosis Procedure	135	DTC Logic	
P0011, P0021 IVT CONTROL	136	Diagnosis Procedure	
DTC Logic		-	
Diagnosis Procedure		P0132, P0152 A/F SENSOR 1	
Piagriosis i rootaart	131	Description	170

DTC Logic17		221
Diagnosis Procedure17	1 D0240 D0245 OMD OFNOOD (DUAGE)	
D0422 D0452 A/E CENCOD 4	P0340, P0345 CMP SENSOR (PHASE)	
P0133, P0153 A/F SENSOR 117		
Description		
DTC Logic		
Diagnosis Procedure17	5 Component Inspection	224
P0137, P0157 HO2S217	8 P0420, P0430 THREE WAY CATALYST	
Description17		226
DTC Logic179		
Component Function Check17	3 -	
Diagnosis Procedure18		
Component Inspection18	2	220
·	P0444 EVAP CANISTER PURGE VOLUME	
P0138, P0158 HO2S218		231
Description18		231
DTC Logic18		231
Component Function Check18	6 Diagnosis Procedure	
Diagnosis Procedure18		232
Component Inspection19	0	
D0120 D0150 H0262	P0500 VSS	
P0139, P0159 HO2S219		
Description	• g. •	
DTC Logic19		
Component Function Check	g	235
Diagnosis Procedure		220
Component Inspection19	•	
P0171, P0174 FUEL INJECTION SYSTEM	Description	
FUNCTION19	DTC Logic	
	_ iag	
DTC Logic		237
Diagnosis Procedure19	P0603 ECM POWER SUPPLY	238
P0172, P0175 FUEL INJECTION SYSTEM	Description	
FUNCTION20		
DTC Logic20	9	
Diagnosis Procedure	<u> </u>	230
Diagnosis i 1000dure20	P0605 ECM	240
P0222, P0223 TP SENSOR20	6 Description	240
Description20	•	
DTC Logic20	<u> </u>	
Diagnosis Procedure20	6	
Component Inspection20		242
Special Repair Requirement20	8 Description	
	DTC Logic	
P0300, P0301, P0302, P0303, P0304, P0305,	Diagnosis Procedure	242
P0306 MISFIRE20	9 P0643 SENSOR POWER SUPPLY	040
DTC Logic20	9 DTC Lastia	
Diagnosis Procedure21	DTC Logic	
-	Diagnosis Procedure	243
P0327, P0328, P0332, P0333 KS21		245
Description21	Description	
DTC Logic21	DTC Logic	
Diagnosis Procedure21	Component Function Check	
Component Inspection21	Diagnosis Procedure (VQ35DE engine)	
DOSSE CKD SENSOD (DOS)	• • • • • • • • • • • • • • • • • • • •	
P0335 CKP SENSOR (POS)21		241
Description	D1919 ICS COMMINICATION FINE	249
DTC Logic	Description	
Diagnosis Procedure21	9	0

DTC Logic	249	DTC Logic	
Diagnosis Procedure	249	Diagnosis Procedure	278
P1217 ENGINE OVER TEMPERATURE	250	P1700 CVT CONTROL SYSTEM	280
DTC Logic		Description	
Component Function Check	250		
Diagnosis Procedure	251	P1715 INPUT SPEED SENSOR (PRIMARY	
P1225 TP SENSOR	254	SPEED SENSOR)	
Description		Description DTC Logic	
DTC Logic		Diagnosis Procedure	
Diagnosis Procedure		Diagnosis i rocedure	201
Special Repair Requirement		P1720 VSS	283
		Description	
P1226 TP SENSOR		DTC Logic	
Description		Diagnosis Procedure	283
DTC Logic		P1800 VIAS CONTROL SOLENOID VALVE	4 005
Diagnosis Procedure			
Special Repair Requirement	257	Description	
P1550 BATTERY CURRENT SENSOR	258	DTC Logic Diagnosis Procedure	
Description		Component Inspection	
DTC Logic		Component inspection	200
Diagnosis Procedure		P1801 VIAS CONTROL SOLENOID VALVE	2.288
Component Inspection		Description	288
		DTC Logic	288
P1551, P1552 BATTERY CURRENT SEN		Diagnosis Procedure	288
SOR		Component Inspection	289
Description		DAGGE DDAI/E CWITCH	004
DTC Logic		P1805 BRAKE SWITCH Description	
Diagnosis Procedure		DTC Logic	
Component Inspection	262	Diagnosis Procedure	
P1553 BATTERY CURRENT SENSOR	264	Component Inspection (Stop Lamp Switch)	
Description			202
DTC Logic		P2100, P2103 THROTTLE CONTROL MO-	
Diagnosis Procedure		TOR RELAY	294
Component Inspection		Description	294
		DTC Logic	
P1554 BATTERY CURRENT SENSOR		Diagnosis Procedure	294
Description		P2101 ELECTRIC THROTTLE CONTROL	
DTC Logic		FUNCTION	206
Component Function Check		Description	
Diagnosis Procedure Component Inspection		DTC Logic	
Component inspection	209	Diagnosis Procedure	
P1564 ASCD STEERING SWITCH	270	Component Inspection	
Description	270	Special Repair Requirement	
DTC Logic	270		
Diagnosis Procedure	270	P2118 THROTTLE CONTROL MOTOR	
Component Inspection	272	Description	
DAEZO ACCO DO AVE CWITCH	070	DTC Logic	
P1572 ASCD BRAKE SWITCH		Component Inspection	
Description		Special Repair Requirement	300
DTC Logic Diagnosis Procedure		P2119 ELECTRIC THROTTLE CONTROL	
Component Inspection (ASCD Brake Switch)		ACTUATOR	302
Component Inspection (Stop Lamp Switch) .		Description	
Component inoposition (Otop Lamp Owner) .		DTC Logic	
P1574 ASCD VEHICLE SPEED SENSOR	278	Diagnosis Procedure	
Description	278	Special Repair Requirement	

P2122, P2123 APP SENSOR30	Component Inspection332
Description30	OA FUEL IN IECTOR
DTC Logic30	
Diagnosis Procedure30	Description
Component Inspection30	
Special Repair Requirement30	Diagnosis Procedure
P2127, P2128 APP SENSOR30	7
Description30	₀₇ FUEL PUMP337
DTC Logic30	Description337
Diagnosis Procedure30	Component Function Check337
Component Inspection30	Diagnosis Procedure337
Special Repair Requirement31	Component Inspection (Fuel Pump)340
P2135 TP SENSOR31	Component Inspection (Condenser)340
Description	
DTC Logic	
Diagnosis Procedure	
Component Inspection	
Special Repair Requirement	
Opoolal Ropall Roquilottiont	Transistor)344
P2138 APP SENSOR31	4 Component Inspection (Condenser)345
Description31	MALEUNICTION INDICATOD 346
DTC Logic31	A Description
Diagnosis Procedure31	Description
Component Inspection31	6 Component Function Check
Special Repair Requirement31	Diagnosis Procedure346
P2A00, P2A03 A/F SENSOR 131	8 POSITIVE CRANKCASE VENTILATION 347
Description	
DTC Logic	Component Inspection 247
Diagnosis Procedure	
	TELLINGERARY FREGORIC OLIVOOR
ASCD BRAKE SWITCH32	Description
Description32	Component Function Check348
Component Function Check32	Diagnosis Procedure348
Diagnosis Procedure32	VARIABLE INDUCTION AIR SYSTEM 351
Component Inspection (ASCD Brake Switch) 32	Description351
ASCD INDICATOR32	0
Description	Common transfer Obselv (/OSEDE angles)
Component Function Check	Diamonia Dranadura (VOSEDE annina)
Diagnosis Procedure	Diamonia Dranadura (VOSEDE annina)
•	FOU DIA CNOCIO
COOLING FAN	-
Description	
Component Function Check	Reference value357
Diagnosis Procedure	
Component Inspection (Cooling Fan Motor) 32	7/ TEM 371
Component Inspection (Cooling Fan Relay) 32	Fall safe386
ELECTRICAL LOAD SIGNAL32	DTC Inspection Priority Chart388
Description	og DTC Index389
Component Function Check	II. (O. CODT O. I.
Diagnosis Procedure32	
ELECTRONIC CONTROLLED ENGINE	SYMPTOM DIAGNOSIS400
MOUNT33	24
Description	ENGINE CONTROL SYSTEM SYMPTOMS 400
Component Function Check	Symptom Lania /iiii
Diagnosis Procedure33	
5	


Description404	ON-VEHICLE MAINTENANCE41
PRECAUTION405	FUEL PRESSURE41
PRECAUTIONS 405	Inspection 41
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN-	ON-VEHICLE REPAIR413
SIONER"405	EVAPORATIVE EMISSION SYSTEM413
Precautions For Xenon Headlamp Service405	Inspection413
Precaution for Procedure without Cowl Top Cover.405 On Board Diagnostic (OBD) System of Engine	SERVICE DATA AND SPECIFICATIONS
and CVT405	(SDS)414
General Precautions406	SERVICE DATA AND SPECIFICATIONS
PREPARATION410	(SDS)414
DDED A D A TION	Idle Speed414
PREPARATION410	Ignition Timing414
Special Service Tools410	Calculated Load Value414
Commercial Service Tools410	Mass Air Flow Sensor414

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow INFOID:0000000003856442 EC

OVERALL SEQUENCE



^{*1:} Include 1st trip DTC.

JMBIA1416GB

Р

Α

D

Е

^{*2:} Include 1st trip freeze frame data.

1.GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the "Diagnostic Work Sheet". (Refer to EC-10, "Diagnostic Work Sheet".)

>> GO TO 2.

< BASIC INSPECTION >

2.CHECK DTC

- 1. Check DTC.
- 2. Perform the following procedure if DTC is displayed.
- Record DTC and freeze frame data. (Print them out with CONSULT-III or GST.)
- Erase DTC. (Refer to EC-102, "Diagnosis Description".)
- Study the relationship between the cause detected by DTC and the symptom described by the customer. (Symptom Table is useful. Refer to EC-400, "Symptom Table".)
- Check related service bulletins for information.

Are any symptoms described and any DTCs detected?

Symptom is described, DTC is displayed>>GO TO 3.

Symptom is described, DTC is not displayed>>GO TO 4.

Symptom is not described, DTC is displayed>>GO TO 5.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer (except MI ON).

Also study the normal operation and fail-safe related to the symptom. Refer to EC-404, "Description" and EC-386, "Fail safe".

Diagnosis Work Sheet is useful to verify the incident.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom. Refer to EC-404, "Description" and EC-386. "Fail safe".

Diagnosis Work Sheet is useful to verify the incident.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the displayed DTC, and then check that DTC is detected again.

If two or more DTCs are detected, refer to EC-388, "DTC Inspection Priority Chart" and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIR-MATION PROCEDURE.

Is DTC detected?

YES >> GO TO 10.

NO >> Check according to GI-35, "Intermittent Incident".

PERFORM BASIC INSPECTION

Perform EC-11, "BASIC INSPECTION: Special Repair Requirement".

Will CONSULT-III be used?

DIAGNOSIS AND REPAIR WORKFLOW

[VQ25DE, VQ35DE] < BASIC INSPECTION > YES >> GO TO 7. NO >> GO TO 9. Α 7 .PERFORM "SPEC" OF "DATA MONITOR" MODE (P) With CONSULT-III EC Check that "MAS A/F SE-B1", "B/FUEL SCHDL", "A/F ALPHA-B1" and "A/F ALPHA-B2" are within the SP value using CONSULT-III in "SPEC" of "DATA MONITOR" mode. Refer to EC-124, "Component Function Check". C Are they within the SP value? YES >> GO TO 9. NO >> GO TO 8. D $oldsymbol{\mathsf{S}}.\mathsf{DETECT}$ MALFUNCTIONING PART BY TROUBLE DIAGNOSIS - SPECIFICATION VALUE Detect malfunctioning part according to <u>EC-125</u>, "Diagnosis Procedure". Is a malfunctioning part detected? Е YES >> GO TO 11. NO >> GO TO 9. F $\mathbf{9}.$ DETECT MALFUNCTIONING SYSTEM BY SYMPTOM TABLE Detect malfunctioning system according to EC-400, "Symptom Table" based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptoms. >> GO TO 10. 10.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE Н Inspect according to Diagnostic Procedure of the system. NOTE: The Diagnostic Procedure in EC section described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to "Circuit Inspection" in GI-37, "Circuit Inspection". Is a malfunctioning part detected? YES >> GO TO 11. NO >> Monitor input data from related sensors or check voltage of related ECM terminals using CON-SULT-III. Refer to EC-357, "Reference Value". K 11. REPAIR OR REPLACE THE MALFUNCTIONING PART Repair or replace the malfunctioning part. 2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replace-Check DTC. If DTC is displayed, erase it, refer to EC-102, "Diagnosis Description". M >> GO TO 12. 12. FINAL CHECK Ν When DTC was detected in step 2, perform DTC Confirmation Procedure or Overall Function Check again, and then check that the malfunction have been completely repaired. When symptom was described from the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected. Is DTC detected and does symptom remain? YES-1 >> DTC is detected: GO TO 10. Р YES-2 >> Symptom remains: GO TO 6. >> Before returning the vehicle to the customer, always erase unnecessary DTC in ECM and TCM NO (Transmission Control Module). (Refer to EC-102, "Diagnosis Description".) If the completion of SRT is needed, drive vehicle under the specific DRIVING PATTERN in EC-392. "How to Set SRT Code".

Diagnostic Work Sheet

INFOID:0000000003856443

DESCRIPTION

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the WORKSHEET SAMPLE below in order to organize all the information for troubleshooting. Some conditions may cause the MI to come on steady or blink, and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere.

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

WORKSHEET SAMPLE

Customer name MR/MS Model & Year VIN		VIN		
Engine #		Trans. Mileage		
Incident Date		Manuf. Date	In Service Date	
Fuel and fuel	filler cap	☐ Vehicle ran out of fuel causing misfire ☐ Fuel filler cap was left off or incorrectly		
	☐ Startability	☐ Impossible to start ☐ No combus ☐ Partial combustion affected by tl ☐ Partial combustion NOT affected ☐ Possible but hard to start ☐ Other	hrottle position d by throttle position	
Symptoms	□ Idling	☐ No fast idle ☐ Unstable ☐ H☐ Others [High idle ☐ Low idle	
Gymp.c.mc	☐ Driveability	☐ Stumble ☐ Surge ☐ Knock ☐ Intake backfire ☐ Exhaust backfir ☐ Others [
	☐ Engine stall	□ At the time of start □ While idling □ While accelerating □ While decelerating □ Just after stopping □ While loading		
Incident occu	rrence	☐ Just after delivery ☐ Recently ☐ In the morning ☐ At night ☐	☐ In the daytime	
Frequency		☐ All the time ☐ Under certain cond	ditions	
Weather cond	ditions	☐ Not affected		
	Weather	☐ Fine ☐ Raining ☐ Snowing	Others [
	Temperature	☐ Hot ☐ Warm ☐ Cool ☐	Cold Humid °F	
		☐ Cold ☐ During warm-up ☐	After warm-up	
Engine conditions		4,000 6,000 8,000 rpm		
Road conditions		hway		
Driving conditions		 Not affected At starting While idling While accelerating While cruising While decelerating While turning (RH/LH) 		
Vehicle speed		30 40 50 60 MPH		
Malfunction ir	ndicator lamp	☐ Turned on ☐ Not turned on		

MTBL0017


INSPECTION AND ADJUSTMENT **BASIC INSPECTION**


BASIC INSPECTION: Special Repair Requirement


INFOID:0000000003856444

1.INSPECTION START

- Check service records for any recent repairs that may indicate a related malfunction, or a current need for scheduled maintenance.
- 2. Open engine hood and check the following:
- Harness connectors for improper connections
- Wiring harness for improper connections, pinches and cut
- Vacuum hoses for splits, kinks and improper connections
- Hoses and ducts for leaks
- Air cleaner clogging
- Gasket
- 3. Confirm that electrical or mechanical loads are not applied.
- Head lamp switch is OFF.
- Air conditioner switch is OFF.
- Rear window defogger switch is OFF.
- Steering wheel is in the straight-ahead position, etc.








- 5. Run engine at about 2,000 rpm for about 2 minutes under no
- 6. Check that no DTC is displayed with CONSULT-III or GST.

Are any DTCs detected?

YES >> GO TO 2. NO >> GO TO 3.



2.repair or replace

Repair or replace components as necessary according to corresponding Diagnostic Procedure.

>> GO TO 3

3.CHECK TARGET IDLE SPEED

Run engine at about 2,000 rpm for about 2 minutes under no load.

Е

F

D

Α

EC

Н

M

Ν

Р

< BASIC INSPECTION > [VQ25DE, VQ35DE]

2. Rev engine between 2,000 and 3,000 rpm 2 or 3 times under no load, then run engine at idle speed for about 1 minute.


Check idle speed.

For procedure, refer to <u>EC-14</u>. "IDLE SPEED : Special Repair Requirement".

For specification, refer to EC-414, "Idle Speed".

Is the inspection result normal?

YES >> GO TO 10. NO >> GO TO 4.



4. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

- 1. Stop engine.
- 2. Perform <u>EC-15</u>, "ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement".

>> GO TO 5.

5. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".

>> GO TO 6.

6. PERFORM IDLE AIR VOLUME LEARNING

Perform EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement".

Is Idle Air Volume Learning carried out successfully?

YES >> GO TO 7.

NO >> Follow the instruction of Idle Air Volume Learning. Then GO TO 4.

7. CHECK TARGET IDLE SPEED AGAIN

- Start engine and warm it up to normal operating temperature.
- 2. Check idle speed.

For procedure, refer to EC-14, "IDLE SPEED: Special Repair Requirement".

For specification, refer to EC-414, "Idle Speed".

Is the inspection result normal?

YES >> GO TO 10.

NO >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the Following.

- Check camshaft position sensor (PHASE) and circuit. Refer to EC-223, "Diagnosis Procedure".
- Check crankshaft position sensor (POS) and circuit. Refer to <u>EC-219, "Diagnosis Procedure"</u>.

Is the inspection result normal?

YES >> GO TO 9.

NO >> 1. Repair or replace malfunctioning part.

2. GO TO 4.

9. CHECK ECM FUNCTION

- 1. Substitute with a non-malfunctioning ECM to check ECM function. (ECM may be the cause of the incident, although this is rare.)
- 2. Perform initialization of NVIS (NATS) system and registration of all NVIS (NATS) ignition key IDs. Refer to SEC-8, "ECM RE-COMMUNICATING FUNCTION: Description".

>> GO TO 4.

10. CHECK IGNITION TIMING

1. Run engine at idle.

INSPECTION AND ADJUSTMENT

[VQ25DE, VQ35DE] < BASIC INSPECTION > Check ignition timing with a timing light. For procedure, refer to EC-15, "IGNITION TIMING: Special Repair Requirement". Α For specification, refer to EC-414, "Ignition Timing". Is the inspection result normal? >> GO TO 19. YES EC NO >> GO TO 11. 11. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING Stop engine. Perform EC-15, "ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement". D >> GO TO 12. 12.perform throttle valve closed position learning Perform EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement". F >> GO TO 13. 13.perform idle air volume learning Perform EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement". Is Idle Air Volume Learning carried out successfully? YES >> GO TO 14. NO >> Follow the instruction of Idle Air Volume Learning. Then GO TO 4. Н 14.CHECK TARGET IDLE SPEED AGAIN Start engine and warm it up to normal operating temperature. Check idle speed. For procedure, refer to EC-14, "IDLE SPEED: Special Repair Requirement". For specification, refer to EC-414, "Idle Speed". Is the inspection result normal? YES >> GO TO 15. NO >> GO TO 17. 15. CHECK IGNITION TIMING AGAIN K Run engine at idle. 2. Check ignition timing with a timing light. For procedure, refer to EC-15, "IGNITION TIMING: Special Repair Requirement". For specification, refer to EC-414, "Ignition Timing". Is the inspection result normal? M YES >> GO TO 19. NO >> GO TO 16. 16. CHECK TIMING CHAIN INSTALLATION N Check timing chain installation. Refer to EM-53, "Removal and Installation". Is the inspection result normal? YES >> GO TO 17. NO >> 1. Repair the timing chain installation. GO TO 4. 17. DETECT MALFUNCTIONING PART Р Check the following. Check camshaft position sensor (PHASE) and circuit. Refer to EC-223, "Diagnosis Procedure". Check crankshaft position sensor (POS) and circuit. Refer to EC-219, "Diagnosis Procedure". Is the inspection result normal? YES >> GO TO 18.

>> 1. Repair or replace malfunctioning part.

NO

2. GO TO 4.

18. CHECK ECM FUNCTION

< BASIC INSPECTION >

- Substitute with a non-malfunctioning ECM to check ECM function. (ECM may be the cause of the incident, although this is rare.)
- Perform initialization of NVIS (NATS) system and registration of all NVIS (NATS) ignition key IDs. Refer to EC-14, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Special Repair Requirement".

>> GO TO 4.

19. INSPECTION END

Did you replace ECM, referring this Basic Inspection procedure?

Yes or No

Yes >> Go to EC-14. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Special Repair Requirement".

No >> INSPECTION END

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Description

INFOID:0000000003856445

INFOID:0000000003856448

[VQ25DE, VQ35DE]

When replacing ECM, the following procedure must be performed.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Special Repair Requirement INFOID:0000000003856446

 ${f 1}$.PERFORM INITIALIZATION OF NVIS (NATS) SYSTEM AND REGISTRATION OF ALL NVIS (NATS) IGNI-TION KEY IDS

Refer to SEC-8, "ECM RE-COMMUNICATING FUNCTION: Description".

>> GO TO 2.

2.PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

Refer to EC-15, "ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement".

>> GO TO 3.

3.PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".

>> GO TO 4.

f 4 Perform idle air volume learning

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement".

>> END

IDLE SPEED

IDLE SPEED: Description

INFOID:0000000003856447

This describes how to check the idle speed. For the actual procedure, follow the instructions in "BASIC INSPECTION".

IDLE SPEED: Special Repair Requirement

1.CHECK IDLE SPEED

(P)With CONSULT-III

EC-14

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION > [VQ25DE, VQ35DE]

Check idle speed in "DATA MONITOR" mode with CONSULT-III.

With GST

Check idle speed with Service \$01 of GST.

>> INSPECTION END

IGNITION TIMING

IGNITION TIMING: Description

This describes how to check the ignition timing. For the actual procedure, follow the instructions in "BASIC INSPECTION".


IGNITION TIMING: Special Repair Requirement

1. CHECK IGNITION TIMING

1. Attach timing light to loop wires as shown.


A : Timing light

<□ : Vehicle front



Check ignition timing.

>> INSPECTION END



ACCELERATOR PEDAL RELEASED POSITION LEARNING

ACCELERATOR PEDAL RELEASED POSITION LEARNING: Description INFOID.00000003856453

Accelerator Pedal Released Position Learning is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time the harness connector of the accelerator pedal position sensor or ECM is disconnected.

ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement

1.START

- 1. Check that accelerator pedal is fully released.
- 2. Turn ignition switch ON and wait at least 2 seconds.
- 3. Turn ignition switch OFF and wait at least 10 seconds.
- 4. Turn ignition switch ON and wait at least 2 seconds.
- 5. Turn ignition switch OFF and wait at least 10 seconds.

INFOID:0000000003856449

INFOID:0000000003856450

Α

EC

D

Е

F

Н

K

L

Ν

54

>> END

< BASIC INSPECTION >

THROTTLE VALVE CLOSED POSITION LEARNING

THROTTLE VALVE CLOSED POSITION LEARNING: Description

INFOID:0000000003856455

[VQ25DE, VQ35DE]

Throttle Valve Closed Position Learning is an operation to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected.

THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement

INFOID:0000000003856456

1.START

- 1. Check that accelerator pedal is fully released.
- 2. Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.
 Check that throttle valve moves during above 10 seconds by confirming the operating sound.

>> END

IDLE AIR VOLUME LEARNING

IDLE AIR VOLUME LEARNING: Description

INFOID:0000000003856457

Idle Air Volume Learning is a function of ECM to learn the idle air volume that keeps engine idle speed within the specific range. It must be performed under the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- · Idle speed or ignition timing is out of specification.

IDLE AIR VOLUME LEARNING: Special Repair Requirement

INFOID:0000000003856458

1.PRECONDITIONING

Before performing Idle Air Volume Learning, check that all of the following conditions are satisfied. Learning will be cancelled if any of the following conditions are missed for even a moment.

- Battery voltage: More than 12.9 V (At idle)
- Engine coolant temperature: 70 100°C (158 212°F)
- Selector lever: P or N
- · Electric load switch: OFF

(Air conditioner, head lamp, rear window defogger)

- For vehicle equipped with daytime light systems, perform one of the following procedures before starting engine not to illuminate headlamps.
- Apply parking brake
- Set lighting switch to the 1st position
- Steering wheel: Neutral (Straight-ahead position)
- Vehicle speed: Stopped
- Transmission: Warmed-up
- With CONSULT-III: Drive vehicle until "ATF TEMP SEN" in "DATA MONITOR" mode of "CVT" system indicates less than 0.9 V.
- Without CONSULT-III: Drive vehicle for 10 minutes.

Will CONSULT-III be used?

YES >> GO TO 2.

NO >> GO TO 3.

2.PERFORM IDLE AIR VOLUME LEARNING

(I) With CONSULT-III

- 1. Perform <u>EC-15</u>, "ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement".
- Perform <u>EC-16</u>, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".
- 3. Start engine and warm it up to normal operating temperature.
- Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode.
- 5. Touch "START" and wait 20 seconds.

INSPECTION AND ADJUSTMENT

[VQ25DE, VQ35DE] < BASIC INSPECTION >

Is "CMPLT" displayed on CONSULT-III screen?

>> GO TO 4. YES

NO >> GO TO 5.

3.perform idle air volume learning

EC

D

Е


F

Α

Without CONSULT-III

NOTE:

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Perform EC-15, "ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement".
- 2. Perform EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".
- Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- Confirm that accelerator pedal is fully released, turn ignition switch ON and wait 3 seconds.
- 6. Repeat the following procedure quickly 5 times within 5 seconds.
- Fully depress the accelerator pedal.
- Fully release the accelerator pedal.
- Wait 7 seconds, fully depress the accelerator pedal for approx. 20 seconds until the MI stops blinking and turns ON.
- Fully release the accelerator pedal within 3 seconds after the MI turns ON.
- Start engine and let it idle.
- 10. Wait 20 seconds.



>> GO TO 4.

4. CHECK IDLE SPEED AND IGNITION TIMING

Rev up the engine 2 or 3 times and check that idle speed and ignition timing are within the specifications. For procedure, refer to EC-14, "IDLE SPEED: Special Repair Requirement" and EC-15, "IGNITION TIMING: Special Repair Requirement".

For specifications, refer to EC-414, "Idle Speed" and EC-414, "Ignition Timing".

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

DETECT MALFUNCTIONING PART-I

Check the following

- Check that throttle valve is fully closed.
- Check PCV valve operation.
- Check that downstream of throttle valve is free from air leakage.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning part.

6.DETECT MALFUNCTIONING PART-II

When the above three items check out OK, engine component parts and their installation condition are questionable. Check and eliminate the cause of the incident.

It is useful to perform "TROUBLE DIAGNOSIS - SPECIFICATION VALUE". Refer to EC-124, "Description".

Н

K

L

M

N

INSPECTION AND ADJUSTMENT

[VQ25DE, VQ35DE] < BASIC INSPECTION >

If any of the following conditions occur after the engine has started, eliminate the cause of the incident and perform Idle Air Volume Learning again:

- Engine stalls.
- · Erroneous idle.

>> INSPECTION END

MIXTURE RATIO SELF-LEARNING VALUE CLEAR

MIXTURE RATIO SELF-LEARNING VALUE CLEAR: Description

This describes show to erase the mixture ratio self-learning value. For the actual procedure, follow the instructions in "Diagnosis Procedure".

MIXTURE RATIO SELF-LEARNING VALUE CLEAR: Special Repair Requirement

INFOID:0000000003856460

1.START

(P)With CONSULT-III

- Start engine and warm it up to normal operating temperature.
- Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-III.
- 3. Clear mixture ratio self-learning value by touching "CLEAR".

With GST

- Start engine and warm it up to normal operating temperature.
 Turn ignition switch OFF.
- 3. Disconnect mass air flow sensor harness connector.
- Restart engine and let it idle for at least 5 seconds.
- Stop engine and reconnect mass air flow sensor harness connector.
- Select Service \$03 with GST. Check that DTC P0102 is detected.
- Select Service \$04 with GST to erase the DTC P0102.


>> END

Α

FUNCTION DIAGNOSIS

ENGINE CONTROL SYSTEM

System Diagram




System Description

INFOID:0000000003856462

ECM performs various controls such as fuel injection control and ignition timing control.

Component Parts Location

INFOID:0000000003856463




- Intake valve timing control solenoid valve (bank 1)
- 4. Fuel injector (bank 2)
- Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air temperature sensor)
- 19. EVAP canister purge volume control solenoid valve
- 22. A/F sensor 1 (bank 1)

- Intake valve timing control solenoid valve (bank 2)
- Cooling fan motor-2
- Camshaft position sensor (PHASE) 8. (bank 2)
- 11. Cooling fan motor-1
- Battery current sensor
- 17. Electric throttle control actuator
- (bank 1)
- 23. Fuel injector (bank 1)


- Electronic controlled engine mount 3. control solenoid valve
- A/F sensor 1 (bank 2)
- 9. Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- 18. Power valve actuator 2 (VQ35DE
- Camshaft position sensor (PHASE) 21. Ignition coil (with power transistor) and spark plug (bank 1)
 - 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)

25. Power valve actuator 1




Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)






- Ignition coil (with power transistor) and spark plug (bank 1)
- Ignition coil (with power transistor) and spark plug (bank 2)

- Fuel injector (bank 1) 2.
- 5. **EVAP** canister
- Fuel injector (bank 2)



- Knock sensor (bank 1)
- Knock sensor (bank 2) 2.
- 3. Knock sensor



Α

EC

D

Е

Н

M


Ν

0

Р


- 1. Crankshaft position sensor (POS)
- Camshaft position sensor (PHASE) 3. (bank 2)
- Camshaft position sensor (PHASE) (bank 1)

< > : Vehicle front



- 1. Refrigerant pressure sensor
- 2. Battery current sensor


: Vehicle front




1. ECM

2. Fuel pump fuse


3. IPDM E/R






- A/F sensor 1 (bank 1) harness con- 2. nector
- 2. A/F sensor 1 (bank 1)
- A/F sensor 1 (bank 2) harness connector

4. A/F sensor 1 (bank 2)



- 1. HO2S2 (bank 1)
- 4. Tie-rod (RH)
- : Vehicle front

- 2. HO2S2 (bank 2)
- 5. Power steering pressure sensor
- 3. HO2S2 (bank 2) harness connector
- 6. HO2S2 (bank 1) harness connector



- Electronic controlled engine mount control solenoid valve
- 4. EVAP canister purge volume control solenoid valve
- Electronic controlled engine mount 2. VIAS control solenoid valve 1
- 3. VIAS control solenoid valve 2

EC

Α

D

Е

F

G

Н

|

J


K

M


Ν

0


Р




- Electronic controlled engine mount 2. control solenoid valve
- VIAS control solenoid valve
- EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. valve (bank 2)
 - solenoid 3. Data link connector



- 1. Stop lamp switch
- 2. ASCD brake switch
- 3. Accelerator pedal position sensor



- 1. ASCD steering switch
- 4. SET/COAST switch
- 2. CANCEL switch
- 5. MAIN switch

3. RESUME/ACCELERATE switch

Α

EC

D

Е

F

G

Н

Κ


L

M

Ν

0

Р



- Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector
- 3. Fuel level sensor unit and fuel pump

Component Description

INFOID:0000000003856464

Component	Reference
A/F sensor 1	EC-163, "Description"
A/F sensor 1 heater	EC-140, "Description"
Accelerator pedal position sensor	EC-304, "Description"
ASCD brake switch	EC-273, "Description"
ASCD steering switch	EC-270, "Description"
Battery current sensor	EC-258, "Description"
Camshaft position sensor (PHASE)	EC-222, "Description"
Crankshaft position sensor (POS)	EC-218, "Description"
Cooling fan motor	EC-324, "Description"
Electric throttle control actuator	EC-302, "Description"
Electronic controlled engine mount	EC-331, "Description"
Engine coolant temperature sensor	EC-157, "Description"
EVAP canister purge volume control solenoid valve	EC-231, "Description"
Fuel injector	EC-334, "Description"
Fuel pump	EC-337, "Description"
Heated oxygen sensor 2	EC-178, "Description"
Heated oxygen sensor 2 heater	EC-143, "Description"
Ignition coil with power transistor	EC-341, "Description"
Intake air temperature sensor	EC-154, "Description"
Intake valve timing control solenoid valve	EC-146, "Description"
Knock sensor	EC-215, "Description"
Mass air flow sensor	EC-149, "Description"
PCV valve	EC-347, "Description"
Power steering pressure sensor	EC-236, "Description"
Power valves 1 and 2	EC-351, "Description"
Refrigerant pressure sensor	EC-348, "Description"
Stop lamp switch	EC-291, "Description"
TCM (VQ35DE engine) Park/neutral position (PNP) switch (VQ25DE engine)	EC-245, "Description"
Throttle control motor	EC-300, "Description"

ENGINE CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]

Component	Reference
Throttle control motor relay	EC-294, "Description"
Throttle position sensor	EC-160, "Description"
VIAS control solenoid valve 1	EC-285, "Description"
VIAS control solenoid valve 2	EC-288, "Description"


Α

EC

D

MULTIPORT FUEL INJECTION SYSTEM

System Diagram



System Description

INPUT/OUTPUT SIGNAL CHART

INFOID:0000000003856466

Ν

< FUNCTION DIAGNOSIS >

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed*3		
Camshaft position sensor (PHASE)	Piston position		
Mass air flow sensor	Amount of intake air		
Intake air temperature sensor	Intake air temperature		
Engine coolant temperature sensor	Engine coolant temperature		
Air fuel ratio (A/F) sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position	For the latest and the second	
TCM (VQ35DE engine) Park/neutral position (PNP) switch (VQ25DE engine)	Gear position	- Fuel injection & mixture ratio control	Fuel injector
Battery	Battery voltage*3		
Knock sensor	Engine knocking condition		
Power steering pressure sensor	Power steering operation		
Heated oxygen sensor 2*1	Density of oxygen in exhaust gas		
ABS actuator and electric unit (control unit)	VDC/TCS operation command*2		
BCM	Air conditioner operation*2		
ABS actuator and electric unit (control unit)	Vehicle speed*2		

^{*1:} This sensor is not used to control the engine system under normal conditions.

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from the crankshaft position sensor (POS), camshaft position sensor (PHASE) and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.

<Fuel increase>

- During warm-up
- · When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from N to D
- High-load, high-speed operation


<Fuel decrease>

- During deceleration
- · During high engine speed operation

^{*2:} This signal is sent to the ECM through CAN communication line.

^{*3:} ECM determines the start signal status by the signals of engine speed and battery voltage.

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can better reduce CO, HC and NOx emissions. This system uses A/F sensor 1 in the exhaust manifold to monitor whether the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about A/F sensor 1, refer to EC-163, "Description". This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of A/F sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from heated oxygen sensor 2.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of A/F sensor 1 or its circuit
- Insufficient activation of A/F sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from N to D
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from A/F sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot wire) and characteristic changes during operation (i.e., fuel injector clogging) directly affect mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short-term fuel trim and long-term fuel trim.

"Short-term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from A/F sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long-term fuel trim" is overall fuel compensation carried out over time to compensate for continual deviation of the short-term fuel trim from the central value. Continual deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

EC

Α

D

Е

. .

Н


J

NI

Р

< FUNCTION DIAGNOSIS >

FUEL INJECTION TIMING



Two types of systems are used.

- Sequential Multiport Fuel Injection System Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.
- Simultaneous Multiport Fuel Injection System Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The six injectors will then receive the signals 2 times for each engine cycle.


This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration, operation of the engine at excessively high speeds or operation of the vehicle at excessively high speeds.

Component Parts Location

INFOID:0000000003857771



- Intake valve timing control solenoid valve (bank 1)
- 4. Fuel injector (bank 2)
- 7. Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air temperature sensor)
- EVAP canister purge volume control 20. solenoid valve
- 22. A/F sensor 1 (bank 1)
- 25. Power valve actuator 1

- Intake valve timing control solenoid valve (bank 2)
- 5. Cooling fan motor-2
- 8. Camshaft position sensor (PHASE) (bank 2)
- 11. Cooling fan motor-1
- 14. Battery current sensor
- 17. Electric throttle control actuator
 - Camshaft position sensor (PHASE) (bank 1)
- 23. Fuel injector (bank 1)

- 3. Electronic controlled engine mount control solenoid valve
- 6. A/F sensor 1 (bank 2)
- 9. Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- 18. Power valve actuator 2 (VQ35DE models)
- 21. Ignition coil (with power transistor) and spark plug (bank 1)
- 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)

EC

Α

_

D

Е

F

G

Н


K

M


Ν

0

Р




- Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)
- ⟨
 → : Vehicle front




- 1. Ignition coil (with power transistor) and spark plug (bank 1)
- 4. Ignition coil (with power transistor) and spark plug (bank 2)
- : Vehicle front

- 2. Fuel injector (bank 1)
- 5. EVAP canister

3. Fuel injector (bank 2)



- 1. Knock sensor (bank 1)
- 2. Knock sensor (bank 2)
- 3. Knock sensor



MULTIPORT FUEL INJECTION SYSTEM

< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]

Crankshaft position sensor (POS)

2. Camshaft position sensor (PHASE) 3. (bank 2)

Camshaft position sensor (PHASE) (bank 1)

Α

EC

D

Е

F

Н

K


M

Ν

0

Р


: Vehicle front



1. Refrigerant pressure sensor

2. Battery current sensor

: Vehicle front





1. ECM

Fuel pump fuse

3. IPDM E/R

: Vehicle front






- A/F sensor 1 (bank 1) harness con- 2. A/F sensor 1 (bank 1)
- A/F sensor 1 (bank 2) harness connector


A/F sensor 1 (bank 2)

⟨
⇒ : Vehicle front




- HO2S2 (bank 1)
- Tie-rod (RH)
- : Vehicle front


- HO2S2 (bank 2)
- Power steering pressure sensor
- HO2S2 (bank 2) harness connector
- HO2S2 (bank 1) harness connector




- Electronic controlled engine mount 2. VIAS control solenoid valve 1 control solenoid valve
- 4. EVAP canister purge volume control solenoid valve
- VIAS control solenoid valve 2




- Electronic controlled engine mount 2. control solenoid valve
- VIAS control solenoid valve
- EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. valve (bank 2)
 - B. Data link connector



- Stop lamp switch
- 2. ASCD brake switch
- 3. Accelerator pedal position sensor



- 1. ASCD steering switch
- SET/COAST switch
- 2. CANCEL switch
- 5. MAIN switch

3. RESUME/ACCELERATE switch

Α

EC

D

Е

=

G

Н

1

L


IV

Ν

0

P

Р



- Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector
- 3. Fuel level sensor unit and fuel pump

⟨□ : Vehicle front

Component Description

INFOID:0000000003856468

Component	Reference
A/F sensor 1	EC-163, "Description"
Accelerator pedal position sensor	EC-304, "Description"
Camshaft position sensor (PHASE)	EC-222, "Description"
Crankshaft position sensor (POS)	EC-218, "Description"
Engine coolant temperature sensor	EC-157, "Description"
Fuel injector	EC-334, "Description"
Heated oxygen sensor 2	EC-178, "Description"
Intake air temperature sensor	EC-154, "Description"
Knock sensor	EC-215, "Description"
Mass air flow sensor	EC-149, "Description"
Park/neutral position switch	EC-245, "Description"
Power steering pressure sensor	EC-236, "Description"
Throttle position sensor	EC-160, "Description"

[VQ25DE, VQ35DE]

Α

EC


D

N

ELECTRIC IGNITION SYSTEM

< FUNCTION DIAGNOSIS >

System Diagram



System Description

INFOID:0000000003856470

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator	
Crankshaft position sensor (POS)	Engine speed*2			
Camshaft position sensor (PHASE)	Piston position			
Mass air flow sensor	Amount of intake air			
Engine coolant temperature sensor	Engine coolant temperature			
Throttle position sensor	Throttle position			
Accelerator pedal position sensor	Accelerator pedal position	Ignition timing control	Ignition coil (with power transistor)	
Battery	Battery voltage*2	Control	(with power translator)	
Knock sensor	Engine knocking			
TCM (VQ35DE engine) Park/neutral position (PNP) switch (VQ25DE engine)	Gear position			
ABS actuator and electric unit (control unit)	Vehicle speed*1			

^{*1:} This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

Ignition order: 1 - 2 - 3 - 4 - 5 - 6

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM.

The ECM receives information such as the injection pulse width and camshaft position sensor (PHASE) signal. Computing this information, ignition signals are transmitted to the power transistor.

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not


EC-37

^{*2:} ECM determines the start signal status by the signals of engine speed and battery voltage.

operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

Component Parts Location


INFOID:0000000003857772




- Intake valve timing control solenoid valve (bank 1)
- 4. Fuel injector (bank 2)
- 7. Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air temperature sensor)
- 19. EVAP canister purge volume control solenoid valve
- 22. A/F sensor 1 (bank 1)
- 25. Power valve actuator 1

- Intake valve timing control solenoid valve (bank 2)
- 5. Cooling fan motor-2
- 8. Camshaft position sensor (PHASE) (bank 2)
- 11. Cooling fan motor-1
- 14. Battery current sensor
- 17. Electric throttle control actuator
- 20. Camshaft position sensor (PHASE) (bank 1)
- 23. Fuel injector (bank 1)

- 3. Electronic controlled engine mount control solenoid valve
- 6. A/F sensor 1 (bank 2)
- 9. Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- Power valve actuator 2 (VQ35DE models)
- 21. Ignition coil (with power transistor) and spark plug (bank 1)
- 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)




 Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)




- Ignition coil (with power transistor) and spark plug (bank 1)
- 4. Ignition coil (with power transistor) and spark plug (bank 2)

- 2. Fuel injector (bank 1)
- 5. EVAP canister
- 3. Fuel injector (bank 2)



- 1. Knock sensor (bank 1)
- 2. Knock sensor (bank 2)
- 3. Knock sensor



Α

EC

D

Е

F

G

Н

ı

J

K


M

Ν

0


- Crankshaft position sensor (POS)
- 2. Camshaft position sensor (PHASE) 3. (bank 2)
- Camshaft position sensor (PHASE) (bank 1)

< > : Vehicle front



- 1. Refrigerant pressure sensor
- 2. Battery current sensor


: Vehicle front




1. ECM

2. Fuel pump fuse


3. IPDM E/R






- A/F sensor 1 (bank 1) harness con- 2. nector
- . A/F sensor 1 (bank 1)
- A/F sensor 1 (bank 2) harness connector

4. A/F sensor 1 (bank 2)



- 1. HO2S2 (bank 1)
- 4. Tie-rod (RH)
- : Vehicle front

- 2. HO2S2 (bank 2)
- 5. Power steering pressure sensor
- 3. HO2S2 (bank 2) harness connector
- 6. HO2S2 (bank 1) harness connector



- Electronic controlled engine mount control solenoid valve
- 4. EVAP canister purge volume control solenoid valve
- Electronic controlled engine mount 2. VIAS control solenoid valve 1
- 3. VIAS control solenoid valve 2

EC

Α

D

Е

F

G

Н

1


J

K


M

Ν


0




- Electronic controlled engine mount 2. control solenoid valve
 - VIAS control solenoid valve
- EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. valve (bank 2)
 - B. Data link connector




- Stop lamp switch
- 2. ASCD brake switch
- 3. Accelerator pedal position sensor



- 1. ASCD steering switch
- 4. SET/COAST switch
- 2. CANCEL switch
- 5. MAIN switch

3. RESUME/ACCELERATE switch



Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector

3. Fuel level sensor unit and fuel pump

: Vehicle front

Component Description

INFOID:0000000003856472

Component	Reference
Accelerator pedal position sensor	EC-304, "Description"
Camshaft position sensor (PHASE)	EC-222, "Description"
Crankshaft position sensor (POS)	EC-218, "Description"
Engine coolant temperature sensor	EC-157, "Description"
Ignition signal	EC-341, "Description"
Knock sensor	EC-215, "Description"
Mass air flow sensor	EC-149, "Description"
Park/neutral position switch	EC-245, "Description"
Throttle position sensor	EC-160, "Description"

Α

EC

D

Е

F

G

Н

Κ

L


M

Ν

0

AIR CONDITIONING CUT CONTROL

System Diagram



System Description

INFOID:0000000003856474

[VQ25DE, VQ35DE]

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
ВСМ	Air conditioner ON signal*1		
Accelerator pedal position sensor	Accelerator pedal position		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*2		
Engine coolant temperature sensor	Engine coolant temperature	Air conditioner	Air conditioner relay
Battery	Battery voltage*2	cut control	
Refrigerant pressure sensor	Refrigerant pressure		
Power steering pressure sensor	Power steering operation		
ABS actuator and electric unit (control unit)	Vehicle speed*1		

^{*1:} This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION


This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned OFF.

- When the accelerator pedal is fully depressed.
- · When cranking the engine.
- At high engine speeds.
- · When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- · When engine speed is excessively low.
- · When refrigerant pressure is excessively low or high.

^{*2:} ECM determines the start signal status by the signals of engine speed and battery voltage.

Component Parts Location

INFOID:0000000003857773



- Intake valve timing control solenoid valve (bank 1)
- 4. Fuel injector (bank 2)
- 7. Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air temperature sensor)
- EVAP canister purge volume control 20. solenoid valve
- 22. A/F sensor 1 (bank 1)
- 25. Power valve actuator 1

- Intake valve timing control solenoid valve (bank 2)
- 5. Cooling fan motor-2
- 8. Camshaft position sensor (PHASE) (bank 2)
- 11. Cooling fan motor-1
- 14. Battery current sensor
- 17. Electric throttle control actuator
 - 20. Camshaft position sensor (PHASE) (bank 1)
- 23. Fuel injector (bank 1)

- 3. Electronic controlled engine mount control solenoid valve
- 6. A/F sensor 1 (bank 2)
- 9. Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- 18. Power valve actuator 2 (VQ35DE models)
- 21. Ignition coil (with power transistor) and spark plug (bank 1)
- 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)

EC

Α

0

D

Е

Н


K

M


N

Ν

0




- Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)
- $\ \ \ \ \ \ \ \ \ \ \$: Vehicle front




- Ignition coil (with power transistor) and spark plug (bank 1)
- 4. Ignition coil (with power transistor) and spark plug (bank 2)
- : Vehicle front

- 2. Fuel injector (bank 1)
- 5. EVAP canister

3. Fuel injector (bank 2)



- 1. Knock sensor (bank 1)
- 2. Knock sensor (bank 2)
- 3. Knock sensor



AIR CONDITIONING CUT CONTROL

AIR CONDITIONING COT CONTRO

< FUNCTION DIAGNOSIS > [VQ25DE, VQ35DE]

Crankshaft position sensor (POS)

2. Camshaft position sensor (PHASE) 3. (bank 2)

Camshaft position sensor (PHASE) (bank 1) А

EC

D

Е

F


Н

K

M

Ν


: Vehicle front



1. Refrigerant pressure sensor

2. Battery current sensor


: Vehicle front



1. ECM


Fuel pump fuse

3. IPDM E/R



Р


0



- A/F sensor 1 (bank 1) harness con- 2. A/F sensor 1 (bank 1)
- A/F sensor 1 (bank 2) harness connector


A/F sensor 1 (bank 2)

⟨
⇒ : Vehicle front




- HO2S2 (bank 1)
- Tie-rod (RH)
- : Vehicle front


- 2. HO2S2 (bank 2)
- Power steering pressure sensor
- HO2S2 (bank 2) harness connector
- HO2S2 (bank 1) harness connector




- Electronic controlled engine mount 2. VIAS control solenoid valve 1 control solenoid valve
- 4. EVAP canister purge volume control solenoid valve
- 3. VIAS control solenoid valve 2




- Electronic controlled engine mount 2. control solenoid valve
- VIAS control solenoid valve
- B. EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. valve (bank 2)
- 3. Data link connector



- 1. Stop lamp switch
- 2. ASCD brake switch
- 3. Accelerator pedal position sensor



- 1. ASCD steering switch
- SET/COAST switch
- 2. CANCEL switch
- 5. MAIN switch

3. RESUME/ACCELERATE switch

Α

EC

D

Е

-

G

Н

J

<


L

M

Ν

C

Р



- Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector
- 3. Fuel level sensor unit and fuel pump

 $\ \ \ \ \ \ \ \ \ \ \$: Vehicle front

Component Description


INFOID:0000000003856476

Component	Reference
Accelerator pedal position sensor	EC-304, "Description"
Camshaft position sensor (PHASE)	EC-222, "Description"
Crankshaft position sensor (POS)	EC-218, "Description"
Engine coolant temperature sensor	EC-157, "Description"
Power steering pressure sensor	EC-236, "Description"
Refrigerant pressure sensor	EC-348, "Description"

< FUNCTION DIAGNOSIS > [VQ25DE, VQ35DE]

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Diagram



System Description

INPUT/OUTPUT SIGNAL CHART

Sensor	Input signal to ECM	ECM function	Actuator
ASCD brake switch	Brake pedal operation		
Stop lamp switch	Brake pedal operation		
ASCD steering switch	ASCD steering switch operation	ASCD vehicle speed	Electric throttle control
TCM (VQ35DE engine)	Gear position	control	actuator
Park/neutral position (PNP) switch (VQ25DE engine)	Powertrain revolution*		
ABS actuator and electric unit (control unit)	Vehicle speed*		

^{*:} This signal is sent to the ECM through CAN communication line

BASIC ASCD SYSTEM

Refer to Owner's Manual for ASCD operating instructions.

Automatic Speed Control Device (ASCD) allows a driver to keep vehicle at predetermined constant speed without depressing accelerator pedal. Driver can set vehicle speed in advance between approximately 40 km/h (25 MPH) and 144 km/h (89 MPH).

ECM controls throttle angle of electric throttle control actuator to regulate engine speed.

Operation status of ASCD is indicated by CRUISE lamp and SET lamp in combination meter. If any malfunction occurs in the ASCD system, it automatically deactivates control.

NOTE:

Always drive vehicle in a safe manner according to traffic conditions and obey all traffic laws.

SET OPERATION

Press MAIN switch. (The CRUISE lamp in combination meter illuminates.)

When vehicle speed reaches a desired speed between approximately 40 km/h (25 MPH) and 144 km/h (89 MPH), press SET/COAST switch. (Then SET lamp in combination meter illuminates.)

ACCELERATE OPERATION

If the RESUME/ACCELERATE switch is pressed during cruise control driving, increase the vehicle speed until the switch is released or vehicle speed reaches maximum speed controlled by the system. And then ASCD will maintain the new set speed.

CANCEL OPERATION

When any of following conditions exist, cruise operation will be canceled.

- CANCEL switch is pressed
- More than 2 switches at ASCD steering switch are pressed at the same time (Set speed will be cleared)

EC

Α

D

Е

INFOID:0000000003856478

M

Ν

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

[VQ25DE, VQ35DE]

< FUNCTION DIAGNOSIS >

- · Brake pedal is depressed
- Selector lever position is N, P or R
- Vehicle speed decreased to 13 km/h (8 MPH) lower than the set speed
- TCS system is operated
- CVT control system has a malfunction. Refer to <u>EC-280, "Description"</u>.

When the ECM detects any of the following conditions, the ECM will cancel the cruise operation and inform the driver by blinking indicator lamp.

• Engine coolant temperature is slightly higher than the normal operating temperature, CRUISE lamp may blink slowly.

When the engine coolant temperature decreases to the normal operating temperature, CRUISE lamp will stop blinking and the cruise operation will be able to work by pressing SET/COAST switch or RESUME/ACCELERATE switch.

Malfunction for some self-diagnoses regarding ASCD control: SET lamp will blink quickly.
 If MAIN switch is turned to OFF while ASCD is activated, all of ASCD operations will be canceled and vehicle speed memory will be erased.

COAST OPERATION

When the SET/COAST switch is pressed during cruise control driving, decrease vehicle set speed until the switch is released. And then ASCD will maintain the new set speed.


RESUME OPERATION

When the RESUME/ACCELERATE switch is pressed after cancel operation other than pressing MAIN switch is performed, vehicle speed will return to last set speed. To resume vehicle set speed, vehicle condition must meet following conditions.

- Brake pedal is released
- Selector lever position is other than P and N
- Vehicle speed is greater than 40 km/h (25 MPH) and less than 144 km/h (89 MPH)

Component Parts Location

INFOID:0000000003857774



- Intake valve timing control solenoid valve (bank 1)
- 4. Fuel injector (bank 2)
- 7. Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air temperature sensor)
- EVAP canister purge volume control 20. solenoid valve
- 22. A/F sensor 1 (bank 1)
- 25. Power valve actuator 1

- Intake valve timing control solenoid valve (bank 2)
- 5. Cooling fan motor-2
- 3. Camshaft position sensor (PHASE) (bank 2)
- 11. Cooling fan motor-1
- 14. Battery current sensor
- 17. Electric throttle control actuator
 - Camshaft position sensor (PHASE) (bank 1)
- 23. Fuel injector (bank 1)

- 3. Electronic controlled engine mount control solenoid valve
- 6. A/F sensor 1 (bank 2)
- 9. Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- 18. Power valve actuator 2 (VQ35DE models)
- 21. Ignition coil (with power transistor) and spark plug (bank 1)
- 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)

EC

Α

D

Е

Н


J

K


M

Ν

0




- Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)
- ⟨
 → : Vehicle front



- 1. Ignition coil (with power transistor) and spark plug (bank 1)
- 4. Ignition coil (with power transistor) and spark plug (bank 2)
- : Vehicle front


- 2. Fuel injector (bank 1)
- 5. EVAP canister

3. Fuel injector (bank 2)



- 1. Knock sensor (bank 1)
- 2. Knock sensor (bank 2)
- Knock sensor

⟨
⇒ : Vehicle front



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

< FUNCTION DIAGNOSIS > [VQ25DE, VQ35DE]

1. Crankshaft position sensor (POS)

2. Camshaft position sensor (PHASE) 3. (bank 2)

Camshaft position sensor (PHASE) (bank 1)

Α

EC


D

Е

F

Н


⟨
⇒ : Vehicle front



1. Refrigerant pressure sensor

2. Battery current sensor

: Vehicle front




1. ECM

2. Fuel pump fuse

3. IPDM E/R

: Vehicle front



J

K

L


M

Ν

0

Ρ


< FUNCTION DIAGNOSIS >



- A/F sensor 1 (bank 1) harness con- 2. A/F sensor 1 (bank 1)
- A/F sensor 1 (bank 2) harness connector


A/F sensor 1 (bank 2)

⟨
⇒ : Vehicle front




- HO2S2 (bank 1)
- Tie-rod (RH)
- : Vehicle front


- HO2S2 (bank 2)
- Power steering pressure sensor
- HO2S2 (bank 2) harness connector
- HO2S2 (bank 1) harness connector




- Electronic controlled engine mount 2. VIAS control solenoid valve 1 control solenoid valve
- EVAP canister purge volume control solenoid valve
- VIAS control solenoid valve 2




- Electronic controlled engine mount 2. control solenoid valve
- VIAS control solenoid valve
- EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. valve (bank 2)
- Data link connector



- Stop lamp switch
- ASCD brake switch
- Accelerator pedal position sensor



- ASCD steering switch
- SET/COAST switch
- **CANCEL** switch 2.
- MAIN switch 5.

RESUME/ACCELERATE switch


Α

EC

D

Е

Ν



- Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector
- 3. Fuel level sensor unit and fuel pump

⟨□ : Vehicle front

Component Description

INFOID:0000000003856480

Component	Reference
ASCD steering switch	EC-270, "Description"
ASCD brake switch	EC-273, "Description"
ASCD clutch switch	EC-273, "Description"
Stop lamp switch	EC-291, "Description"
Electric throttle control actuator	EC-302, "Description"
ASCD indicator	EC-323, "Description"

CAN COMMUNICATION

< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]

CAN COMMUNICATION

System Description

INFOID:0000000003856481

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Refer to LAN-22, "CAN System Specification Chart", about CAN communication for detail.

EC

Α

D

Е

F

Н

K

L


M

Ν

COOLING FAN CONTROL

System Diagram

INFOID:0000000003856482



System Description

INFOID:0000000003856483

INPUT/OUTPUT SIGNAL CHART

Sensor	Input signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*1	Cooling fan control IPDM E/R ↓ Cooling fan relay ↓ Cooling fan motor	
Battery	Battery voltage*1		
ABS actuator and electric unit (control unit)	Vehicle speed*2		
Engine coolant temperature sensor	Engine coolant temperature		
ВСМ	Air conditioner ON signal*2		
Refrigerant pressure sensor	Refrigerant pressure		


^{*1:} The ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 4-step control [HIGH/MIDDLE/LOW/OFF].

^{*2:} This signal is sent to ECM through CAN communication line.

Cooling Fan Operation



Cooling Fan Relay Operation

The ECM controls cooling fan relays in the IPDM E/R through CAN communication line.

Cooling for aroad		Cooling fan relay		
Cooling fan speed	1	2	3	
Stop (OFF)	OFF	OFF	OFF	
Low (LOW)	ON	OFF	OFF	
Middle (MID)	OFF	ON	OFF	
High (HI)	OFF	ON	ON	

Α

EC

D

Е

F

G

Н

J

K


M

Ν

0

Component Parts Location


INFOID:0000000003857775




- Intake valve timing control solenoid valve (bank 1)
- Fuel injector (bank 2) 4.
- Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air temperature sensor)
- 19. EVAP canister purge volume control solenoid valve
- 22. A/F sensor 1 (bank 1)
- 25. Power valve actuator 1


- Intake valve timing control solenoid valve (bank 2)
- Cooling fan motor-2
- Camshaft position sensor (PHASE) (bank 2)
- 11. Cooling fan motor-1
- 14. Battery current sensor
- 17. Electric throttle control actuator
- 20. Camshaft position sensor (PHASE) 21. Ignition coil (with power transistor) (bank 1)
- 23. Fuel injector (bank 1)

- Electronic controlled engine mount 3. control solenoid valve
- A/F sensor 1 (bank 2)
- Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- 18. Power valve actuator 2 (VQ35DE models)
- and spark plug (bank 1)
- 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)




Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)






- Ignition coil (with power transistor) and spark plug (bank 1)
- Ignition coil (with power transistor) and spark plug (bank 2)

- Fuel injector (bank 1) 2.
- 5. **EVAP** canister
- Fuel injector (bank 2)



- Knock sensor (bank 1)
- Knock sensor (bank 2) 2.
- 3. Knock sensor



Α

EC

D

Е

Н


M

Ν

0


- Crankshaft position sensor (POS)
- Camshaft position sensor (PHASE) 3. (bank 2)
- Camshaft position sensor (PHASE) (bank 1)

< : Vehicle front



- 1. Refrigerant pressure sensor
- 2. Battery current sensor


: Vehicle front




1. ECM

2. Fuel pump fuse


3. IPDM E/R






- A/F sensor 1 (bank 1) harness con- 2. nector
- 2. A/F sensor 1 (bank 1)
- A/F sensor 1 (bank 2) harness connector

4. A/F sensor 1 (bank 2)



- 1. HO2S2 (bank 1)
- 4. Tie-rod (RH)
- : Vehicle front

- 2. HO2S2 (bank 2)
- 5. Power steering pressure sensor
- 3. HO2S2 (bank 2) harness connector
- 6. HO2S2 (bank 1) harness connector



- Electronic controlled engine mount control solenoid valve
- 4. EVAP canister purge volume control solenoid valve
- Electronic controlled engine mount 2. VIAS control solenoid valve 1
- 3. VIAS control solenoid valve 2

EC

Α

D

Е

F

G

Н

1


J

K


M

Ν


0




- Electronic controlled engine mount 2. control solenoid valve
- VIAS control solenoid valve
- EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. valve (bank 2)
 - 3. Data link connector




- Stop lamp switch
- 2. ASCD brake switch
- 3. Accelerator pedal position sensor



- 1. ASCD steering switch
- SET/COAST switch
- 2. CANCEL switch
- 5. MAIN switch

3. RESUME/ACCELERATE switch



Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector

3. Fuel level sensor unit and fuel pump

: Vehicle front

Component Description

INFOID:0000000003856485

Component	Reference
Camshaft position sensor (PHASE)	EC-222, "Description"
Crankshaft position sensor (POS)	EC-218, "Description"
Cooling fan motor	EC-324, "Description"
Engine coolant temperature sensor	EC-157, "Description"
Refrigerant pressure sensor	EC-348, "Description"

Α

EC

D

Е

F

G

Н

K

L


M

Ν


0

ELECTRONIC CONTROLLED ENGINE MOUNT

System Diagram



- 1. Power valve actuator 1
- 4. Power valve actuator 2
- : From next figure
- 2. VIAS control solenoid valve 1
- 5. Intake manifold collector
- 3. VIAS control solenoid valve 2



- Electronic controlled engine mount 2. control solenoid valve
- Front electronic controlled engine mount
- Rear electronic controlled engine mount

: To previous figure

NOTE:

Do not use soapy water or any type of solvent while installing vacuum hose.

System Description

INPUT/OUTPUT SIGNAL CHART

Sensor	Input signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed	Engine mount	Electronic controlled engine mount control solenoid
ABS actuator and electric unit (control unit)	Vehicle speed*	CONTROL	valve

^{*:} This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

EC

Α

D

Е

F

G

Н

1 \

L

M

N

INFOID:0000000003856487

F

The ECM controls the engine mount operation corresponding to the engine speed. The control system has a 2-step control [Soft/Hard]


Vehicle condition	Engine mount control
Engine speed: Below 950 rpm	Soft
Engine speed: Above 950 rpm	Hard

Component Parts Location

< FUNCTION DIAGNOSIS >

INFOID:0000000003860670

[VQ25DE, VQ35DE]



- Intake valve timing control solenoid valve (bank 1)
- Fuel injector (bank 2)
- Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air 17. Electric throttle control actuator temperature sensor)
- solenoid valve

- Intake valve timing control solenoid valve (bank 2)
- 5. Cooling fan motor-2
- Camshaft position sensor (PHASE) 9. (bank 2)
- 11. Cooling fan motor-1
- 14. Battery current sensor
- (bank 1)

- Electronic controlled engine mount control solenoid valve
- A/F sensor 1 (bank 2)
- Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- 18. Power valve actuator 2 (VQ35DE models)
- 19. EVAP canister purge volume control 20. Camshaft position sensor (PHASE) 21. Ignition coil (with power transistor) and spark plug (bank 1)

ELECTRONIC CONTROLLED ENGINE MOUNT

ELECTRONIC CONTROLLED ENGINE MOON


22. A/F sensor 1 (bank 1)

< FUNCTION DIAGNOSIS >

- 23. Fuel injector (bank 1)
- 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)


[VQ25DE, VQ35DE]

25. Power valve actuator 1



 Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)

: Vehicle front



- 1. Ignition coil (with power transistor) and spark plug (bank 1)

EVAP canister


2.

5.

Fuel injector (bank 1)

3. Fuel injector (bank 2)

- 4. Ignition coil (with power transistor) and spark plug (bank 2)
- : Vehicle front



- 1. Knock sensor (bank 1)
- 2. Knock sensor (bank 2)
- 3. Knock sensor

∠ : Vehicle front

EC

Α

D

Е

F

G

Н

J


K

L

M


Ν

C




- 1. Crankshaft position sensor (POS)
- Camshaft position sensor (PHASE) 3. (bank 2)
- Camshaft position sensor (PHASE) (bank 1)

 $\ \ \ \ \ \ \ \ \ \ \$: Vehicle front



- 1. Refrigerant pressure sensor
- 2. Battery current sensor

: Vehicle front



1. ECM


2. Fuel pump fuse


3. IPDM E/R

⟨
→ : Vehicle front

ELECTRONIC CONTROLLED ENGINE MOUNT


< FUNCTION DIAGNOSIS > [VQ25DE, VQ35DE]





- A/F sensor 1 (bank 1) harness con A/F sensor 1 (bank 1) nector
- A/F sensor 1 (bank 2) harness connector

- 4. A/F sensor 1 (bank 2)
- : Vehicle front



- 1. HO2S2 (bank 1)
- 4. Tie-rod (RH)
- : Vehicle front

- 2. HO2S2 (bank 2)
- 5. Power steering pressure sensor
- 3. HO2S2 (bank 2) harness connector
- 6. HO2S2 (bank 1) harness connector

Α

EC

0

D

Е

F

G

Н


Κ

ı

M


Ν

0




- Electronic controlled engine mount control solenoid valve
- VIAS control solenoid valve 1
- VIAS control solenoid valve 2


EVAP canister purge volume control solenoid valve



- Electronic controlled engine mount control solenoid valve
- 2. VIAS control solenoid valve
- EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. Data link connector valve (bank 2)




- Stop lamp switch
- 2. ASCD brake switch
- Accelerator pedal position sensor

ELECTRONIC CONTROLLED ENGINE MOUNT


< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]



- ASCD steering switch
- SET/COAST switch
- 2. CANCEL switch
- 5. MAIN switch

RESUME/ACCELERATE switch



Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector

3. Fuel level sensor unit and fuel pump

Component Description

INFOID:0000000003856489

Component	Reference
Camshaft position sensor (PHASE)	EC-222, "Description"
Crankshaft position sensor (POS)	EC-218, "Description"
Electronic controlled engine mount control solenoid valve	EC-331, "Description"

Α

EC

D

Е

G

Н

K

M


Ν

0

EVAPORATIVE EMISSION SYSTEM

System Diagram

INFOID:0000000003949755



System Description

INFOID:0000000003949756

INPUT/OUTPUT SIGNAL CHART


Sensor	Input signal to ECM	ECM function	Actuator	
Crankshaft position sensor (POS)	Engine speed*1			
Camshaft position sensor (PHASE)	Piston position			
Mass air flow sensor	Amount of intake air			
Engine coolant temperature sensor	Engine coolant temperature			
Air fuel ratio (A/F) sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	EVAP canister purge flow control	EVAP canister purge vol- ume control solenoid valve	
Throttle position sensor	Throttle position			
Accelerator pedal position sensor	Accelerator pedal position			
Battery	Battery voltage*1			
ABS actuator and electric unit (control unit)	Vehicle speed*2			

^{*1:} ECM determines the start signal status by the signals of engine speed and battery voltage.

^{*2:} This signal is sent to the ECM through CAN communication line.

[VQ25DE, VQ35DE]

SYSTEM DESCRIPTION



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.

The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank.

The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases.

EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.

EVAPORATIVE EMISSION LINE DRAWING

Α

EC

C

D

Е

F

G

ш

Н

J


K

L

M

Ν


0



1. Intake manifold

EVAP canister purge volume control solenoid valve

A. From EVAP canister



EVAP canister
 : Vehicle front

A. To previous figure

B. To/From B in this figure

NOTE:

Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

Α

EC

C

D

Е

F

G

Н

J

Κ

L

M


Ν

0

Ρ

Component Parts Location

INFOID:0000000003857776





- Intake valve timing control solenoid valve (bank 1)
- Fuel injector (bank 2) 4.
- Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air temperature sensor)
- 19. EVAP canister purge volume control solenoid valve
- 22. A/F sensor 1 (bank 1)
- 25. Power valve actuator 1

- Intake valve timing control solenoid valve (bank 2)
- Cooling fan motor-2
- Camshaft position sensor (PHASE) (bank 2)
- 11. Cooling fan motor-1
- 14. Battery current sensor
- 17. Electric throttle control actuator
- 20. Camshaft position sensor (PHASE) 21. Ignition coil (with power transistor) (bank 1)
- 23. Fuel injector (bank 1)

- Electronic controlled engine mount 3. control solenoid valve
- A/F sensor 1 (bank 2)
- 9. Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- 18. Power valve actuator 2 (VQ35DE models)
- and spark plug (bank 1)
- 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)


Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)






- Ignition coil (with power transistor) and spark plug (bank 1)
- Ignition coil (with power transistor) and spark plug (bank 2)

- Fuel injector (bank 1) 2.
- 5. **EVAP** canister
- Fuel injector (bank 2)



- Knock sensor (bank 1)
- Knock sensor (bank 2) 2.
- 3. Knock sensor



Α

EC

D

Е

Н


M

Ν

0

- 1. Crankshaft position sensor (POS)
- 2. Camshaft position sensor (PHASE) 3. (bank 2)
- Camshaft position sensor (PHASE) (bank 1)


< > : Vehicle front



1. Refrigerant pressure sensor

2. Battery current sensor


: Vehicle front




1. ECM

2. Fuel pump fuse


3. IPDM E/R






- A/F sensor 1 (bank 1) harness con- 2. nector
- 2. A/F sensor 1 (bank 1)
- A/F sensor 1 (bank 2) harness connector

4. A/F sensor 1 (bank 2)



- 1. HO2S2 (bank 1)
- 4. Tie-rod (RH)
- : Vehicle front

- 2. HO2S2 (bank 2)
- 5. Power steering pressure sensor
- 3. HO2S2 (bank 2) harness connector
- 6. HO2S2 (bank 1) harness connector



- Electronic controlled engine mount control solenoid valve
- 4. EVAP canister purge volume control solenoid valve
- Electronic controlled engine mount 2. VIAS control solenoid valve 1
- 3. VIAS control solenoid valve 2

EC

Α

D

Е

F

G

Н

1


J

K


M

Ν


0




- Electronic controlled engine mount 2. control solenoid valve
- VIAS control solenoid valve
- EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. valve (bank 2)
 - enoid 3. Data link connector




- 1. Stop lamp switch
- 2. ASCD brake switch
- 3. Accelerator pedal position sensor



- 1. ASCD steering switch
- SET/COAST switch
- 2. CANCEL switch
- 5. MAIN switch

3. RESUME/ACCELERATE switch



Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector

3. Fuel level sensor unit and fuel pump

Component Description

INFOID:0000000003856493

Component	Reference
A/F sensor 1	EC-163, "Description"
Accelerator pedal position sensor	EC-304, "Description"
Camshaft position sensor (PHASE)	EC-222, "Description"
Crankshaft position sensor (POS)	EC-218, "Description"
Engine coolant temperature sensor	EC-157, "Description"
EVAP canister purge volume control solenoid valve	EC-231, "Description"
Mass air flow sensor	EC-149, "Description"
Throttle position sensor	EC-160, "Description"

Α

EC

D

Е

F

G

Н

Κ

L

M


Ν

0

INTAKE VALVE TIMING CONTROL

System Diagram

INFOID:0000000003856494



System Description


INFOID:0000000003856495

INPUT/OUTPUT SIGNAL CHART

Sensor	Input signal to ECM	ECM function	Actuator	
Crankshaft position sensor (POS)	Engine speed and piston position			
Camshaft position sensor (PHASE)	Engine speed and piston position	Intake valve timing control	Intake valve timing control solenoid valve	
Engine oil temperature sensor	Engine oil temperature			
Engine coolant temperature sensor	Engine coolant temperature			
ABS actuator and electric unit (control unit)	Vehicle speed*			

^{*:} This signal is sent to the ECM through CAN communication line

SYSTEM DESCRIPTION




This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing (IVT) control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

Component Parts Location

INFOID:0000000003857777



- Intake valve timing control solenoid valve (bank 1)
- 4. Fuel injector (bank 2)
- 7. Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air temperature sensor)
- EVAP canister purge volume control 20. solenoid valve
- 22. A/F sensor 1 (bank 1)
- 25. Power valve actuator 1

- Intake valve timing control solenoid valve (bank 2)
- 5. Cooling fan motor-2
- 3. Camshaft position sensor (PHASE) (bank 2)
- 11. Cooling fan motor-1
- 14. Battery current sensor
- 17. Electric throttle control actuator
 - Camshaft position sensor (PHASE) (bank 1)
- 23. Fuel injector (bank 1)

- 3. Electronic controlled engine mount control solenoid valve
- 6. A/F sensor 1 (bank 2)
- 9. Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- 18. Power valve actuator 2 (VQ35DE models)
- 21. Ignition coil (with power transistor) and spark plug (bank 1)
- 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)

EC

Α

0

D

Е

F

G


Н

<


M

Ν

0




- Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)
- $\ \ \ \ \ \ \ \ \ \ \$: Vehicle front




- 1. Ignition coil (with power transistor) and spark plug (bank 1)
- 4. Ignition coil (with power transistor) and spark plug (bank 2)
- : Vehicle front

- 2. Fuel injector (bank 1)
- 5. EVAP canister

3. Fuel injector (bank 2)



- 1. Knock sensor (bank 1)
- 2. Knock sensor (bank 2)
- 3. Knock sensor



INTAKE VALVE TIMING CONTROL

< FUNCTION DIAGNOSIS >


[VQ25DE, VQ35DE]

Crankshaft position sensor (POS)

2. Camshaft position sensor (PHASE) 3. (bank 2)

Camshaft position sensor (PHASE) (bank 1)


: Vehicle front



1. Refrigerant pressure sensor

2. Battery current sensor


: Vehicle front



1. ECM

Fuel pump fuse

3. IPDM E/R



С

Α

EC

D

Е

F

G

Н

J


Κ

ı

M

Ν


0



- A/F sensor 1 (bank 1) harness con- 2. A/F sensor 1 (bank 1)
- A/F sensor 1 (bank 2) harness connector


A/F sensor 1 (bank 2)

⟨
⇒ : Vehicle front




- HO2S2 (bank 1)
- Tie-rod (RH)
- : Vehicle front


- HO2S2 (bank 2)
- Power steering pressure sensor
- HO2S2 (bank 2) harness connector
- HO2S2 (bank 1) harness connector




- control solenoid valve
- 4. EVAP canister purge volume control solenoid valve
- Electronic controlled engine mount 2. VIAS control solenoid valve 1
- 3. VIAS control solenoid valve 2




- Electronic controlled engine mount 2. control solenoid valve
- VIAS control solenoid valve
- B. EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. valve (bank 2)
 - B. Data link connector



- 1. Stop lamp switch
- 2. ASCD brake switch
- 3. Accelerator pedal position sensor



- 1. ASCD steering switch
- 4. SET/COAST switch
- 2. CANCEL switch
- 5. MAIN switch

3. RESUME/ACCELERATE switch

Α

EC

D

Е

=

G

Н

J


<

L

N

Ν

C



- Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector
- 3. Fuel level sensor unit and fuel pump

 $\ \ \ \ \ \ \ \ \ \ \$: Vehicle front

Component Description


INFOID:0000000003856497

Component	Reference
Camshaft position sensor (PHASE)	EC-222, "Description"
Crankshaft position sensor (POS)	EC-218, "Description"
Engine coolant temperature sensor	EC-157, "Description"
Intake valve timing control solenoid valve	EC-146, "Description"

[VQ25DE, VQ35DE]

VARIABLE INDUCTION AIR SYSTEM

System Diagram



System Description


INFOID:0000000003856499

INPUT/OUTPUT SIGNAL CHART

Sensor	Input signal to ECM	ECM function	Actuator	
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*			_
Mass air flow sensor	Amount of intake air			
Engine coolant temperature sensor	Engine coolant temperature	VIAS control	VIAS control solenoid valve 1 VIAS control solenoid valve 2	
Throttle position sensor	Throttle position		VIAS control solenoid valve 2	
Accelerator pedal position sensor	Accelerator pedal position			
Battery	Battery voltage*			

^{*:} ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION



EC

Α

D

Е

F

ı

Ν

0


< FUNCTION DIAGNOSIS >

In the medium speed range, the power valves are closed. Under this condition, the pressure waves of the exhaust stroke do not disturb the pressure waves of the intake stroke of each opposite bank. Therefore, charging efficiency is increased together with the effect of the long intake passage.

However, in the high speed range, the power valves are open. Under this condition, the pressure waves of intake stroke are resonant with those of each opposite bank exhaust stroke. Therefore, charging efficiency is also increased.


In addition, both valves (valves 1 and 2 for VQ35DE engine and a valve for VQ25DE engine) are opened or closed in other ranges mentioned above. Thus maximum charging efficiency is obtained for the various driving conditions.

VACUUM HOSE DRAWING (VQ35DE engine)



- 1. Power valve actuator 1
- 2. VIAS control solenoid valve 1
- Power valve actuator 2
- 5. Intake manifold collector
- 3. VIAS control solenoid valve 2

VACUUM HOSE DRAWING (VQ25DE engine)



1. Power valve actuator

VIAS control solenoid valve
 Intake manifold collector

EC

Α

D

Е


Κ

Ν

0

Component Parts Location


INFOID:0000000003860679



- Intake valve timing control solenoid valve (bank 1)
- Fuel injector (bank 2) 4.
- Ignition coil (with power transistor) and spark plug (bank 2)
- 10. Engine coolant temperature sensor
- 13. Refrigerant pressure sensor
- 16. Mass air flow sensor (with intake air temperature sensor)
- 19. EVAP canister purge volume control solenoid valve
- 22. A/F sensor 1 (bank 1)
- 25. Power valve actuator 1


- Intake valve timing control solenoid valve (bank 2)
- Cooling fan motor-2
- Camshaft position sensor (PHASE) (bank 2)
- 11. Cooling fan motor-1
- 14. Battery current sensor
- 17. Electric throttle control actuator
- (bank 1)
- 23. Fuel injector (bank 1)

- Electronic controlled engine mount 3. control solenoid valve
- A/F sensor 1 (bank 2)
- 9. Crankshaft position sensor (POS)
- 12. ECM
- 15. IPDM E/R
- 18. Power valve actuator 2 (VQ35DE models)
- 20. Camshaft position sensor (PHASE) 21. Ignition coil (with power transistor) and spark plug (bank 1)
 - 24. VIAS control solenoid valve 1 and 2 (VQ35DE models)




 Mass air flow sensor (with intake air 2. Electric throttle control actuator temperature sensor)






- 1. Ignition coil (with power transistor) and spark plug (bank 1)
- 4. Ignition coil (with power transistor) and spark plug (bank 2)

- 2. Fuel injector (bank 1)
- 5. EVAP canister
- Fuel injector (bank 2)



- 1. Knock sensor (bank 1)
- 2. Knock sensor (bank 2)
- Knock sensor



EC

Α

D

Е

F

G

Н

J

K


L

M

Ν


- Crankshaft position sensor (POS)
- 2. Camshaft position sensor (PHASE) 3. (bank 2)
- Camshaft position sensor (PHASE) (bank 1)

< : Vehicle front



- 1. Refrigerant pressure sensor
- 2. Battery current sensor


⟨
→ : Vehicle front




1. ECM

2. Fuel pump fuse

3. IPDM E/R




VARIABLE INDUCTION AIR SYSTEM




- A/F sensor 1 (bank 1) harness con- 2. nector
 - . A/F sensor 1 (bank 1)
- A/F sensor 1 (bank 2) harness connector

4. A/F sensor 1 (bank 2)



- 1. HO2S2 (bank 1)
- 4. Tie-rod (RH)
- : Vehicle front

- 2. HO2S2 (bank 2)
- 5. Power steering pressure sensor
- 3. HO2S2 (bank 2) harness connector
- 6. HO2S2 (bank 1) harness connector



- Electronic controlled engine mount control solenoid valve
- 4. EVAP canister purge volume control solenoid valve
- Electronic controlled engine mount 2. VIAS control solenoid valve 1
- 3. VIAS control solenoid valve 2

EC

Α

D

Е

F

G

Н

1


J

K


M

Ν


0




- Electronic controlled engine mount 2. control solenoid valve
- VIAS control solenoid valve
- EVAP canister purge volume control solenoid valve



- Intake valve timing control solenoid 2. valve (bank 1)
- Intake valve timing control solenoid 3. valve (bank 2)
 - trol solenoid 3. Data link connector




- 1. Stop lamp switch
- 2. ASCD brake switch
- 3. Accelerator pedal position sensor



- 1. ASCD steering switch
- 4. SET/COAST switch
- 2. CANCEL switch
- 5. MAIN switch

3. RESUME/ACCELERATE switch



Fuel level sensor unit and fuel pump 2. Fuel pressure regulator harness connector

3. Fuel level sensor unit and fuel pump

Component Description

INFOID:0000000003856501

Component	Reference
Accelerator pedal position sensor	EC-304, "Description"
Camshaft position sensor (PHASE)	EC-222, "Description"
Crankshaft position sensor (POS)	EC-218, "Description"
Engine coolant temperature sensor	EC-157, "Description"
Mass air flow sensor	EC-149, "Description"
Throttle position sensor	EC-160, "Description"
Power valve 1 and 2	EC-351, "Description"
VIAS control solenoid valve 1	EC-285, "Description"
VIAS control solenoid valve 2	EC-288, "Description"

Α

EC

D

Е

F

G

Н

Κ

L

M

Ν

0

ON BOARD DIAGNOSTIC (OBD) SYSTEM

Diagnosis Description

INFOID:0000000003856502

INTRODUCTION

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information	Diagnostic service
Diagnostic Trouble Code (DTC)	Service \$03 of ISO 15031-5
Freeze Frame data	Service \$02 of ISO 15031-5
System Readiness Test (SRT) code	Service \$01 of ISO 15031-5
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Service \$07 of ISO 15031-5
1st Trip Freeze Frame data	_
Test values and Test limits	Service \$06 of ISO 15031-5
Calibration ID	Service \$09 of ISO 15031-5

The above information can be checked using procedures listed in the table below.

×: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	SRT status	Test value
CONSULT-III	×	×	×	×	×	×	_
GST	×	×	×	_	×	×	×
ECM	×	×*	_	_	_	×	_

^{*:} When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator MI on the instrument panel illuminates when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to EC-386, "Fail safe.)

TWO TRIP DETECTION LOGIC

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MI will not illuminate at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MI illuminates. The MI illuminates at the same time the DTC is stored. <2nd trip> The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to illuminate or blink the MI, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

×: Applicable —: Not applicable

	MI				DTC		1st trip DTC	
Items	1st trip		2nd trip		4 04 4 11 10	0.163	1 ot trip	2nd trip
ione	Blinking	Illuminat- ed	Blinking	Illuminat- ed	1st trip displaying	2nd trip displaying	1st trip displaying	display- ing
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	×	_	_	_	_	_	×	_
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	_	_	×	_	_	×	_	_
One trip detection diagnoses (Refer to EC-389, "DTC Index".)	_	×	_	_	×	_	_	_
Except above	_	_	_	×	_	×	×	_

DTC AND FREEZE FRAME DATA

DTC and 1st Trip DTC

[VQ25DE, VQ35DE]

EC

D

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not recur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is saved in the ECM memory. The MI will not illuminate (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are saved in the ECM memory and the MI illuminates. In other words, the DTC is stored in the ECM memory and the MI illuminates when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or illuminate the MI during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in "How to Erase DTC and 1st Trip DTC".

For malfunctions in which 1st trip DTCs are displayed, refer to "EMISSION-RELATED DIAGNOSTIC INFOR-MATION ITEMS". These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-III.

1st trip DTC is specified in Service \$07 of ISO 15031-5. 1st trip DTC detection occurs without illuminating the MI and therefore does not warn the driver of a malfunction. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in Work Flow procedure Step 2, refer to EC-7, "Work Flow". Then perform DTC Confirmation Procedure or Component Function Check to try to duplicate the malfunction. If the malfunction is duplicated, the item requires repair.

Freeze Frame Data and 1st Trip Freeze Frame Data

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short-term fuel trim, long-term fuel trim, engine speed, vehicle speed, absolute throttle position, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-III or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-III screen, not on the GST.

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MI on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items			
1	Freeze frame data	Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175		
2		Except the above items (Includes CVT related items)		
3	1st trip freeze frame d	ata		

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was saved in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in "How to Erase DTC and 1st Trip DTC".

How to Read DTC and 1st Trip DTC

(a) With CONSULT-III

With GST

CONSULT-III or GST (Generic Scan Tool) Examples: P0340, P0850, P1148, etc.

These DTCs are prescribed by ISO 15031-6.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VQ25DE, VQ35DE]

< FUNCTION DIAGNOSIS >

(CONSULT-III also displays the malfunctioning component or system.)

No Tools

The number of blinks of the MI in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Example: 0340, 0850, 1148, etc.

These DTCs are controlled by NISSAN.

- 1st trip DTC No. is the same as DTC No.
- Output of a DTC indicates a malfunction. However, GST or the Diagnostic Test Mode II do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-III can identify malfunction status as shown below. Therefore, using CONSULT-III (if available) is recommended.

DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-III. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be [0].

If a 1st trip DTC is stored in the ECM, the time data will be [1t].

How to Erase DTC and 1st Trip DTC

(P) With CONSULT-III

NOTE:

- If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
- If the DTC is not for CVT related items (see EC-389), skip step 1.
- 1. Erase DTC in TCM. Refer to TM-35, "Diagnosis Description".
- 2. Select "ENGINE" with CONSULT-III.
- 3. Select "SELF-DIAG RESULTS".
- 4. Touch "ERASE". (DTC in ECM will be erased.)

WITH GST

NOTE:

- If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
- 1. Select Service \$04 with GST (Generic Scan Tool).

No Tools

NOTE:

- If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
- 1. Erase DTC in ECM. Refer to How to Erase Diagnostic Test Mode II (Self-diagnostic Results).
- If the battery is disconnected, the emission-related diagnostic information will be cleared within 24 hours.
- The following data are cleared when the ECM memory is erased.
- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

SYSTEM READINESS TEST (SRT) CODE

System Readiness Test (SRT) code is specified in Service \$01 of ISO 15031-5.

As part of an enhanced emissions test for Inspection & Maintenance (I/M), certain states require the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "INCMP", use the information in this Service Manual to set the SRT to "CMPLT".

In most cases the ECM will automatically complete its self-diagnosis cycle during normal usage, and the SRT status will indicate "CMPLT" for each application system. Once set as "CMPLT", the SRT status remains "CMPLT" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern; the SRT will indicate "INCMP" for these items.

NOTE:

ON BOARD DIAGNOSTIC (OBD) SYSTEM

< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]

The SRT will also indicate "INCMP" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "CMPLT" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "INCMP" for one or more of the SRT items the vehicle is returned to the customer untested.

NOTE:

If MI is ON during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "CMPLT" for all test items. Therefore, it is important to check SRT ("CMPLT") and DTC (No DTCs) before the inspection.

SRT Item

The table below shows required self-diagnostic items to set the SRT to "CMPLT".

SRT item (CONSULT-III indication)	Performance Priority*	Required self-diagnostic items to set the SRT to "CMPLT"	Corresponding DTC No.
CATALYST	2	Three way catalyst function	P0420, P0430
HO2S	2	Air fuel ratio (A/F) sensor 1	P0133, P0153
		Heated oxygen sensor 2	P0137, P0157
		Heated oxygen sensor 2	P0138, P0158
		Heated oxygen sensor 2	P0139, P0159

^{*:} If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure), one by one based on the priority for models with CONSULT-III.

SRT Set Timing

SRT is set as "CMPLT" after self-diagnosis has been performed one or more times. Completion of SRT is done regardless of whether the result is OK or NG. The set timing is different between OK and NG results and is shown in the table below.

			Example									
Self-diagnosis result		Diagnosis	$\begin{array}{cccccccccccccccccccccccccccccccccccc$									
All OK	Case 1	P0400	OK (1)	—(1)	OK (2)	— (2)						
		P0402	OK (1)	—(1)	— (1)	OK (2)						
		P1402	OK (1)	OK (2)	— (2)	— (2)						
		SRT of EGR	"CMPLT"	"CMPLT"	"CMPLT"	"CMPLT"						
	Case 2	P0400	OK (1)	—(1)	— (1)	— (1)						
		P0402	— (0)	— (0)	OK (1)	— (1)						
		P1402	OK (1)	OK (2)	— (2)	— (2)						
		SRT of EGR	"INCMP"	"INCMP"	"CMPLT"	"CMPLT"						
NG exists	Case 3	P0400	OK	OK OK		_						
		P0402	_	_	_	_						
		P1402	NG	_	NG	NG (Consecutive NG)						
		(1st trip) DTC	1st trip DTC	_	1st trip DTC	DTC (= MI ON)						
		SRT of EGR	"INCMP"	"INCMP"	"INCMP"	"CMPLT"						

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is NG.

When all SRT related self-diagnoses show OK results in a single cycle (Ignition OFF-ON-OFF), the SRT will indicate "CMPLT". → Case 1 above

When all SRT related self-diagnoses show OK results through several different cycles, the SRT will indicate "CMPLT" at the time the respective self-diagnoses have at least one OK result. \rightarrow Case 2 above

EC

Α

Е

D

F

N

^{-:} Self-diagnosis is not carried out.

[VQ25DE, VQ35DE]

If one or more SRT related self-diagnoses show NG results in 2 consecutive cycles, the SRT will also indicate "CMPLT". \rightarrow Case 3 above

The table above shows that the minimum number of cycles for setting SRT as "INCMP" is the number one (1) for each self-diagnosis (Case 1 & 2) or the number two (2) for one of self-diagnoses (Case 3). However, in preparation for the state emissions inspection, it is unnecessary for each self-diagnosis to be executed twice (Case 3) for the following reasons:


- The SRT will indicate "CMPLT" at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires "CMPLT" of the SRT only with OK self-diagnosis results.
- During SRT driving pattern, the 1st trip DTC (NG) is detected prior to "CMPLT" of SRT and the self-diagnosis memory must be erased from the ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate "INCMP".

SRT can be set as "CMPLT" together with the DTC(s). Therefore, DTC check must always be carried out prior to the state emission inspection even though the SRT indicates "CMPLT".

SRT Service Procedure

< FUNCTION DIAGNOSIS >

If a vehicle has failed the state emissions inspection due to one or more SRT items indicating "INCMP", review the flowchart diagnostic sequence on the next figure.



[&]quot;How to Read DTC and 1st Trip DTC" *2 "How to Display SRT Status"

ON BOARD DIAGNOSTIC (OBD) SYSTEM

< FUNCTION DIAGNOSIS >

How to Display SRT Status

(P)WITH CONSULT-III

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-III.

For items whose SRT codes are set, "CMPLT" is displayed on the CONSULT-III screen; for items whose SRT codes are not set, "INCMP" is displayed.

NOTE:

Though displayed on the CONSULT-III screen, "HO2S HTR" is not SRT item.

WITH GST


Selecting Service \$01 with GST (Generic Scan Tool)

MALFUNCTION INDICATOR (MI)

Description

The MI is located on the instrument panel.

- 1. The MI will illuminate when the ignition switch is turned ON without the engine running. This is a bulb check. If the MI does not illuminate, check MI circuit. Refer to EC-346. "Component Function Check".
- When the engine is started, the MI should go off. If the MI remains on, the on board diagnostic system has detected an engine system malfunction.



On Board Diagnostic System Function

The on board diagnostic system has the following three functions.

Diagnostic Test KEY and ENG. Fun Mode Status		Function	Explanation of Function				
Mode I	Ignition switch in ON position Engine stopped	BULB CHECK	This function checks the MI bulb for damage (blown, oper circuit, etc.). If the MI does not come on, check MI circuit.				
	Engine running	MALFUNCTION WARNING	When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MI will illuminat to inform the driver that a malfunction has been detected. The following malfunctions will illuminate or blink the MI is the 1st trip. • Misfire (Possible three way catalyst damage) • One trip detection diagnoses				
Mode II	Ignition switch in ON position	SELF-DIAGNOSTIC RESULTS	This function allows DTCs and 1st trip DTCs to be read.				
	Engine stopped						

Diagnostic Test Mode I — Bulb Check

In this mode, the MI on the instrument panel should stay ON. If it remains OFF, check MI circuit. Refer to EC-346, "Component Function Check".

Diagnostic Test Mode I — Malfunction Warning

EC

Α

[VQ25DE, VQ35DE]

Е

D

Н


MI	Condition					
ON	When the malfunction is detected.					
OFF	No malfunction.					

This DTC number is clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)

Diagnostic Test Mode II — Self-diagnostic Results

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MI as shown below.

The DTC and 1st trip DTC are displayed at the same time. If the MI does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MI illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT-III or GST. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes as per the following.

Number	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
Flashes	10	1	2	3	4	5	6	7	8	9	11	12	13	14	15	16

The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-seconds) - OFF (0.6-seconds) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-seconds ON and 0.3-seconds OFF cycle. A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-seconds OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC 0000 refers to no malfunction. (See EC-389, "DTC Index")

How to Switch Diagnostic Test Mode

NOTE:

It is better to count the time accurately with a clock.

< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]

- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- ECM always returns to Diagnostic Test Mode I after the ignition switch is turned OFF.

HOW TO SET DIAGNOSTIC TEST MODE II (SELF-DIAGNOSTIC RESULTS)

- 1. Confirm that accelerator pedal is fully released, turn ignition switch ON and wait 3 seconds.
- 2. Repeat the following procedure quickly 5 times within 5 seconds.
- Fully depress the accelerator pedal.
- Fully release the accelerator pedal.
- Wait 7 seconds, fully depress the accelerator pedal and keep it depressed for approx. 10 seconds until the MI starts blinking.

NOTE:


Do not release the accelerator pedal for 10 seconds if MI starts blinking during this period. This blinking is displaying SRT status and is continued for another 10 seconds.

4. Fully release the accelerator pedal.

ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).

NOTE:

Wait until the same DTC (or 1st trip DTC) appears to completely confirm all DTCs.



HOW TO ERASE DIAGNOSTIC TEST MODE II (SELF-DIAGNOSTIC RESULTS)

- Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to "How to Set Diagnostic Test Mode II (Self-diagnostic Results)".
- Fully depress the accelerator pedal and keep it depressed for more than 10 seconds.The emission-related diagnostic information has been erased from the backup memory in the ECM.
- Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.
- If the battery is disconnected, the DTC will be lost from the backup memory within 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

OBD System Operation Chart

Relationship Between MI, 1st Trip DTC, DTC, and Detectable Items

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MI will come on.
- The MI will go off after the vehicle is driven 3 times (driving pattern B) with no malfunction. A drive is counted
 only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while
 counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The "TIME" in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT-III will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in OK for the 2nd trip.

Summary Chart

Items	Fuel Injection System	Misfire	Other
MI (turns off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)

EC

Α

D

Е

Н

.1

K

M

V

O

P

< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]


Items	Fuel Injection System	Misfire	Other
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)

For details about patterns B and C under "Fuel Injection System" and "Misfire", see "EXPLANATION FOR DRIVING PATTERNS FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM".

For details about patterns A and B under Other, see "EXPLANATION FOR DRIVING PATTERNS FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM".

- *1: Clear timing is at the moment OK is detected.
- *2: Clear timing is when the same malfunction is detected in the 2nd trip.

Relationship Between MI, DTC, 1st Trip DTC and Driving Patterns for "Misfire <Exhaust Quality Deterioration>", "Fuel Injection System"



*1: When the same malfunction is detected in two consecutive trips, MI will illuminate.

< FUNCTION DIAGNOSIS >

- times (pattern B) without any malfunctions.
- *2: MI will turn off after vehicle is driven 3 *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be

[VQ25DE, VQ35DE]

Α

EC

D

Е

F

Н

- stored in ECM. *6: The 1st trip DTC and the 1st trip *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be
- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

freeze frame data will be cleared at the moment OK is detected.

- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.
- *8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

Explanation for Driving Patterns for "Misfire < Exhaust Quality Deterioration>", "Fuel Injection System" <Driving Pattern B>

stored in ECM.

Driving pattern B means the vehicle operation as per the following:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MI will turn off when the B counter reaches 3. (*2 in "OBD SYSTEM OPERATION CHART")

<Driving Pattern C>

Driving pattern C means operating vehicle as per the following:

The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ±375 rpm

Calculated load value: (Calculated load value in the freeze frame data) x (1±0.1) [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), T should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), T should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as per the following:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)


- The C counter will be cleared when the malfunction is detected regardless of vehicle conditions above.
- The C counter will be counted up when vehicle conditions above are satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

Relationship Between MI, DTC, 1st Trip DTC and Driving Patterns Except For "Misfire <Exhaust Quality Deterioration>", "Fuel Injection System"

Ν

K

Р



- *1: When the same malfunction is detected in two consecutive trips, MI will illuminate.
- times (pattern B) without any malfunctions.
- *2: MI will turn off after vehicle is driven 3 *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

< FUNCTION DIAGNOSIS >

- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- *6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.

[VQ25DE, VQ35DE]


_ .

Α

EC

*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

Explanation for Driving Patterns Except for "Misfire < Exhaust Quality Deterioration>", "Fuel Injection System" < Driving Pattern A>



- The A counter will be cleared when the malfunction is detected regardless of (1) (4).
- The A counter will be counted up when (1) (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

<Driving Pattern B>

Driving pattern B means operating vehicle as per the following:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MI will go off when the B counter reaches 3 (*2 in OBD SYSTEM OPERATION CHART).

CONSULT-III Function

INFOID:0000000003856503

FUNCTION

Diagnostic test mode	Function
Work Support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-III unit.
Self-Diagnostic Result	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*
Data Monitor	Input/Output data in the ECM can be read.
Active Test	Diagnostic Test Mode in which CONSULT-III drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
DTC & SRT Confirmation	The status of system monitoring tests and the self-diagnosis status/results can be confirmed.
Function Test	This mode is used to inform customers when their vehicle requires periodic maintenance.
ECU Part Number	ECM part number can be read.

- *: The following emission-related diagnostic information is cleared when the ECM memory is erased.
- · Diagnostic trouble codes
- · 1st trip diagnostic trouble codes
- · Freeze frame data

EC-113

Е

D

Н

K

Ν

0

Р

< FUNCTION DIAGNOSIS >

- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

			DIAGNOSTIC TEST MODE							
	ltem				AGNOSTIC SULTS	DATA		DTC & SRT CONFIRMATION		
			WORK SUPPORT	DTC*1	FREEZE FRAME DATA* ²	MONI- TOR	ACTIVE TEST	SRT STA- TUS	DTC WORK SUP- PORT	
		Crankshaft position sensor (POS)		×	×	×				
		Camshaft position sensor (PHASE)		×	×	×				
		Mass air flow sensor		×		×				
		Engine coolant temperature sensor		×	×	×	×			
		Engine oil temperature sensor				×				
		Air fuel ratio (A/F) sensor 1		×		×		×	×	
		Heated oxygen sensor 2		×		×		×	×	
RTS		Vehicle speed signal		×	×	×				
M		Accelerator pedal position sensor		×		×				
Ä		Throttle position sensor		×	×	×				
NO		Intake air temperature sensor			×	×				
MP	Ţ	Knock sensor		×						
ŭ	INPUT	Refrigerant pressure sensor				×				
ENGINE CONTROL COMPONENT PARTS	_	Closed throttle position switch (accelerator pedal position sensor signal)				×				
8		Air conditioner switch				×				
Ä		Park/neutral position (PNP) signal		×		×				
EN		Stop lamp switch		×		×				
		Power steering pressure sensor		×		×				
		Battery voltage				×				
		Load signal				×				
		Primary speed sensor		×		×				
		Battery current sensor		×		×				
		ASCD steering switch		×		×				
		ASCD brake switch		×		×				

[VQ25DE, VQ35DE]

Α

EC

D

Е

		DIAGNOSTIC TEST MODE						
			_	SELF-DIAGNOSTIC RESULTS			DTC & SRT CONFIRMATION	
ltem		WORK SUPPORT	DTC*1	FREEZE FRAME DATA* ²	DATA MONI- TOR	ACTIVE TEST	SRT STA- TUS	DTC WORK SUP- PORT
	Fuel injector				×	×		
	Power transistor (Ignition timing)				×	×		
	Throttle control motor relay		×		×			
တ	Throttle control motor		×					
PAR	EVAP canister purge volume control solenoid valve		×		×	×		×
	Air conditioner relay				×			
S	Fuel pump relay	×			×	×		
<u> </u>	Cooling fan relay		×		×	×		
OL COM	Air fuel ratio (A/F) sensor 1 heater		×		×		×* ³	
Z Z	Heated oxygen sensor 2 heater		×		×		×* ³	
ENGINE CONTROL COMPONENT PARTS OUTPUT	Intake valve timing control solenoid valve		×		×	×		
	VIAS control solenoid valve 1		×		×	×		
ū	VIAS control solenoid valve 2		×		×	×		
	Electronic controlled engine mount				×	×		
	Alternator				×	×		
	Calculated load value			×	×			

X: Applicable

WORK SUPPORT MODE

Work Item

WORK ITEM	CONDITION	USAGE
FUEL PRESSURE RELEASE	FUEL PUMP WILL STOP BY TOUCHING "START" DUR- ING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS.	When releasing fuel pressure from fuel line
IDLE AIR VOL LEARN	THE IDLE AIR VOLUME THAT KEEPS THE ENGINE WITHIN THE SPECIFIED RANGE IS MEMORIZED IN ECM.	When learning the idle air volume
SELF-LEARNING CONT	THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEF- FICIENT.	When clearing mixture ratio self- learning value
TARGET IDLE RPM ADJ*	IDLE CONDITION	When setting target idle speed
TARGET IGN TIM ADJ*	IDLE CONDITION	When adjusting target ignition timing

^{*:} This function is not necessary in the usual service procedure.

SELF-DIAG RESULTS MODE

Self Diagnostic Item

Regarding items of DTC and 1st trip DTC, refer to EC-389, "DTC Index".

^{*1:} This item includes 1st trip DTCs.

^{*2:} This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-III screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to EC-102, "Diagnosis Description".

^{*3:} Always "CMPLT" is displayed.

Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item*	Description
DIAG TROUBLE CODE [PXXXX]	The engine control component part/control system has a trouble code that is displayed as PXXXX. (Refer to EC-389, "DTC Index".)
FUEL SYS-B1	"Fuel injection system status" at the moment a malfunction is detected is displayed.
FUEL SYS-B2	One of in the following mode is displayed. Mode2: Open loop due to detected system malfunction Mode3: Open loop due to driving conditions (power enrichment, deceleration enleanment) Mode4: Closed loop - using oxygen sensor(s) as feedback for fuel control Mode5: Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	The engine coolant temperature at the moment a malfunction is detected is displayed.
L-FUEL TRM-B1 [%]	"Long-term fuel trim" at the moment a malfunction is detected is displayed.
L-FUEL TRM-B2 [%]	The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
S-FUEL TRM-B1 [%]	"Short-term fuel trim" at the moment a malfunction is detected is displayed.
S-FUEL TRM-B2 [%]	 The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
ENGINE SPEED [rpm]	The engine speed at the moment a malfunction is detected is displayed.
VEHICL SPEED [km/h] or [mph]	The vehicle speed at the moment a malfunction is detected is displayed.
ABSOL TH.P/S [%]	The throttle valve opening angle at the moment a malfunction is detected is displayed.
B/FUEL SCHDL [msec]	The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	The intake air temperature at the moment a malfunction is detected is displayed.
INT MANI PRES [kPa]	These items are displayed but are not applicable to this model.
COMBUST CONDITION	- These items are displayed but are not applicable to this model.

^{*:} The items are the same as those of 1st trip freeze frame data.

DATA MONITOR MODE

Monitored Item

×: Applicable

			×: Applicable
Monitored item	Unit	Description	Remarks
ENG SPEED	rpm	Indicates the engine speed computed from the signal of the crankshaft position sensor (POS) and camshaft position sensor (PHASE).	 Accuracy becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS A/F SE-B1	V	The signal voltage of the mass air flow sensor is displayed.	 When the engine is stopped, a certain value is indicated. When engine is running, specification range is indicated in "SPEC".
B/FUEL SCHDL	msec	"Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction.	When engine is running, specification range is indicated in "SPEC".
A/F ALPHA-B1			When the engine is stopped, a certain
A/F ALPHA-B2	%	The mean value of the air-fuel ratio feedback cor- rection factor per cycle is indicated.	 value is indicated. This data also includes the data for the air-fuel ratio learning control. When engine is running, specification range is indicated in "SPEC".

< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]

Monitored item	Unit	Description	Remarks
COOLAN TEMP/S	°C or °F	The engine coolant temperature (determined by the signal voltage of the engine coolant tempera- ture sensor) is displayed.	When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The en- gine coolant temperature determined by the ECM is displayed.
A/F SEN1 (B1)	V	The A/F signal computed from the input signal of	
A/F SEN1 (B2)	V	the air fuel ratio (A/F) sensor 1 is displayed.	
HO2S2 (B1)	V	The signal voltage of the heated oxygen sensor 2	
HO2S2 (B2)	V	is displayed.	
HO2S2 MNTR(B1) HO2S2 MNTR(B2)	RICH/LEAN	Display of heated oxygen sensor 2 signal: RICH: means the amount of oxygen after three way catalyst is relatively small. LEAN: means the amount of oxygen after three way catalyst is relatively large.	When the engine is stopped, a certain value is indicated.
VHCL SPEED SE	km/h or mph	The vehicle speed computed from the vehicle speed signal sent from combination meter is dis- played.	
BATTERY VOLT	V	The power supply voltage of ECM is displayed.	
ACCEL SEN 1 ACCEL SEN 2	V	The accelerator pedal position sensor signal voltage is displayed.	ACCEL SEN 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.
TP SEN 1-B1			TP SEN 2-B1 signal is converted by
TP SEN 2-B1	V	The throttle position sensor signal voltage is displayed.	ECM internally. Thus, it differs from ECM terminal voltage signal.
INT/A TEMP SE	°C or °F	The intake air temperature (determined by the signal voltage of the intake air temperature sensor) is indicated.	
START SIGNAL	ON/OFF	Indicates start signal status [ON/OFF] computed by the ECM according to the signals of engine speed and battery voltage.	 After starting the engine, [OFF] is dis- played regardless of the starter sig- nal.
CLSD THL POS	ON/OFF	Indicates idle position [ON/OFF] computed by ECM according to the accelerator pedal position sensor signal.	
AIR COND SIG	ON/OFF	Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.	
P/N POSI SW	ON/OFF	Indicates [ON/OFF] condition from the park/neu- tral position (PNP) signal.	
PW/ST SIGNAL	ON/OFF	[ON/OFF] condition of the power steering system (determined by the signal voltage of the power steering pressure sensor) is indicated.	
LOAD SIGNAL	ON/OFF	Indicates [ON/OFF] condition from the electrical load signal. ON: Rear window defogger switch is ON and/or lighting switch is in 2nd position. OFF: Both rear window defogger switch and lighting switch are OFF.	
IGNITION SW	ON/OFF	Indicates [ON/OFF] condition from ignition switch signal.	
HEATER FAN SW	ON/OFF	Indicates [ON/OFF] condition from the heater fan switch signal.	
BRAKE SW	ON/OFF	Indicates [ON/OFF] condition from the stop lamp switch signal.	
INJ PULSE-B1 INJ PULSE-B2	msec	Indicates the actual fuel injection pulse width compensated by ECM according to the input signals.	When the engine is stopped, a certain computed value is indicated.

EC-117

Monitored item	Unit	Description	Remarks
IGN TIMING	BTDC	Indicates the ignition timing computed by ECM according to the input signals.	When the engine is stopped, a certain value is indicated.
CAL/LD VALUE	%	"Calculated load value" indicates the value of the current air flow divided by peak air flow.	
MASS AIRFLOW	g·m/s	Indicates the mass air flow computed by ECM according to the signal voltage of the mass air flow sensor.	
PURG VOL C/V	%	 Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. The opening becomes larger as the value increases. 	
INT/V TIM (B1)	°CA	Indicates [°CA] of intake camshaft advance an-	
INT/V TIM (B2)	- CA	gle.	
INT/V SOL-B1		The control value of the intake valve timing con-	
INT/V SOL-B2	%	 trol solenoid valve (determined by ECM according to the input signals) is indicated. The advance angle becomes larger as the value increases. 	
VIAS S/V-1	ON/OFF	The control condition of the VIAS control solenoid valve 1 (determined by ECM according to the in- put signals) is indicated. ON: VIAS control solenoid valve 1 is operating. OFF: VIAS control solenoid valve 1 is not operat- ing.	
VIAS S/V-2	ON/OFF	The control condition of the VIAS control solenoid valve 2 (determined by ECM according to the in- put signals) is indicated. ON: VIAS control solenoid valve 2 is operating. OFF: VIAS control solenoid valve 2 is not operat- ing.	
AIR COND RLY	ON/OFF	The air conditioner relay control condition (determined by ECM according to the input signals) is indicated.	
ENGINE MOUNT	IDLE/TRVL	The control condition of the electronic controlled engine mount (determined by ECM according to the input signals) is indicated. IDLE: Engine speed is below 950 rpm TRVL: Engine speed is above 950 rpm	
FUEL PUMP RLY	ON/OFF	 Indicates the fuel pump relay control condition determined by ECM according to the input sig- nals. 	
VENT CONT/V*	ON/OFF	The control condition of the EVAP canister vent control valve (determined by ECM according to the input signals) is indicated. ON: Closed OFF: Open	
THRTL RELAY	ON/OFF	Indicates the throttle control motor relay control condition determined by the ECM according to the input signals.	
COOLING FAN	HI/MID/LOW/ OFF	The control condition of the cooling fan (determined by ECM according to the input signals) is indicated. HI: High speed operation MID: Middle speed operation LOW: Low speed operation OFF: Stop	

< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]

Monitored item	Unit	Description	Remarks
HO2S2 HTR (B1)	ON/OFF	Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to	
HO2S2 HTR (B2) I/P PULLY SPD	rpm	the input signals. Indicates the engine speed computed from the	
VELUCI E ODEED	·	turbine revolution sensor signal. The vehicle speed computed from the vehicle	
VEHICLE SPEED	km/h or mph	speed signal sent from TCM is displayed.	
IDL A/V LEARN	YET/CMPLT	Displays the condition of idle air volume learning YET: Idle Air Volume Learning has not been performed yet. CMPLT: Idle Air Volume Learning has already been performed successfully.	
ENG OIL TEMP	°C or °F	The engine oil temperature (determined by the signal voltage of the engine oil temperature sen- sor) is displayed.	
TRVL AFTER MIL	km or mile	Distance traveled while MI is activated.	
A/F S1 HTR(B1)		Air fuel ratio (A/F) sensor 1 heater control value	
A/F S1 HTR(B2)	%	 computed by ECM according to the input signals. The current flow to the heater becomes larger as the value increases. 	
AC PRESS SEN	V	The signal voltage from the refrigerant pressure sensor is displayed.	
VHCL SPEED SE	km/h or mph	The vehicle speed computed from the vehicle speed signal sent from combination meter is displayed.	
SET VHCL SPD	km/h or mph	The preset vehicle speed is displayed.	
MAIN SW	ON/OFF	Indicates [ON/OFF] condition from MAIN switch signal.	
CANCEL SW	ON/OFF	Indicates [ON/OFF] condition from CANCEL switch signal.	
RESUME/ACC SW	ON/OFF	Indicates [ON/OFF] condition from RESUME/AC- CELERATE switch signal.	
SET SW	ON/OFF	Indicates [ON/OFF] condition from SET/COAST switch signal.	
BRAKE SW1	ON/OFF	Indicates [ON/OFF] condition from ASCD brake switch signal or ASCD clutch switch.	
BRAKE SW2	ON/OFF	Indicates [ON/OFF] condition of stop lamp switch signal.	
VHCL SPD CUT	NON/CUT	Indicates the vehicle cruise condition. NON: Vehicle speed is maintained at the ASCD set speed. CUT: Vehicle speed decreased to excessively low compared with the ASCD set speed, and ASCD operation is cut off.	
LO SPEED CUT	NON/CUT	Indicates the vehicle cruise condition. NON: Vehicle speed is maintained at the ASCD set speed. CUT: Vehicle speed decreased to excessively low, and ASCD operation is cut off.	
AT OD MONITOR	ON/OFF	Indicates [ON/OFF] condition of CVT O/D according to the input signal from the TCM.	
AT OD CANCEL	ON/OFF	Indicates [ON/OFF] condition of CVT O/D cancel request signal.	
CRUISE LAMP	ON/OFF	Indicates [ON/OFF] condition of CRUISE lamp determined by the ECM according to the input signals.	

[VQ25DE, VQ35DE]

Monitored item	Unit	Description	Remarks
SET LAMP	ON/OFF	Indicates [ON/OFF] condition of SET lamp determined by the ECM according to the input signals.	
BAT CUR SEN	mV	The signal voltage of battery current sensor is displayed.	
ALT DUTY SIG	ON/OFF	The control condition of the power generation voltage variable control (determined by ECM according to the input signals) is indicated. ON: Power generation voltage variable control is active. OFF: Power generation voltage variable control is inactive.	
A/F ADJ-B1		Indicates the correction of factor stored in ECM.	
A/F ADJ-B2	_	The factor is calculated from the difference be- tween the target air-fuel ratio stored in ECM and the air-fuel ratio calculated from A/F sensor 1 sig- nal.	
ALT DUTY	%	Indicates the duty ratio of the power generation command value. The ratio is calculated by ECM based on the battery current sensor signal.	

^{*:} This item is not used on this vehicle.

NOTE

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ACTIVE TEST MODE

Test Item

TEST ITEM	CONDITION	JUDGMENT	CHECK ITEM (REMEDY)
FUEL INJEC- TION	Engine: Return to the original non-standard condition Change the amount of fuel injection using CONSULT-III.	If malfunctioning symptom disappears, see CHECK ITEM.	Harness and connectors Fuel injector Air fuel ratio (A/F) sensor 1
IGNITION TIM- ING	Engine: Return to the original non-standard condition Timing light: Set Retard the ignition timing using CONSULT-III.	If malfunctioning symptom disappears, see CHECK ITEM.	Perform Idle Air Volume Learning.
POWER BAL- ANCE	 Engine: After warming up, idle the engine. A/C switch OFF Selector lever: P or N Cut off each injector signal one at a time using CONSULT-III. 	Engine runs rough or dies.	 Harness and connectors Compression Fuel injector Power transistor Spark plug Ignition coil
COOLING FAN*1	Ignition switch: ON Turn the cooling fan "HI", "MID", "LOW" and "OFF" using CON- SULT-III.	Cooling fan moves and stops.	Harness and connectors Cooling fan motor IPDM E/R
ENG COOLANT TEMP	Engine: Return to the original non-standard condition Change the engine coolant temperature using CONSULT-III.	If malfunctioning symptom disappears, see CHECK ITEM.	Harness and connectors Engine coolant temperature sensor Fuel injector
FUEL PUMP RE- LAY	Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT-III and listen to operating sound.	Fuel pump relay makes the operating sound.	Harness and connectors Fuel pump relay

< FUNCTION DIAGNOSIS >

[VQ25DE, VQ35DE]

TEST ITEM	CONDITION	JUDGMENT	CHECK ITEM (REMEDY)	۸
VIAS S/V-1	Ignition switch: ON Turn solenoid valve "ON" and "OFF" using CONSULT-III and listen to operating sound.	Solenoid valve makes the operating sound.	Harness and connectors Solenoid valve	EC
VIAS S/V-2	Ignition switch: ON Turn solenoid valve "ON" and "OFF" using CONSULT-III and listen to operating sound.	Solenoid valve makes the operating sound.	Harness and connectors Solenoid valve	С
ENGINE MOUNTING	Ignition switch: ON Turn electronic controlled engine mount "IDLE" and "TRVL" with CONSULT-III.	Electronic controlled engine mount makes the operating sound.	Harness and connectors Electronic controlled engine mount	D
PURG VOL CONT/V	Engine: After warming up, run engine at 1,500 rpm. Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-III.	Engine speed changes according to the opening percent.	Harness and connectors Solenoid valve	E
VENT CON- TROL/V* ²	Ignition switch: ON (Engine stopped) Turn solenoid valve "ON" and "OFF" with the CONSULT-III and listen to operating sound.	Solenoid valve makes an operating sound.	Harness and connectors Solenoid valve	G
V/T ASSIGN AN- GLE	Engine: Return to the original trouble condition Change intake valve timing using CONSULT-III.	If trouble symptom disappears, see CHECK ITEM.	Harness and connectors Intake valve timing control solenoid valve	H
ALTERNATOR DUTY	Engine: Idle Change duty ratio using CON- SULT-III.	Battery voltage changes.	Harness and connectors IPDM E/R Alternator	

^{*1:} Leaving cooling fan OFF with CONSULT-III while engine is running may cause the engine to overheat.

DTC & SRT CONFIRMATION MODE

SRT STATUS Mode

For details, refer to EC-102, "Diagnosis Description".

SRT WORK SUPPORT Mode

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

DTC WORK SUPPORT Mode

Test mode	Test item	Corresponding DTC No.	Reference page
	A/F SEN1(B1) P1278/P1279	P0133	EC-173
A/F SEN1	A/F SEN1(B1) P1276	P0130	EC-163
A/F SEINT	A/F SEN1(B2) P1288/P1289	P0153	EC-173
	A/F SEN1(B2) P1286	P0150	EC-163
	HO2S2(B1) P1146	P0138	EC-184
	HO2S2(B1) P1147	P0137	EC-178
HO2S2	HO2S2(B1) P0139	P0139	EC-192
HO232	HO2S2(B2) P1166	P0158	EC-184
	HO2S2(B2) P1167	P0157	EC-178
	HO2S2(B2) P0159	P0159	EC-192

Ν

^{*2:} This item is not used on this vehicle.

Diagnosis Tool Function


INFOID:0000000003856504

DESCRIPTION

Generic Scan Tool (OBD II scan tool) complying with ISO 15031-5 has 8 different functions explained below.

ISO15765-4 is used as the protocol.

The name "GST" or "Generic Scan Tool" is used in this service manual.




FUNCTION

Dia	agnostic Service	Function
Service \$01	READINESS TESTS	This diagnostic service gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
Service \$02	(FREEZE DATA)	This diagnostic service gains access to emission-related data value which were stored by ECM during the freeze frame. For details, refer to EC-389 , "DTC Index".
Service \$03	DTCs	This diagnostic service gains access to emission-related power train trouble codes which were stored by ECM.
Service \$04	CLEAR DIAG INFO	This diagnostic service can clear all emission-related diagnostic information. This includes: Clear number of diagnostic trouble codes (Service \$01) Clear diagnostic trouble codes (Service \$03) Clear trouble code for freeze frame data (Service \$01) Clear freeze frame data (Service \$02) Reset status of system monitoring test (Service \$01) Clear on board monitoring test results (Service \$06 and \$07)
Service \$06	(ON BOARD TESTS)	This diagnostic service accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
Service \$07	(ON BOARD TESTS)	This diagnostic service enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.
Service \$08	_	This diagnostic service is not applicable on this vehicle.
Service \$09	(CALIBRATION ID)	This diagnostic service enables the off-board test device to request specific vehicle information such as Vehicle Identification Number (VIN) and Calibration IDs.

INSPECTION PROCEDURE

- 1. Turn ignition switch OFF.
- 2. Connect "GST" to data link connector (1), which is located under LH dash panel.




< FUNCTION DIAGNOSIS >

Turn ignition switch ON.

4. Enter the program according to instruction on the screen or in the operation manual.


(*: Regarding GST screens in this section, sample screens are shown.)



[VQ25DE, VQ35DE]

5. Perform each diagnostic mode according to each service proce-

For further information, see the GST Operation Manual of the tool maker.



EC-123

Α

EC

D

Е

F

Н

K

L

M

Ν

0

Р

[VQ25DE, VQ35DE]

COMPONENT DIAGNOSIS

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

Description

The specification (SP) value indicates the tolerance of the value that is displayed in "SPEC" of "DATA MONITOR" mode of CONSULT-III during normal operation of the Engine Control System. When the value in "SPEC" in "DATA MONITOR" mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not illuminate the MI.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Component Function Check

INFOID:0000000003856506

1.START

Check that all of the following conditions are satisfied.

- Vehicle driven distance: More than 5,000 km (3,107 miles)
- Barometric pressure: 98.3 104.3 kPa (0.983 1.043 bar, 1.003 1.064 kg/cm², 14.25 15.12 psi)
- Atmospheric temperature: 20 30°C (68 86°F)
- Engine coolant temperature: 75 95°C (167 203°F)
- Transmission: Warmed-up
- After the engine is warmed up to normal operating temperature, drive vehicle until "FLUID TEMP SE" (CVT fluid temperature sensor signal) indicates more than 60°C (140°F).
- Electrical load: Not applied
- Rear window defogger switch, air conditioner switch, lighting switch are OFF. Steering wheel is straight ahead.
- Engine speed: Idle

>> GO TO 2.

2.PERFORM "SPEC" OF "DATA MONITOR" MODE

With CONSULT-III

NOTE:

Perform "SPEC" in "DATA MONITOR" mode in maximum scale display.

- 1. Perform "EC-11, "BASIC INSPECTION: Special Repair Requirement".
- Select "B/FUEL SCHDL", "A/F ALPHA-B1", "A/F ALPHA-B2" and "MAS A/F SE-B1" in "SPEC" of "DATA MONITOR" mode with CONSULT-III.
- 3. Check that monitor items are within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END


NO >> Go to EC-125, "Diagnosis Procedure".


Diagnosis Procedure

INFOID:0000000003856507

Α

OVERALL SEQUENCE





DETAILED PROCEDURE

1.CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

(E)With CONSULT-III

- Start engine.
- Confirm that the testing conditions are met. Refer to <u>EC-124, "Component Function Check"</u>.
- Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "SPEC" of "DATA MONITOR" mode, and check that the each indication is within the SP value.

[VQ25DE, VQ35DE] < COMPONENT DIAGNOSIS > NOTE: Check "A/F ALPHA-B1", "A/F ALPHA-B2" for approximately 1 minute because they may fluctuate. It is NG if the indication is out of the SP value even a little. Is the measurement value within the SP value? >> GO TO 17. YES EC NO-1 >> Less than the SP value: GO TO 2. NO-2 >> More than the SP value: GO TO 3. 2.CHECK "B/FUEL SCHDL" Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and check that the indication is within the SP value. D Is the measurement value within the SP value? YES >> GO TO 4. NO >> More than the SP value: GO TO 19. Е 3.CHECK "B/FUEL SCHDL" Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and check that the indication is within the SP value. F Is the measurement value within the SP value? YES >> GO TO 6. NO-1 >> More than the SP value: GO TO 6. NO-2 >> Less than the SP value: GO TO 25. 4.CHECK "A/F ALPHA-B1", "A/F ALPHA-B2" Stop the engine. Disconnect PCV hose, and then plug it. 2. Start engine. Select "A/F ALPHA-B1". "A/F ALPHA-B2" in "SPEC" of "DATA MONITOR" mode, and check that the each indication is within the SP value. Is the measurement value within the SP value? YES >> GO TO 5. NO >> GO TO 6. 5. CHANGE ENGINE OIL Stop the engine. Change engine oil. NOTE: This symptom may occur when a large amount of gasoline is mixed with engine oil because of driving conditions (such as when engine oil temperature does not rise enough since a journey distance is too short during winter). The symptom will not be detected after changing engine oil or changing driving conditions. M >> INSPECTION END $\mathbf{6}.$ CHECK FUEL PRESSURE Ν Check fuel pressure. (Refer to EC-411, "Inspection".) Is the inspection result normal? YES >> GO TO 9. NO-1 >> Fuel pressure is too high: Replace "fuel filter and fuel pump assembly" and then. GO TO 8. NO-2 >> Fuel pressure is too low: GO TO 7. Р .DETECT MALFUNCTIONING PART Check fuel hoses and fuel tubes for clogging. Is the inspection result normal?

>> Replace "fuel filter and fuel pump assembly" and then GO TO 8.

>> Repair or replace malfunctioning part and then GO TO 8.

8.CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

YES

NO

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

- Start engine.
- Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "SPEC" of "DATA MONITOR" mode, and check that the each indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> GO TO 9.

9.PERFORM POWER BALANCE TEST

- Perform "POWER BALANCE" in "ACTIVE TEST" mode.
- Check that the each cylinder produces a momentary engine speed drop.

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 10.

10. DETECT MALFUNCTIONING PART

Check the following below.

- Ignition coil and its circuit (Refer to <u>EC-341, "Component Function Check"</u>.)
- Fuel injector and its circuit (Refer to EC-334, "Component Function Check".)
- Intake air leakage
- Low compression pressure (Refer to EM-22, "Inspection".)

Is the inspection result normal?

YES >> Replace fuel injector and then GO TO 11.

>> Repair or replace malfunctioning part and then GO TO 11. NO

11.CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

- Start engine.
- Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "SPEC" of "DATA MONITOR" mode, and check that the each indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> GO TO 12.

12.CHECK A/F SENSOR 1 FUNCTION

Perform all DTC CONFIRMATION PROCEDURE related with A/F sensor 1.

- For DTC P0130, P0150, refer to <u>EC-163. "DTC Logic"</u>.
 For DTC P0131, P0151, refer to <u>EC-167, "DTC Logic"</u>.
- For DTC P0132, P0152, refer to <u>EC-170, "DTC Logic"</u>.
- For DTC P0133, P0153, refer to EC-173, "DTC Logic".
- For DTC P2A00, P2A03, refer to <u>EC-318, "DTC Logic"</u>.

Are any DTCs detected?

YES >> GO TO 15.

>> GO TO 13. NO

13. CHECK A/F SENSOR 1 CIRCUIT

Perform Diagnostic Procedure according to corresponding DTC.

>> GO TO 14.

14.CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

- 1. Start engine.
- Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "SPEC" of "DATA MONITOR" mode, and check that each indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

>> GO TO 15. NO

15. DISCONNECT AND RECONNECT ECM HARNESS CONNECTOR

Stop the engine.

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Disconnect ECM harness connector. Check pin terminal and connector for damage, and then reconnect it. Α >> GO TO 16. $16. {\sf CHECK} \text{ "A/F ALPHA-B1"}, \text{ "A/F ALPHA-B2"}$ EC Start engine. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "SPEC" of "DATA MONITOR" mode, and check that the each indication is within the SP value. Is the measurement value within the SP value? YES >> INSPECTION END NO >> Detect malfunctioning part according to <a>EC-400, "Symptom Table". D 17 CHECK "B/FUEL SCHDL" Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and check that the indication is within the SP Е value. Is the measurement value within the SP value? >> INSPECTION END F NO-1 >> More than the SP value: GO TO 18. NO-2 >> Less than the SP value: GO TO 25. 18.DETECT MALFUNCTIONING PART Check for the cause of large engine friction. Refer to the following. Engine oil level is too high Engine oil viscosity Н Belt tension of power steering, alternator, A/C compressor, etc. is excessive Noise from engine Noise from transmission, etc. 2. Check for the cause of insufficient combustion. Refer to the following. Valve clearance malfunction Intake valve timing control function malfunction Camshaft sprocket installation malfunction, etc. >> Repair or replace malfunctioning part, and then GO TO 30. 19. CHECK INTAKE SYSTEM K Check for the cause of uneven air flow through mass air flow sensor. Refer to the following. Crushed air ducts Malfunctioning seal of air cleaner element Uneven dirt of air cleaner element Improper specification of intake air system Is the inspection result normal? YES >> GO TO 21. NO >> Repair or replace malfunctioning part, and then GO TO 20. 20.CHECK "A/F ALPHA-B1", "A/F ALPHA-B2", AND "B/FUEL SCHDL" N Select "A/F ALPHA-B1", "A/F ALPHA-B2", and "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and check that each indication is within the SP value. Is the measurement value within the SP value? YES >> INSPECTION END NO >> "B/FUEL SCHDL" is more, "A/F ALPHA-B1", "A/F ALPHA-B2" are less than the SP value: GO TO 21. DISCONNECT AND RECONNECT MASS AIR FLOW SENSOR HARNESS CONNECTOR

- 1. Stop the engine.
- 2. Disconnect mass air flow sensor harness connector. Check pin terminal and connector for damage and then reconnect it again.

>> GO TO 22.

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

22.CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

- 1. Start engine.
- Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "SPEC" of "DATA MONITOR" mode, and check that each indication is within the SP value.

Is the measurement value within the SP value?

YES >> Detect malfunctioning part of mass air flow sensor circuit and repair it. Refer to <u>EC-150, "Diagnosis Procedure"</u>. Then GO TO 29.

NO >> GO TO 23.

23. CHECK "MAS A/F SE-B1"

Select "MAS A/F SE-B1" in "SPEC" of "DATA MONITOR" mode, and check that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> GO TO 24.

NO >> More than the SP value: Replace mass air flow sensor, and then GO TO 29.

24. REPLACE ECM

- 1. Replace ECM.
- Refer to <u>EC-14</u>, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Special Repair Requirement".

>> GO TO 29.

25. CHECK INTAKE SYSTEM

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- · Crushed air ducts
- Malfunctioning seal in air cleaner element
- · Uneven dirt in air cleaner element
- Improper specification in intake air system

Is the inspection result normal?

YES >> GO TO 27.

NO >> Repair or replace malfunctioning part, and then GO TO 26.

26.check "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and check that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> Less than the SP value: GO TO 27.

27.CHECK "MAS A/F SE-B1"

Select "MAS A/F SE-B1" in "SPEC" of "DATA MONITOR" mode, and check that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> GO TO 28.

NO >> Less than the SP value: Replace mass air flow sensor, and then GO TO 30.

28. CHECK INTAKE SYSTEM

Check for the cause of air leak after the mass air flow sensor. Refer to the following.

- · Disconnection, looseness, and cracks in air duct
- Looseness of oil filler cap
- · Disconnection of oil level gauge
- Open stuck, breakage, hose disconnection, or cracks in PCV valve
- Disconnection or cracks in EVAP purge hose, stuck open EVAP canister purge volume control solenoid valve
- Malfunctioning seal in rocker cover gasket
- Disconnection, looseness, or cracks in hoses, such as a vacuum hose, connecting to intake air system parts

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

• Malfunctioning seal in intake air system, etc.

>> GO TO 30.

 $29.\mathtt{CHECK}$ "A/F ALPHA-B1", "A/F ALPHA-B2", AND "B/FUEL SCHDL"

Select "A/F ALPHA-B1", "A/F ALPHA-B2", and "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and check that each indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> Detect malfunctioning part according to EC-400, "Symptom Table".

30. CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and then check that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> Detect malfunctioning part according to EC-400. "Symptom Table".

EC

Α

С

D

Е

F

G

Н

J

Κ

M

L

Ν

0

Р

[VQ25DE, VQ35DE]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000003856508

1. CHECK GROUND CONNECTION-I

- 1. Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I

- 1. Disconnect ECM harness connector.
- 2. Check the continuity between ECM harness connector and ground.

E	CM	- Ground	Continuity	
Connector	Terminal	Giodila	Continuity	
F7	12			
Γ/	16		Existed	
	107	Ground		
E16	108	Giouna		
E10	111			
	112			

3. Also check harness for short to power.

is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F121, E7
- · Harness for open or short between ECM and ground

>> Repair open circuit, short to power in harness or connectors.

4. CHECK ECM POWER SUPPLY CIRCUIT-I

- 1. Reconnect ECM harness connector.
- 2. Turn ignition switch OFF and then ON.
- 3. Check the voltage between ECM harness connector and ground.

E	СМ	Ground	Voltage
Connector	Connector Terminal		Voltage
E16	93	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R connector E10
- 10A fuse (No. 44)
- · Harness for open or short between ECM and fuse

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

>> Repair open circuit, short to ground or short to power in harness or connectors.

6.CHECK ECM POWER SUPPLY CIRCUIT-II

- Turn ignition switch OFF and wait at least 10 seconds.
- Check the voltage between ECM harness connector and ground.

ECM		Ground	Voltage	
Connector	Terminal	Giodila	voltage	
E16	105	Ground	After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop to approximately 0 V.	

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 9.

7.CHECK ECM POWER SUPPLY CIRCUIT-III

- Turn ignition switch ON.
- Check the voltage between IPDM E/R harness connector and ground.

IPDI	И E/R	Ground	Voltage
Connector	Terminal	Giodila	
F12	49	Ground	Battery voltage
1 12	53	Giodila	Dattery Voltage

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace IPDM E/R.

8. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

9. CHECK ECM POWER SUPPLY CIRCUIT-IV

- Turn ignition switch OFF and wait at least 10 seconds.
- Check the voltage between ECM harness connector and ground.

E	CM	Ground	Voltage
Connector	Terminal	Glound	voltage
F7	24	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 10.

10.CHECK ECM POWER SUPPLY CIRCUIT-V

- Disconnect ECM harness connector.
- 2. Disconnect IPDM E/R harness connector.
- 3. Check the continuity between ECM harness connector and IPDM E/R harness connector.

ECM		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	Continuity
F7	24	F12	69	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

EC-133

EC

Α

Е

F

K

Ν

Р

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

YES >> GO TO 11.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

11. CHECK 15A FUSE

- 1. Disconnect 15A fuse (No. 50) from IPDM E/R.
- 2. Check 15A fuse.

Is the inspection result normal?

YES >> GO TO 13.

NO >> Replace 15A fuse.

12. CHECK ECM POWER SUPPLY CIRCUIT-VI

- 1. Disconnect ECM harness connector.
- 2. Disconnect IPDM E/R harness connector.
- 3. Check the continuity between ECM harness connector and IPDM E/R harness connector.

E	CM	IPDN	/I E/R	Continuity
Connector	Terminal	Connector	Terminal	Continuity
E16	105	E10	10	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 13.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

13. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace harness or connectors.

U1000, U1001 CAN COMM CIRCUIT

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Α

EC

D

Е

Н

Ν

Р

U1000, U1001 CAN COMM CIRCUIT

Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000	CAN communication	When ECM is not transmitting or receiving CAN communication signal of OBD (emission related diagnosis) for 2 seconds or more.	Harness or connectors (CAN communication line is open or
U1001	line	When ECM is not transmitting or receiving CAN communication signal other than OBD (emission related diagnosis) for 2 seconds or more.	shorted)

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Turn ignition switch ON and wait at least 3 seconds.
- 2. Check DTC.

Is DTC detected?

YES >> EC-135. "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

Go to LAN-14, "Trouble Diagnosis Flow Chart".

INFOID:0000000003856511

P0011, P0021 IVT CONTROL

DTC Logic

DTC DETECTION LOGIC

NOTE:

If DTC P0011 or P0021 is displayed with DTC P0075, P0081, first perform the trouble diagnosis for DTC P0075, P0081. Refer to EC-146, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0011	Intake valve timing control performance (bank 1)		 Crankshaft position sensor (POS) Camshaft position sensor (PHASE) Intake valve timing control solenoid valve
P0021	Intake valve timing control performance (bank 2)	There is a gap between angle of target and phase-control angle degree.	 Accumulation of debris to the signal pick-up portion of the camshaft Timing chain installation Foreign matter caught in the oil groove for intake valve timing control

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10 V and 16 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE-I

(II) With CONSULT-III

- 1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-III.
- 2. Start engine and warm it up to the normal operating temperature.
- 3. Maintain the following conditions for at least 6 consecutive seconds. Hold the accelerator pedal as steady as possible.

VHCL SPEED SE	100 - 120 km/h (63 - 75 mph)
ENG SPEED	1,200 - 2,000 rpm
COOLAN TEMP/S	More than 60°C (140°F)
B/FUEL SCHDL	More than 7.3 msec
Selector lever	D position

CAUTION:

Always drive at a safe speed.

- 4. Stop vehicle with engine running and let engine idle for 10 seconds.
- 5. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT-III" above.

Is 1st trip DTC detected?

YES >> Go to EC-137, "Diagnosis Procedure"

NO >> GO TO 3.

3.PERFORM DTC CONFIRMATION PROCEDURE-II

(P)With CONSULT-III

1. Maintain the following conditions for at least 20 consecutive seconds.

ENG SPEED	1,200 - 3,175 rpm (A constant rotation is maintained.)	А
COOLAN TEMP/S	More than 70°C (158°F)	
Selector lever	1st or 2nd position	
Driving location uphill	Driving vehicle uphill (Increased engine load will help maintain the driving conditions required for this test.)	EC
CAUTION: Always drive at a Check 1st trip DTC		D
	With CONSULT-III" above.	
•	137, "Diagnosis Procedure"	Е
Diagnosis Proced		F
1.CHECK OIL PRESS	SURE WARNING LAMP	
 Start engine. Check oil pressur nated. 	re warning lamp and confirm it is not illumi-	G
Is oil pressure warming YES >> Go to LU-7 NO >> GO TO 2.	g lamp illuminated? 7, "Inspection".	Н
	PBIA8559J	J
2.CHECK INTAKE VA	ALVE TIMING CONTROL SOLENOID VALVE	1.7
Refer to <u>EC-138</u> , "Com Is the inspection result	•	K
'	nalfunctioning intake valve timing control solenoid valve. AFT POSITION SENSOR (POS)	L
Refer to EC-221, "Com		M
Is the inspection result YES >> GO TO 4.		N
4	T POSITION SENSOR (PHASE)	
Refer to EC-224, "Com Is the inspection result	· · · · · · · · · · · · · · · · · · ·	0

Check the following.

NO

YES >> GO TO 5.

5. CHECK CAMSHAFT (INTAKE)

>> Replace malfunctioning camshaft position sensor (PHASE).

[VQ25DE, VQ35DE]

< COMPONENT DIAGNOSIS >


- Accumulation of debris on the signal plate of camshaft rear end
- · Chipping signal plate of camshaft rear end

Is the inspection result normal?

YES >> GO TO 6.

NO

>> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



6. CHECK TIMING CHAIN INSTALLATION

Check service records for any recent repairs that may cause timing chain misaligned.

Are there any service records that may cause timing chain misaligned?

YES >> Check timing chain installation. Refer to EM-53, "Removal and Installation".

NO >> GO TO 7.

7. CHECK LUBRICATION CIRCUIT

Refer to EM-53, "Removal and Installation".

Is the inspection result normal?

YES >> GO TO 8.

NO >> Clean lubrication line.

8. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003856514

1. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE-I

- Disconnect intake valve timing control solenoid valve harness connector.
- 2. Check resistance between intake valve timing control solenoid valve terminals as per the following.

Terminals	Resistance
1 and 2	7.0 - 7.5 Ω [at 20°C (68°F)]
1 or 2 and ground	$\stackrel{\scriptstyle \sim \; \Omega}{\text{(Continuity should not exist)}}$

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace malfunctioning intake valve timing control solenoid valve.

2.CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE-II

- 1. Remove intake valve timing control solenoid valve.
- 2. Provide 12 V DC between intake valve timing control solenoid valve terminals 1 and 2, and then interrupt it. Check that the plunger moves as shown in the figure.

CAUTION:


Never apply 12 V DC continuously for 5 seconds or more. Doing so may result in damage to the coil in intake valve timing control solenoid valve.

NOTE:

Always replace O-ring when intake valve timing control solenoid valve is removed.

Is the inspection result normal?

YES >> INSPECTION END



NO >> Replace malfunctioning intake valve timing control solenoid valve.

Α

EC

С

D

Е

F

G

Н

J

Κ

L

 \mathbb{N}

Ν

0

Р

[VQ25DE, VQ35DE]

P0031, P0032, P0051, P0052 A/F SENSOR 1 HEATER

Description INFOID:000000003855515

SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM function	Actuator	
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Air fuel ratio (A/F) sensor 1	Air fuel ratio (A/F) sensor 1 heater	
Mass air flow sensor	Amount of intake air	neater control	rieatei	

The ECM performs ON/OFF duty control of the A/F sensor 1 heater corresponding to the engine operating condition to keep the temperature of A/F sensor 1 element at the specified range.

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0031	Air fuel ratio (A/F) sensor 1 heater (bank 1) control circuit low	The current amperage in the A/F sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the A/F sensor 1 heater.)	Harness or connectors (The A/F sensor 1 heater circuit is open or shorted.) A/F sensor 1 heater
P0032	Air fuel ratio (A/F) sensor 1 heater (bank 1) control circuit high	The current amperage in the A/F sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the A/F sensor 1 heater.)	 Harness or connectors (The A/F sensor 1 heater circuit is shorted.) A/F sensor 1 heater
P0051	Air fuel ratio (A/F) sensor 1 heater (bank 2) control circuit low	The current amperage in the A/F sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the A/F sensor 1 heater.)	 Harness or connectors (The A/F sensor 1 heater circuit is open or shorted.) A/F sensor 1 heater
P0052	Air fuel ratio (A/F) sensor 1 heater (bank 2) control circuit high	The current amperage in the A/F sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the A/F sensor 1 heater.)	 Harness or connectors (The A/F sensor 1 heater circuit is shorted.) A/F sensor 1 heater

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for at least 10 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-140, "Diagnosis Procedure".

NG >> INSPECTION END

Diagnosis Procedure

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- 2. Check ground connection E38. Refer to Ground Inspection in GI-35, "Intermittent Incident".

EC-140

INFOID:0000000003856517

P0031, P0032, P0051, P0052 A/F SENSOR 1 HEATER

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

- Disconnect air fuel ratio (A/F) sensor 1 harness connector.
- Turn ignition switch ON. 2.
- Check the voltage between A/F sensor 1 harness connector and ground.

DTC		A/F sensor 1	Ground	Voltage	
ыс	Bank Connector Terminal		Giodila	voltage	
P0031, P0032	1	F27	4	Ground	Battery voltage
P0051, P0052	2	F64	4	Glodila	Dattery voltage

Is the inspection result normal?

>> GO TO 4. YES

NO >> GO TO 3.

3.DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F12
- 15A fuse (No. 46)
- · Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

f 4 .CHECK A/F SENSOR 1 HEATER OUTPUT SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check harness continuity between A/F sensor 1 harness connector and ECM harness connector.

DTC		A/F sensor 1		ECM		Continuity
ыс	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0031, P0032	1	F27	3	F7	4	Existed
P0051, P0052	2	F64	3	1 7	8	LXISIGU

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5.CHECK A/F SENSOR 1 HEATER

Refer to EC-142, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6.REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1.

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

EC

Α

Е

D

Н

M

N

P0031, P0032, P0051, P0052 A/F SENSOR 1 HEATER

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

7.CHECK INTERMITTENT INCIDENT

Perform GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003856518

1. CHECK AIR FUEL RATIO (A/F) SENSOR 1

Check resistance between A/F sensor terminals as per the following.

Terminal No.	Resistance
3 and 4	1.8 - 2.44 Ω [at 25°C (77°F)]
3 and 1, 2	∞ Ω
4 and 1, 2	(Continuity should not exist)

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1.

CAUTION:

- Discard any (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

P0037, P0038, P0057, P0058 HO2S2 HEATER

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P0037, P0038, P0057, P0058 HO2S2 HEATER

Description INFOID:0000000003856519

SYSTEM DESCRIPTION

Sensor	Input signal to ECM	ECM function	Actuator	
Camshaft position sensor (PHASE) Crankshaft position sensor (POS) Engine speed Head		Heated oxygen sensor 2		
Engine coolant temperature sensor	Engine coolant temperature	heater control	Heated oxygen sensor 2 heater	
Mass air flow sensor	Amount of intake air			

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed, amount of intake air and engine coolant temperature.

OPERATION

Engine speed	Heated oxygen sensor 2 heater	
Above 3,600 rpm	OFF	
Below 3,600 rpm after the following conditions are met. Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	ON	(

DTC Logic INFOID:0000000003856520

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0037	Heated oxygen sensor 2 heater (bank 1) control circuit low	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.) Heated oxygen sensor 2 heater
P0038	Heated oxygen sensor 2 heater (bank 1) control circuit high	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.) Heated oxygen sensor 2 heater
P0057	Heated oxygen sensor 2 heater (bank 2) control circuit low	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.) Heated oxygen sensor 2 heater
P0058	Heated oxygen sensor 2 heater (bank 2) control circuit high	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.) Heated oxygen sensor 2 heater

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5 V and 16 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

EC-143

EC

Α

D

Е

F

P0037, P0038, P0057, P0058 HO2S2 HEATER

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

- 1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-III.
- 2. Start engine and warm it up to the normal operating temperature.
- 3. Turn ignition switch OFF and wait at least 10 seconds.
- 4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 5. Let engine idle for 1 minute.
- 6. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT-III" above.

Is 1st trip DTC detected?

YES >> Go to EC-144, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856521

1. CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK HO2S2 POWER SUPPLY CIRCUIT

- 1. Disconnect heated oxygen sensor 2 (HO2S2) harness connector.
- 2. Turn ignition switch ON.
- 3. Check the voltage between HO2S2 harness connector and ground.

DTC		HO2S2	Ground	Voltage	
	Bank	Connector	Terminal	Ground	voltage
P0037, P0038	1	F70	2	Ground	Battery voltage
P0057, P0058	2	F71	2	Giodila	

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R connector F12
- 15A fuse (No. 46)
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair open circuit, short to ground or short to power in harness or connectors.

4. CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- 3. Check the continuity between HO2S2 harness connector and ECM harness connector.

DTC	HO2S2			E	Continuity	
	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0037, P0038	1	F70	3	F7	13	Existed
P0057, P0058	2	F71	3	1-7	17	

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

P0037, P0038, P0057, P0058 HO2S2 HEATER [VQ25DE, VQ35DE] < COMPONENT DIAGNOSIS > NO >> Repair open circuit, short to ground or short to power in harness or connectors. Α 5. CHECK HEATED OXYGEN SENSOR 2 HEATER Refer to EC-145, "Component Inspection". Is the inspection result normal? EC YES >> GO TO 7. NO >> GO TO 6. 6.REPLACE HEATED OXYGEN SENSOR 2Replace malfunctioning heated oxygen sensor 2. **CAUTION:** Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one. Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant. Е >> INSPECTION END 7. CHECK INTERMITTENT INCIDENT F Refer to GI-35, "Intermittent Incident". >> INSPECTION END Component Inspection INFOID:0000000003856522 Н 1. CHECK HEATED OXYGEN SENSOR 2 HEATER Check resistance between HO2S2 terminals as per the following. Terminal No. Resistance 2 and 3 3.4 - 4.4 Ω [at 25°C (77°F)] 1 and 2, 3, 4 (Continuity should not exist) 4 and 1, 2, 3 Is the inspection result normal? YES >> INSPECTION END NO >> GO TO 2. L 2.REPLACE HEATED OXYGEN SENSOR 2 Replace malfunctioning heated oxygen sensor 2. **CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

Р

Ν

P0075, P0081 IVT CONTROL SOLENOID VALVE

Description INFOID:0000000003856523

Intake valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.


The intake valve timing control solenoid valve changes the oil amount and direction of flow through intake valve timing control unit or stops oil flow.

The longer pulse width advances valve angle.

The shorter pulse width retards valve angle.

< COMPONENT DIAGNOSIS >

When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the intake valve angle at the control position.



DTC Logic

INFOID:0000000003856524

[VQ25DE, VQ35DE]

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0075	Intake valve timing control so- lenoid valve (bank 1) circuit	An improper voltage is sent to the ECM through intake valve timing control solenoid	Harness or connectors (Intake valve timing control solenoid valve)
P0081	Intake valve timing control so- lenoid valve (bank 2) circuit		circuit is open or shorted.) • Intake valve timing control solenoid valve

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.perform dtc confirmation procedure

- Start engine and let it idle for 5 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

>> Go to EC-146, "Diagnosis Procedure". YES

>> INSPECTION END NO

Diagnosis Procedure

INFOID:0000000003856525

1.CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- 2. Disconnect intake valve timing control solenoid valve harness connector.
- Turn ignition switch ON.
- Check the voltage between intake valve timing (IVT) control solenoid valve harness connector and ground with CONSULT-III or tester.

DTC	IVT control solenoid valve			Ground	Voltage
	Bank	Connector	Terminal	Giodila	vollage
P0075	1	F81	2	Ground	Battery voltage
P0081	2	F82	2	Giodila	ballery vollage

Is the inspection result normal?

YES >> GO TO 2.

P0075, P0081 IVT CONTROL SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

2.CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

Α

EC

D

Е

Н

K

L

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check the continuity between intake valve timing control solenoid valve harness connector and ECM harness connector.

DTC	IVT control solenoid valve			ECM		Continuity
ыс	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0075	1	F81	1	F8	78	Existed
P0081	2	F82	1	10	75	LXISIEU

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

3.CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to EC-147, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace malfunctioning intake valve timing control solenoid valve.

4.CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003857782

1. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE-I

- 1. Disconnect intake valve timing control solenoid valve harness connector.
- 2. Check resistance between intake valve timing control solenoid valve terminals as per the following.

Terminals	Resistance
1 and 2	7.0 - 7.5 Ω [at 20°C (68°F)]
1 or 2 and ground	$\stackrel{\scriptstyle \infty \; \Omega}{\text{(Continuity should not exist)}}$

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace malfunctioning intake valve timing control solenoid valve.

2.CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE-II

1. Remove intake valve timing control solenoid valve.

Р

N

P0075, P0081 IVT CONTROL SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

2. Provide 12 V DC between intake valve timing control solenoid valve terminals 1 and 2, and then interrupt it. Check that the plunger moves as shown in the figure.

CAUTION:

Never apply 12 V DC continuously for 5 seconds or more. Doing so may result in damage to the coil in intake valve timing control solenoid valve.


NOTE:

Always replace O-ring when intake valve timing control solenoid valve is removed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace malfunctioning intake valve timing control solenoid valve.




[VQ25DE, VQ35DE]

P0102, P0103 MAF SENSOR

Description INFOID:0000000003856532

The mass air flow sensor (1) is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. The mass air flow sensor controls the temperature of the hot wire to a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The greater air flow, the greater the heat loss.

Therefore, the electric current supplied to hot wire is changed to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



DTC Logic INFOID:0000000003856533

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	 Harness or connectors (The sensor circuit is open or shorted.) Intake air leaks Mass air flow sensor
P0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	Harness or connectors (The sensor circuit is open or shorted.) Mass air flow sensor

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

Which DTC is detected?

P0102 >> GO TO 2.

P0103 >> GO TO 3.

2.PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P0102

- Start engine and wait at least 5 seconds.
- Check DTC.

Is DTC detected?

YES >> Go to EC-150, "Diagnosis Procedure".

>> INSPECTION END NO

3.PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P0103-I

- Turn ignition switch ON and wait at least 5 seconds.
- Check DTC.

Is DTC detected?

YES >> Go to EC-150, "Diagnosis Procedure".

NO >> GO TO 4.

f 4.PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P0103-II

- Start engine and wait at least 5 seconds.
- Check DTC.

Is DTC detected?

YES >> Go to EC-150, "Diagnosis Procedure".

EC

Α

D

Е

F

K

N

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856534

1. INSPECTION START

Confirm the detected DTC.

Which DTC is detected?

P0102 >> GO TO 2.

P0103 >> GO TO 3.

2. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Vacuum hoses
- · Intake air passage between air duct to intake manifold

Is the inspection result normal?

YES >> GO TO 3.

NO >> Reconnect the parts.

3.check ground connection

- 1. Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace ground connection.

4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

- 1. Disconnect mass air flow (MAF) sensor harness connector.
- Turn ignition switch ON.
- 3. Check the voltage between MAF sensor harness connector and ground.

MAF	sensor	Ground	Voltage	
Connector	Terminal	Glodila	voltage	
F4	5	Ground	Battery voltage	

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

$5.\mathsf{DETECT}$ MALFUNCTIONING PART

Check the following.

- Harness connectors E7, F121
- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and IPDM E/R
 - >> Repair open circuit, short to ground or short to power in harness or connectors.

6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between MAF sensor harness connector and ECM harness connector.

MAF	sensor	E(Continuity	
Connector Terminal		Connector	Terminal	Continuity
F4	4	F8	56	Existed

4. Also check harness for short to ground and short to power.

P0102, P0103 MAF SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

7.CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between MAF sensor harness connector and ECM harness connector.

MAF	sensor	E	Continuity	
Connector	Terminal	Connector Terminal		Continuity
F4	3	F8	58	Existed

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

8. CHECK MASS AIR FLOW SENSOR

Refer to EC-151, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace mass air flow sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

1.CHECK MASS AIR FLOW SENSOR-I

(P)With CONSULT-III

- 1. Reconnect all harness connectors disconnected.
- 2. Start engine and warm it up to normal operating temperature.
- 3. Connect CONSULT-III and select "DATA MONITOR" mode.
- 4. Select "MAS A/F SE-B1" and check indication under the following conditions.

Monitor item	Condition	MAS A/F SE-B1 (V)
	Ignition switch ON (Engine stopped.)	Approx. 0.4
MAS A/F SE-B1	Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2
MAS AVF SE-BI	2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 1.9
	Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*

^{*:} Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Without CONSULT-III

- 1. Reconnect all harness connectors disconnected.
- 2. Start engine and warm it up to normal operating temperature.
- 3. Check the voltage between ECM harness connector terminals under the following conditions.

EC

Α

D

Е

F

G

INFOID:0000000003856535

K

L

M

	ECM			
Connector -	+ -		Condition	Voltage (V)
	Terminal	Terminal		
	58 (MAF sen- sor signal)		Ignition switch ON (Engine stopped.)	Approx. 0.4
F8		56 (Sensor	Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2
го		ground)	2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 1.9
			Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*

^{*:} Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Is the inspection result normal?

YES >> GO TO 4. NO >> GO TO 2.

2.CHECK FOR THE CAUSE OF UNEVEN AIR FLOW THROUGH MASS AIR FLOW SENSOR

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- · Crushed air ducts
- · Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system parts

Is the inspection result normal?

YES >> GO TO 4. NO >> GO TO 3.

3. CHECK MASS AIR FLOW SENSOR-II

(P)With CONSULT-III

- Repair or replace malfunctioning part.
- Start engine and warm it up to normal operating temperature.
- 3. Connect CONSULT-III and select "DATA MONITOR" mode.
- 4. Select "MAS A/F SE-B1" and check indication under the following conditions.

Monitor item	Condition	MAS A/F SE-B1 (V)
	Ignition switch ON (Engine stopped.)	Approx. 0.4
MAS A/F SE-B1	Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2
WAS A/F SE-BT	2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 1.9
	Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*

^{*:} Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Without CONSULT-III

- 1. Repair or replace malfunctioning part.
- 2. Start engine and warm it up to normal operating temperature.
- Check the voltage between ECM harness connector terminals under the following conditions.

	ECM			
Connector —	+	_	Condition	Voltage (V)
	Terminal	Terminal		
	58 (MAF sen- sor signal)		Ignition switch ON (Engine stopped.)	Approx. 0.4
F8			Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2
		ground)	2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 1.9
			Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*

^{*:} Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Is the inspection result normal?

P0102, P0103 MAF SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Α

EC

D

Е

F

YES >> INSPECTION END

NO >> GO TO 4.

4. CHECK MASS AIR FLOW SENSOR-III

With CONSULT-III

- Turn ignition switch OFF.
- 2. Disconnect mass air flow sensor harness connector and reconnect it again.
- 3. Start engine and warm it up to normal operating temperature.
- 4. Connect CONSULT-III and select "DATA MONITOR" mode.
- 5. Select "MAS A/F SE-B1" and check indication under the following conditions.

Monitor item	Condition	MAS A/F SE-B1 (V)
	Ignition switch ON (Engine stopped.)	Approx. 0.4
MAS A/F SE-B1	Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2
MAS A/F SE-B1	2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 1.9
	Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*

^{*:} Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Without CONSULT-III

- 1. Turn ignition switch OFF.
- 2. Disconnect mass air flow sensor harness connector and reconnect it again.
- 3. Start engine and warm it up to normal operating temperature.
- 4. Check the voltage between ECM harness connector terminals under the following conditions.

ECM				_	
Connector	+	_	Condition	Voltage (V)	
Connector	Terminal	Terminal			
			Ignition switch ON (Engine stopped.)	Approx. 0.4	
58 F8 (MAF sen- (S		Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2		
ГО	F8 (MAF sen- (Sensor sor signal) ground)		2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 1.9	
			Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*	

^{*:} Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Clean or replace mass air flow sensor.

L

K

Ν


0

P0112, P0113 IAT SENSOR

Description

The intake air temperature sensor is built-into the mass air flow sensor (1). The sensor detects intake air temperature and transmits a signal to the ECM.


The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the rise in temperature.



<Reference data>

Intake air temperature [°C (°F)]	Voltage* (V)	Resistance (kΩ)
25 (77)	3.3	1.800 - 2.200
80 (176)	1.2	0.283 - 0.359

^{*:} These data are reference values and are measured between ECM terminals 50 (Intake air temperature sensor) and 56 (Sensor ground).



DTC Logic

INFOID:0000000003856537

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P0112	Intake air tempera- ture sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	Harness or connectors (The sensor circuit is open or shorted.)	
P0113	Intake air tempera- ture sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	Intake air temperature sensor	

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.perform dtc confirmation procedure

- 1. Turn ignition switch ON and wait at least 5 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-155, "Diagnosis Procedure".

NO >> INSPECTION END

[VQ25DE, VQ35DE]

Diagnosis Procedure

INFOID:0000000003856538

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

- Disconnect mass air flow sensor (with intake air temperature sensor) harness connector.
- 2. Turn ignition switch ON.
- Check the voltage between mass air flow sensor harness connector and ground.

MAF	sensor	Ground	Voltage	
Connector	Terminal	Ground	voltage	
F4	2	Ground	Approx. 5 V	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

3.CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check harness continuity between mass air flow sensor harness connector and ECM harness connector.

MAF sensor		ECM		Continuity
Connector	Terminal	Connector	Terminal	Continuity
F4	1	F8	56	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4.CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to EC-155, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace mass air flow sensor (with intake air temperature sensor).

5. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003856539

1. CHECK INTAKE AIR TEMPERATURE SENSOR

- Turn ignition switch OFF.
- Disconnect mass air flow sensor harness connector.
- Check resistance between mass air flow sensor terminals as per the following.

EC-155

EC

Α

D

Е

M

P0112, P0113 IAT SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Terminal	Condition		Resistance (kΩ)
1 and 2	Temperature [°C (°F)]	25 (77)	1.800 - 2.200

Is the inspection result normal?


YES >> INSPECTION END

NO >> Replace mass air flow sensor (with intake air temperature sensor).

P0117, P0118 ECT SENSOR

Description INFOID:0000000003856544


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature [°C (°F)]	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

^{*:} These data are reference values and are measured between ECM terminals 46 (Engine coolant temperature sensor) and 52 (Sensor ground).



DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble Diagnosis Name	DTC detecting condition	Possible Cause	ŀ
P0117	Engine coolant tem- perature sensor cir- cuit low input	An excessively low voltage from the sensor is sent to ECM.	Harness or connectors (The sensor circuit is open or shorted.)	
P0118	Engine coolant tem- perature sensor cir- cuit high input	An excessively high voltage from the sensor is sent to ECM.	Engine coolant temperature sensor	_

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON and wait at least 5 seconds.
- 2. Check DTC.

Is DTC detected?

YES >> Go to EC-158, "Diagnosis Procedure".

NO >> INSPECTION END

Α

EC

Е

D

INFOID:0000000003856545

Ν

Diagnosis Procedure

< COMPONENT DIAGNOSIS >

INFOID:0000000003856546

[VQ25DE, VQ35DE]

CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2. CHECK ECT SENSOR POWER SUPPLY CIRCUIT

- Disconnect engine coolant temperature (ECT) sensor harness connector.
- 2. Turn ignition switch ON.
- Check the voltage between ECT sensor harness connector and ground.

ECT :	sensor	Ground	Voltage	
Connector Terminal		Ground	voltage	
F80	1	Ground	Approx. 5 V	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

${f 3.}$ CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check the continuity between ECT sensor harness connector and ECM harness connector.

ECT sensor		ECM		Continuity	
Connector	Terminal	Connector	Terminal	Continuity	
F80	2	F8	52	Existed	

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

f 4.CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to EC-158, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace engine coolant temperature sensor.

CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003856547

1. CHECK ENGINE COOLANT TEMPERATURE SENSOR

- Turn ignition switch OFF.
- Disconnect engine coolant temperature sensor harness connector.
- Remove engine coolant temperature sensor.

P0117, P0118 ECT SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

4. Check resistance between engine coolant temperature sensor terminals as per the following.

Terminals	Condition		Resistance (kΩ)
	Temperature [°C (°F)]	20 (68)	2.1 - 2.9
1 and 2		50 (122)	0.68 - 1.00
		90 (194)	0.236 - 0.260

JMBIA0080ZZ

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace engine coolant temperature sensor.

EC

Α

C

D

Е

F

G

Н

.

K

J

L

M

Ν


0

P0122, P0123 TP SENSOR

Description INFOID:0000000003856548

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has two sensors. These sensors are a kind of potentiometer which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and controls the throttle valve opening angle in response to driving conditions via the throttle control motor.



DTC Logic

INFOID:0000000003856549

DTC DETECTION LOGIC

NOTE:

If DTC P0122 or P0123 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0122	Throttle position sensor 2 circuit low input	An excessively low voltage from the TP sensor 2 is sent to ECM.	Harness or connectors (TP sensor 2 circuit is open or shorted.)
P0123	Throttle position sensor 2 circuit high input	An excessively high voltage from the TP sensor 2 is sent to ECM.	Electric throttle control actuator (TP sensor 2)

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for 1 second.
- Check DTC.

Is DTC detected?

YES >> Go to EC-160, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856550

CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT

- Disconnect electric throttle control actuator harness connector.
- Turn ignition switch ON.

P0122, P0123 TP SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

3. Check the voltage between electric throttle control actuator harness connector and ground.

Electric throttle	control actuator	Ground	Voltage	
Connector	Terminal	Giodila	voltage	
F29	1	Ground	Approx. 5 V	

EC

Α

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

1

3.check throttle position sensor 2 ground circuit for open and short

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

Е

F

Electric throttle	control actuator	E	CM	Continuity
Connector	Terminal	Connector	Terminal	Continuity
F29	4	F8	36	Existed

G

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

Н

4.CHECK THROTTLE POSITION SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

Electric throttle	control actuator	E	Continuity	
Connector	Terminal	Connector	Terminal	Continuity
F29	3	F8	38	Existed

2. Also check harness for short to ground and short to power.

K

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5.CHECK THROTTLE POSITION SENSOR

Refer to EC-162, "Component Inspection".

M

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

N

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- 2. Refer to EC-162, "Special Repair Requirement".

0

Р

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003856551

1. CHECK THROTTLE POSITION SENSOR

- 1. Turn ignition switch OFF.
- 2. Reconnect all harness connectors disconnected.
- 3. Perform EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".
- 4. Turn ignition switch ON.
- 5. Selector lever position is D.
- 6. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM					
Connector	+ -		Condition		Voltage	
Connector	Terminal	Terminal				
	37 (TP sensor 1	36 (Sensor ground)		Fully released	More than 0.36 V	
F8	signal)		Accelerator pedal	Fully depressed	Less than 4.75 V	
-	38 (TP sensor 2		Accelerator pedar	Fully released	Less than 4.75 V	
	signal)			Fully depressed	More than 0.36 V	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- 2. Go to EC-162, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

INFOID:0000000003856552

1. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement"

>> GO TO 2.

2. PERFORM IDLE AIR VOLUME LEARNING

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement"

>> END

Α

D

Е

Р


P0130, P0150 A/F SENSOR 1

Description INFOID:0000000003856564


The air fuel ratio (A/F) sensor 1 is a planar one-cell limit current sensor. The sensor element of the A/F sensor 1 is composed an electrode layer, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement $\lambda = 1$, but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide λ range.

The exhaust gas components diffuse through the diffusion layer at the sensor cell. An electrode layer is applied voltage, and this current relative oxygen density in lean. Also this current relative hydrocarbon density in rich.



Therefore, the A/F sensor 1 is able to indicate air fuel ratio by this electrode layer of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of about 800°C (1,472°F).



DTC Logic INFOID:0000000003856565

DTC DETECTION LOGIC

To judge malfunctions, the diagnosis checks that the A/F signal computed by ECM from the A/F sensor 1 signal fluctuates according to fuel feedback control.

DTC No.	Trouble diagnosis name		DTC detecting condition	Possible Cause	ŀ
P0130	Air fuel ratio (A/F) sensor 1 (bank 1) circuit	A)	The A/F signal computed by ECM from the A/F sensor 1 signal is constantly in a range other than approx. 2.2 V.	Harness or connectors (The A/F sensor 1 circuit is open or shorted.)	
	(Dank I) Gircuit		The A/F signal computed by ECM from the A/F sensor 1 signal is constantly approx. 2.2 V.	A/F sensor 1	
P0150	Air fuel ratio (A/F) sensor 1	A)	The A/F signal computed by ECM from the A/F sensor 1 signal is constantly in a range other than approx. 2.2 V.	Harness or connectors (The A/F sensor 1 circuit is open or shorted.)	ľ
	(bank 2) circuit	B)	The A/F signal computed by ECM from the A/F sensor 1 signal is constantly approx. 2.2 V.	A/F sensor 1	1

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A

Start engine and warm it up to normal operating temperature.

[VQ25DE, VQ35DE]

- < COMPONENT DIAGNOSIS > Let it idle for 2 minutes.
- 3. Check 1st trip DTC.

Is 1st trip DTC detected?

>> Go to EC-165, "Diagnosis Procedure".

NO-1 >> With CONSULT-III: GO TO 3.

NO-2 >> Without CONSULT-III: GO TO 7.

3.CHECK AIR FUEL RATIO (A/F) SENSOR 1 FUNCTION

- Start engine and warm it up to normal operating temperature.
- Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-III.
- Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication.

Does the indication fluctuate around 2.2 V?

YES >> GO TO 4.

NO >> Go to EC-165. "Diagnosis Procedure".

4. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION B-I

- Select "A/F SEN1 (B1) P1276" (for DTC P0130) or "A/F SEN1 (B2) P1286" (for DTC P0150) of "A/F SEN1" in "DTC WORK SUPPORT" mode with CONSULT-III.
- Touch "START".
- When the following conditions are met, "TESTING" will be displayed on the CONSULT-III screen.

ENG SPEED	1,000 - 3,200 rpm
VHCL SPEED SE	More than 64 km/h (40 mph)
B/FUEL SCHDL	1.0 - 8.0 msec
Selector lever	D position

If "TESTING" is not displayed after 20 seconds, retry from step 2.

CAUTION:

Always drive vehicle at a safe speed.

Is "TESTING" displayed on CONSULT-III screen?

YES >> GO TO 5.

NO >> Check A/F sensor 1 function again. GO TO 3.

$oldsymbol{5}$.PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION B-II

Release accelerator pedal fully.

NOTE:

Never apply brake when releasing the accelerator pedal.

Which does "TESTING" change to?

COMPLETED>>GO TO 6.

OUT OF CONDITION>>Retry DTC CONFIRMATION PROCEDURE. GO TO 4.

$oldsymbol{6}$.PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION B-III

Touch "SELF-DIAG RESULT".

Which is displayed on CONSULT-III screen?

OK >> INSPECTION END

NG >> Go to EC-165, "Diagnosis Procedure".

1.PERFORM COMPONENT FUNCTION CHECK FOR MALFUNCTION B

Perform component function check. Refer to EC-165, "Component Function Check".

NOTE:

Use component function check to check the overall function of the A/F sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-165, "Diagnosis Procedure".

[VQ25DE, VQ35DE]

INFOID:0000000003856566

Α

EC

D

Е

F

Component Function Check

1. PERFORM COMPONENT FUNCTION CHECK

- 1. Start engine and warm it up to normal operating temperature.
- 2. Drive the vehicle at a speed of 80 km/h (50 MPH) for a few minutes in the suitable gear position.
- Set D position, then release the accelerator pedal fully until the vehicle speed decreases to 50 km/h (31 MPH).

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

Never apply brake when releasing the accelerator pedal.

- 4. Repeat steps 2 and 3 for 5 times.
- 5. Stop the vehicle and turn ignition switch OFF.
- 6. Wait at least 10 seconds and restart engine.
- 7. Repeat steps 2 and 3 for 5 times.
- 8. Stop the vehicle and connect GST to the vehicle.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-165, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

- Disconnect A/F sensor 1 harness connector.
- 2. Turn ignition switch ON.
- Check the voltage between A/F sensor 1 harness connector and ground.

DTC		A/F sensor 1	Ground	Voltage	
DIC	Bank	Connector	Terminal	Giodila	voltage
P0130	1	F27	4	Ground	Battery voltage
P0150	2	F64	4	Sibulia	Dattery Voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F12
- 15A fuse (No. 46)
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

4.CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

INFOID:0000000003856567

Н

N

DTC		A/F sensor 1		E	CM	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0130	1	F27	1		45	
F0130		2	2	F8	49	Existed
P0150	50 2 F64	2 E64	1	10	53	LAISIEU
FU150		2		57		

4. Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

DTC	A/F sensor 1			A/F sensor 1 ECM		Ground	Continuity							
DIC	Bank	Connector	Terminal	Connector	Terminal	Giodila	Continuity							
P0130	1	F27	1		45									
F0130		1 127	Γ21	121	1 21	121	121	121	1 121	2 F8	Fo	49	Cround	Not evieted
P0150	2	F64	1	ГО	53	Ground	Not existed							
PU150	2	г04	2		57									

5. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Perform GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning part.

6.REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1.

CAUTION:

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END


P0131, P0151 A/F SENSOR 1

Description INFOID:0000000003856568


The air fuel ratio (A/F) sensor 1 is a planar one-cell limit current sensor. The sensor element of the A/F sensor 1 is composed an electrode layer, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement $\lambda = 1$, but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide λ range.

The exhaust gas components diffuse through the diffusion layer at the sensor cell. An electrode layer is applied voltage, and this current relative oxygen density in lean. Also this current relative hydrocarbon density in rich.



Therefore, the A/F sensor 1 is able to indicate air fuel ratio by this electrode layer of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of about 800°C (1,472°F).



DTC Logic INFOID:0000000003856569

DTC DETECTION LOGIC

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the A/F sensor 1 signal is not inordinately low.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0131	Air fuel ratio (A/F) sensor 1 (bank 1) circuit low voltage	The A/F signal computed by ECM from the A/	Harness or connectors (The A/F sensor 1 circuit is open or
P0151	Air fuel ratio (A/F) sensor 1 (bank 2) circuit low voltage	F sensor 1 signal is constantly approx. 0 V.	shorted.) • A/F sensor 1

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V at idle.

>> GO TO 2.

2.check A/F sensor 1 function

(P)With CONSULT-III

- Start engine and warm it up to normal operating temperature.
- Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-III.
- Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication.

With GST

Follow the procedure "With CONSULT-III" above.

Is the indication constantly approx. 0 V?

EC

Α

D

Е

K

M

Ν

YES >> Go to EC-168, "Diagnosis Procedure".

NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE

(P)With CONSULT-III

- 1. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
- Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine. CAUTION:

Always drive vehicle at a safe speed.

3. Maintain the following conditions for about 20 consecutive seconds.

ENG SPEED	1,000 - 3,200 rpm
VHCL SPEED SE	More than 40 km/h (25 mph)
B/FUEL SCHDL	1.5 - 9.0 msec
Selector lever	Suitable position

NOTE:

- Keep the accelerator pedal as steady as possible during cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 1, return to step 1.
- 4. Check 1st trip DTC.

®With GST

Follow the procedure "With CONSULT-III" above.

Is 1st trip DTC detected?

YES >> Go to EC-168, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856570

1. CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

- 1. Disconnect A/F sensor 1 harness connector.
- 2. Turn ignition switch ON.
- 3. Check the voltage between A/F sensor 1 harness connector and ground.

DTC		A/F sensor 1		Ground	Voltage	
DIC	Bank	Connector	Terminal	Ground	voltage	
P0131	1	F27	4	Ground	Battery voltage	
P0151	2	F64	4	Giodila	ballery vollage	

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F12
- 15A fuse (No. 46)
- Harness for open or short between A/F sensor 1 and fuse

[VQ25DE, VQ35DE]

EC

D

Е

F

4.CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

DTC	A/F sensor 1			E	CM	Continuity
DIC	Bank	Connector	Terminal	ECM al Connector Terminal 45 49 53 57	Continuity	
P0131	0121 1 E27	F27	1		45	
FUISI	'	121	2	E0	49	Frietral
P0151	D0454 2 504	E64	1	ГО	53	Existed
F0151	2	2 F64 —	2		57	

4. Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

DTC	A/F sensor 1			ECM		Ground	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	- Ground	Continuity
P0131	D0404 4 5	F27	1		45		
P0131	Į į	F21	2	Ε0	49	Ground	Not evieted
D0454	F0.4	1	F8	53	Giouna	Not existed	
P0151	P0151 2	F64	2		57		

Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Perform GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning part.

O.REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1.

CAUTION:

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

Ν

K


P0132, P0152 A/F SENSOR 1

Description INFOID:000000003856571


The air fuel ratio (A/F) sensor 1 is a planar one-cell limit current sensor. The sensor element of the A/F sensor 1 is composed an electrode layer, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement $\lambda = 1$, but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide λ range.

The exhaust gas components diffuse through the diffusion layer at the sensor cell. An electrode layer is applied voltage, and this current relative oxygen density in lean. Also this current relative hydrocarbon density in rich.



Therefore, the A/F sensor 1 is able to indicate air fuel ratio by this electrode layer of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of about 800°C (1,472°F).



DTC Logic

DTC DETECTION LOGIC

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the A/F sensor 1 signal is not inordinately high.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0132	Air fuel ratio (A/F) sensor 1 (bank 1) circuit high voltage	The A/F signal computed by ECM from the A/F	Harness or connectors (The A/F sensor 1 circuit is open or
P0152	Air fuel ratio (A/F) sensor 1 (bank 2) circuit high voltage	sensor 1 signal is constantly approx. 5 V.	shorted.) • A/F sensor 1

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V at idle.

>> GO TO 2.

2.CHECK A/F SENSOR 1 FUNCTION

(P)With CONSULT-III

- 1. Start engine and warm it up to normal operating temperature.
- 2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-III.
- 3. Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication.

With GST

Follow the procedure "With CONSULT-III" above.

Is the indication constantly approx. 5 V?

[VQ25DE, VQ35DE]

YES >> Go to EC-171, "Diagnosis Procedure".

NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE

(I) With CONSULT-III

Turn ignition switch OFF, wait at least 10 seconds and then restart engine.

Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
 CAUTION:

Always drive vehicle at a safe speed.

3. Maintain the following conditions for about 20 consecutive seconds.

ENG SPEED	1,000 - 3,200 rpm
VHCL SPEED SE	More than 40 km/h (25 mph)
B/FUEL SCHDL	1.5 - 9.0 msec
Selector lever	Suitable position

NOTE:

- Keep the accelerator pedal as steady as possible during the cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 1, return to step 1.
- 4. Check 1st trip DTC.

®With GST

Follow the procedure "With CONSULT-III" above.

Is 1st trip DTC detected?

YES >> Go to EC-171, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

- Disconnect A/F sensor 1 harness connector.
- Turn ignition switch ON.
- 3. Check the voltage between A/F sensor 1 harness connector and ground.

DTC		A/F sensor 1 Ground	Voltage		
	Bank	Connector	Terminal 4	voltage	
P0132	1	F27	4	Ground	Battery voltage
P0152	2	F64	4	Giodila	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F12
- 15A fuse (No. 46)
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

А

EC

С

D

Е

Г

G

. .

Н

INFOID:00000000003856573

K

L

M

Ν

0

4. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

DTC	A/F sensor 1			E	CM	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0132	1 F27	1		45		
F0132	'	1 21	2	- 0	49	Cylintad
D0152	P0152 2 F64 —	FC4	1	F8	53	Existed
FU152		2		57		

4. Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

DTC	A/F sensor 1			ECM		Ground	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Ground	Continuity
P0132	D0422 4 F27	F27	1		45		Not existed
P0132	Į.	F21	2	F8	49	Ground	
P0152	P0152 2 F64	1	го	53	Giodila	Not existed	
FU152	2	F04	2	57	57		

5. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Perform GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning part.

O.REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1.

CAUTION:

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

Α

D

Е

F

Н

N


P0133, P0153 A/F SENSOR 1

Description INFOID:0000000003856574


The air fuel ratio (A/F) sensor 1 is a planar one-cell limit current sensor. The sensor element of the A/F sensor 1 is composed an electrode layer, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement $\lambda = 1$, but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide λ range.

The exhaust gas components diffuse through the diffusion layer at the sensor cell. An electrode layer is applied voltage, and this current relative oxygen density in lean. Also this current relative hydrocarbon density in rich.



Therefore, the A/F sensor 1 is able to indicate air fuel ratio by this electrode layer of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of about 800°C (1,472°F).



DTC Logic INFOID:0000000003856575

DTC DETECTION LOGIC

To judge the malfunction of A/F sensor 1, this diagnosis measures response time of the A/F signal computed by ECM from the A/F sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and the A/F sensor 1 temperature index. Judgment is based on whether the compensated time (the A/F signal cycling time index) is inordinately long or not.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0133	Air fuel ratio (A/F) sensor 1 (bank 1) circuit slow response		Harness or connectors (The A/F sensor 1 circuit is open or shorted.)
P0153	Air fuel ratio (A/F) sensor 1 (bank 2) circuit slow response	The response of the A/F signal computed by ECM from A/F sensor 1 signal takes more than the specified time.	 A/F sensor 1 A/F sensor 1 heater Fuel pressure Fuel injector Intake air leaks Exhaust gas leaks PCV Mass air flow sensor

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

Will CONSULT-III be used?

YES >> GO TO 2.

>> GO TO 5. NO

2.perform dtc confirmation procedure-i

(P)With CONSULT-III

- 1. Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1minute under no load.
- Let engine idle for 1 minute.
- Select "A/F SEN1(B1) P1278/P1279" (for DTC P0133) or "A/F SEN1(B2) P1288/P1289" (for DTC P0153) of "A/F SEN1" in "DTC WORK SUPPORT" mode with CONSULT-III.
- 6. Touch "START".

Is COMPLETED displayed?

YES >> GO TO 3.

NO >> GO TO 4.

3. PERFORM DTC CONFIRMATION PROCEDURE-II

Check that "OK" is displayed after touching "SELF-DIAG RESULT".

Is OK displayed?

YES >> INSPECTION END

NO >> Go to EC-175, "Diagnosis Procedure".

4.PERFORM DTC CONFIRMATION PROCEDURE-III

- 1. After perform the following procedure, "TESTING" will be displayed on the CONSULT-III screen.
- Increase the engine speed up to between 4,000 and 5,000 rpm and maintain that speed for 10 seconds.
- Fully release accelerator pedal and then let engine idle for about 10 seconds.

If "TESTING" is not displayed after 10 seconds, refer to EC-124, "Component Function Check".

- Wait for about 20 seconds at idle under the condition that "TESTING" is displayed on the CONSULT-III screen.
- Check that "TESTING" changes to "COMPLETED".

If "TESTING" changed to "OUT OF CONDITION", refer to EC-124, "Component Function Check".

4. Check that "OK" is displayed after touching "SELF-DIAG RESULT".

Is OK displayed?

YES >> INSPECTION END

NO >> Go to EC-175, "Diagnosis Procedure".

5. CHECK MIXTURE RATIO SELF-LEARNING VALUE

- 1. Start engine and warm it up to normal operating temperature.
- 2. Select Service \$01 with GST.
- 3. Calculate the total value of "Short-term fuel trim" and "Long-term fuel trim" indications.

Is the total percentage within ±15%?

YES >> GO TO 7.

NO >> GO TO 6.

6.DETECT MALFUNCTIONING PART

Check the following.

- Intake air leaks
- Exhaust gas leaks
- · Incorrect fuel pressure
- Lack of fuel
- Fuel injector
- Incorrect PCV hose connection
- PCV valve
- Mass air flow sensor

>> Repair or replace malfunctioning part.

7.PERFORM DTC CONFIRMATION PROCEDURE-IV

1. Turn ignition switch OFF and wait at least 10 seconds.

[VQ25DE, VQ35DE]

- Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- Let engine idle for 1 minute. 3.
- Increase the engine speed up to between 4,000 and 5,000 rpm and maintain that speed for 10 seconds.
- 5. Fully release accelerator pedal and then let engine idle for about 1 minute.
- Check 1st trip DTC.

Is 1st trip DTC detected?

>> Go to EC-175, "Diagnosis Procedure". YES

>> INSPECTION END NO

Diagnosis Procedure

INFOID:0000000003856576

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.


2. RETIGHTEN A/F SENSOR 1

Loosen and retighten the A/F sensor 1. Refer to EM-34, "Removal and Installation".

>> GO TO 3.

3. CHECK EXHAUST GAS LEAK

- Start engine and run it at idle.
- 2. Listen for an exhaust gas leak before three way catalyst (manifold).



Is exhaust gas leak detected?

>> Repair or replace malfunctioning part.

NO >> GO TO 4.

4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

Is intake air leak detected?

YES >> Repair or replace malfunctioning part.

NO >> GO TO 5.

5.CLEAR MIXTURE RATIO SELF-LEARNING VALUE

- Clear the mixture ratio self-learning value. Refer to EC-18. "MIXTURE RATIO SELF-LEARNING VALUE CLEAR: Special Repair Requirement".
- Run engine for at least 10 minutes at idle speed.
- Check 1st trip DTC.

Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected? Is it difficult to start engine?

YES >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to EC-198. "DTC Logic" or EC-202, "DTC Logic".

NO >> GO TO 6.

$oldsymbol{\circ}$.CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

Disconnect A/F sensor 1 harness connector.

EC-175

EC

Α

D

F

M

Ν

- Turn ignition switch ON.
- 3. Check the voltage between A/F sensor 1 harness connector and ground.

DTC		A/F sensor 1		Ground	Voltage	
DIC	Bank	Connector	Terminal	Ground	voltage	
P0133	1	F27	4	Ground	Battory voltago	
P0153	2	F64	4	Giouna	Battery voltage	

Is the inspection result normal?

YES >> GO TO 8. NO >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F12
- 15A fuse (No. 46)
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

8. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

DTC	A/F sensor 1			E	CM	Continuity
DIC	Bank	Connector	nector Terminal Connector		Terminal	Continuity
P0133	1 F27	1		45		
F0133	1	F21	2	F8	49	Existed
D0152	P0153 2 F64	E64	1	ГО	53	EXISIEU
F0155		2		57		

4. Check the continuity between A/F sensor 1 harness connector or ECM harness connector ground.

DTC	A/F sensor 1			ECM		Ground	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Ground Ground	Continuity
P0133	133 1 F27	1 507		45			
F0133	'	Γ21	2	F8	49	Ground	Not existed
P0153	2	2 F64	1	- ГО	53		
	2	F04	2		57		

5. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

9.CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER

Refer to EC-142, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 10. NO >> GO TO 13.

10. CHECK MASS AIR FLOW SENSOR

Refer to EC-151, "Component Inspection".

Is the inspection result normal?

P0133, P0153 A/F SENSOR 1					
< COMPONENT DIAGNOSIS > [VQ25DE, VQ35DE]					
YES >> GO TO 11. NO >> Replace mass air flow sensor.	Δ				
NO >> Replace mass air flow sensor. 11.CHECK PCV VALVE	А				
Refer to <u>EC-347, "Component Inspection"</u> . Is the inspection result normal?	EC				
YES >> GO TO 12.					
NO >> Repair or replace PCV valve.	С				
12.check intermittent incident					
Perform GI-35, "Intermittent Incident".					
Is the inspection result normal?	D				
YES >> GO TO 13. NO >> Repair or replace malfunctioning part.					
13. REPLACE AIR FUEL RATIO (A/F) SENSOR 1	Е				
Replace malfunctioning air fuel ratio (A/F) sensor 1. CAUTION:	_				
• Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a	F				
hard surface such as a concrete floor; use a new one. • Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread					
Cleaner and approved anti-seize lubricant.	G				
>> INSPECTION END	Н				
	J				
	K				
	L				
	M				
	IVI				
	Ν				
	0				
	Р				

INFOID:0000000003856578

P0137, P0157 HO2S2


Description INFOID:000000003856577

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1 V in richer conditions to 0 V in leaner conditions.


Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



DTC Logic

DTC DETECTION LOGIC

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during various driving conditions such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0137	Heated oxygen sensor 2 (bank 1) circuit low voltage	The maximum voltage from the sensor does not	Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2
P0157	Heated oxygen sensor 2 (bank 2) circuit low voltage	reach the specified voltage.	Fuel pressureFuel injectorIntake air leaks

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Will CONSULT-III be used?

Will CONSULT-III be used?

YES >> GO TO 2.

NO >> GO TO 5.

2. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

For better results, perform "DTC WORK SUPPORT" at a temperature of 0 to 30 °C (32 to 86 °F).

>> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE

[VQ25DE, VQ35DE] < COMPONENT DIAGNOSIS >

- Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-III.
- Start engine and warm it up to the normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 5. Let engine idle for 1 minute.
- Check that "COOLAN TEMP/S" indicates more than 70°C (158°F).

If not, warm up engine and go to next step when "COOLAN TEMP/S" indication reaches 70°C (158°F).

- 7. Open engine hood.
- 8. Select "HO2S2 (B1) P1147" (for DTC P0137) or "HO2S2 (B2) P1167" (for DTC P0157) of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-III.
- Follow the instruction of CONSULT-III.

NOTE:

It will take at most 10 minutes until "COMPLETED" is displayed.

10. Touch "SELF-DIAG RESULTS".

Which is displayed on CONSULT-III screen?

OK >> INSPECTION END

NG >> Go to EC-180, "Diagnosis Procedure".

CAN NOT BE DIAGNOSED>>GO TO 4.

f 4.PERFORM DTC CONFIRMATION PROCEDURE AGAIN

- Turn ignition switch OFF and leave the vehicle in a cool place (soak the vehicle).
- 2. Perform DTC confirmation procedure again.

>> GO TO 3.

5.PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to EC-179, "Component Function Check".

NOTE:

Use component function check to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-180, "Diagnosis Procedure".

Component Function Check

$oldsymbol{1}$ -PERFORM COMPONENT FUNCTION CHECK-I

Without CONSULT-III

- Start engine and warm it up to the normal operating temperature. 1.
- Turn ignition switch OFF and wait at least 10 seconds.
- Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- Let engine idle for 1 minute.
- 5. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM					
DTC	Connec-	+	_	Condition	Voltage	
	tor	Terminal	Terminal			
P0137	- F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Revving up to 4,000 rpm under no	The voltage should be above 0.68 V	
P0157		34 [HO2S2 (bank 2) signal]	ground)	load at least 10 times	at least once during this procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2. EC

Α

D

Е

F

Н

INFOID:0000000003856579

N

2.perform component function check-ii

Check the voltage between ECM harness connector terminals under the following conditions.

	ECM				
DTC	Connec-	+	_	Condition	Voltage
	tor	Terminal	Terminal		
P0137	F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Keeping engine at idle for 10 minutes	The voltage should be above 0.68 V at least once during this procedure.
P0157		34 [HO2S2 (bank 2) signal]	ground)		

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 3.

3.PERFORM COMPONENT FUNCTION CHECK-III $\,$

Check the voltage between ECM harness connector terminals under the following conditions.

DTC	ECM				
	Connec- tor	+	_	Condition	Voltage
		Terminal	Terminal		
P0137	_ F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Coasting from 80 km/h (50 MPH) in D position	The voltage should be above 0.68 V at least once during this procedure.
P0157		34 [HO2S2 (bank 2) signal]	ground)		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-180, "Diagnosis Procedure".

Diagnosis Procedure

INFOID:0000000003856580

1.CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CLEAR MIXTURE RATIO SELF-LEARNING VALUE

- Clear the mixture ratio self-learning value. Refer to EC-18, "MIXTURE RATIO SELF-LEARNING VALUE CLEAR: Special Repair Requirement".
- Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC P0171 or P0174 detected? Is it difficult to start engine?

>> Perform trouble diagnosis for DTC P0171 or P0174. Refer to EC-198, "DTC Logic". YES

NO >> GO TO 3.

3.CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- 2. Disconnect heated oxygen sensor 2 harness connector.
- Disconnect ECM harness connector.

< COMPONENT DIAGNOSIS >

Check the continuity between heated oxygen sensor 2 (HO2S2) harness connector and ECM harness connector.

DTC		HO2S2		E	Continuity	
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0137	1	F70	1	F8	35	Existed
P0157	2	F71	1	10	33	LAISIGU

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

$oldsymbol{4}.$ CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between HO2S2 harness connector and ECM harness connector.

DTC		HO2S2		E	CM	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0137	1	F70	4	F8	33	Existed
P0157	2	F71	4	10	34	LAISIEU

Check the continuity between HO2S2 harness connector or ECM harness connector and ground.

DTC		HO2S2		E	CM	Ground	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Oround	
P0137	1	F70	4	F8	33	Ground	Not existed
P0157	2	F71	4	1.0	34	Giouna	INOL EXISTED

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5.CHECK HEATED OXYGEN SENSOR 2

Refer to EC-182, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6.REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7) in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

.CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

EC-181

EC

Α

F

Н

K

M

Р

Component Inspection

INFOID:0000000003856581

1.INSPECTION START

Will CONSULT-III be used?


Will CONSULT-III be used?

YES >> GO TO 2. NO >> GO TO 3.

2.CHECK HEATED OXYGEN SENSOR 2

(P)With CONSULT-III

- Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-III.
- 2. Start engine and warm it up to the normal operating temperature.
- 3. Turn ignition switch OFF and wait at least 10 seconds.
- 4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 5. Let engine idle for 1 minute.
- Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-III.
- 7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to ±25%.



"HO2S2 (B1)/(B2)" should be above 0.68 V at least once when the "FUEL INJECTION" is +25%. "HO2S2 (B1)/(B2)" should be below 0.18 V at least once when the "FUEL INJECTION" is -25%.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

3.CHECK HEATED OXYGEN SENSOR 2-I

⋈Without CONSULT-III

- 1. Start engine and warm it up to the normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- Let engine idle for 1 minute.
- 5. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM				
Connector	+	_	Condition	Voltage	
Connector	Terminal	Terminal			
F8	33 [HO2S2 (bank 1) signal] 34 [HO2S2 (bank 2) signal]	35 (Sensor ground)	Revving up to 4,000 rpm under no load at least 10 times	The voltage should be above 0.68 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 4.

4. CHECK HEATED OXYGEN SENSOR 2-II

Α

EC

D

Е

Н

K

Ν

Р

ECM					
Connector	+ -		Condition	Voltage	
	Terminal	Terminal			
F8	33 [HO2S2 (bank 1) signal] 35		Keeping engine at idle for 10 minutes	The voltage should be above 0.68 V at least once during this procedure.	
F8 -	34 [HO2S2 (bank 2) signal]	(Sensor ground)	recepting engine at tale for 10 minutes	The voltage should be below 0.18 V at least once during this procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK HEATED OXYGEN SENSOR 2-III

Check the voltage between ECM harness connector terminals under the following conditions.

ECM						
Connector	+ -		Condition	Voltage		
	Terminal	Terminal				
F8	33 [HO2S2 (bank 1) signal] 35		Coasting from 80 km/h (50 MPH) in D po-	The voltage should be above 0.68 V at least once during this procedure.		
10	34 [HO2S2 (bank 2) signal]	(Sensor ground)	sition	The voltage should be below 0.18 V at least once during this procedure.		

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

6. REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

INFOID:0000000003856583

P0138, P0158 HO2S2


Description

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1 V in richer conditions to 0 V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.




DTC Logic

DTC DETECTION LOGIC

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst (manifold) causes the longer switching time.


MALFUNCTION A

To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during various driving conditions such as fuel cut.



MALFUNCTION B

To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of sensor is sufficiently low during various driving conditions such as fuel cut.



DTC No.	Trouble diagnosis name		DTC detecting condition	Possible cause
	Heated oxygen sensor 2	A)	An excessively high voltage from the sensor is sent to ECM.	Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2
P0138	(bank 1) circuit high voltage	В)	The minimum voltage from the sensor is not reached to the specified voltage.	Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2 Fuel pressure Fuel injector

IVQ25DE. VQ35DE1

DTC No.	Trouble diagnosis name		DTC detecting condition	Possible cause
	Heated oxygen sensor 2	A)	An excessively high voltage from the sensor is sent to ECM.	Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2
P0158	(bank 2) circuit high voltage	В)	The minimum voltage from the sensor is not reached to the specified voltage.	Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2 Fuel pressure Fuel injector
	IFIRMATION PROCI	EDU	RE	
DTC Co			peen previously conducted, always t	urn ignition switch OFF and wait at
asi 10 st	econas beiore conaucii	iiig ti	ie next test.	
	> GO TO 2. DRM DTC CONFIRMAT	ΓΙΟΝ	PROCEDURE FOR MALFUNCTION	NΔ
			e normal operating temperature.	\ /\
. Turn iç . Start e . Check	gnition switch OFF and engine and keep the en and trip DTC.	l wait		n for at least 1 minute under no load.
	OTC detected?		Dro ooduro"	
NO-1 >	> Go to <u>EC-187, "Diag</u> > With CONSULT-III: G	OF	O 3.	
NIO-2 ~	> Without CONSULT-II	II. C.C) TO 5	
.PERFC			PROCEDURE FOR MALFUNCTION	N B
PERFO	results, perform "DT " "DATA MONITOR" mo engine and warm it up to	C W ode v to the	PROCEDURE FOR MALFUNCTION ORK SUPPORT" at a temperature with CONSULT-III. enormal operating temperature. at least 10 seconds.	of 0 to 30 °C (32 to 86 °F).
OTE: or better . Select . Start e . Start e . Start e . Let en . Check	results, perform "DT ""DATA MONITOR" mo engine and warm it up to gnition switch OFF and engine and keep the en igine idle for 1 minute.	TON TO Wode viso the light of the gine	PROCEDURE FOR MALFUNCTION ORK SUPPORT" at a temperature with CONSULT-III. enormal operating temperature. at least 10 seconds. speed between 3,500 and 4,000 rpm andicates more than 70°C (158°F).	of 0 to 30 °C (32 to 86 °F). In for at least 1 minute under no load.
PERFC OTE: or better Select Start e Turn ig Start e Let en Check If not,	results, perform "DT "DATA MONITOR" more engine and warm it up to engine and keep the engine idle for 1 minute. It that "COOLAN TEMP warm up engine and g	TON TO Wode viso the light of the gine	ORK SUPPORT" at a temperature with CONSULT-III. en normal operating temperature. It at least 10 seconds. speed between 3,500 and 4,000 rpm	of 0 to 30 °C (32 to 86 °F). In for at least 1 minute under no load.
PERFC OTE: or better . Select . Start e . Turn iq . Start e . Let en . Check If not, . Open . Select "DTC	results, perform "DT "E "DATA MONITOR" more engine and warm it up to engine and keep the engine idle for 1 minute. It that "COOLAN TEMP warm up engine and gengine hood. "HO2S2 (B1) P1146" WORK SUPPORT" more	rC Wode was to the displaying the di	PROCEDURE FOR MALFUNCTION ORK SUPPORT" at a temperature with CONSULT-III. enormal operating temperature. It at least 10 seconds. It is speed between 3,500 and 4,000 rpm andicates more than 70°C (158°F). In ext step when "COOLAN TEMP/S" DTC P0138) or "HO2S2 (B2) P116 with CONSULT-III.	of 0 to 30 °C (32 to 86 °F). If for at least 1 minute under no load. Indication reaches 70°C (158°F).
DTE: or better Select Start e Turn iq Start e Let en Check If not, Open Select "DTC Follow NOTE	results, perform "DT "DATA MONITOR" morengine and warm it up to gnition switch OFF and engine idle for 1 minute. It that "COOLAN TEMP warm up engine and gengine hood. "HO2S2 (B1) P1146" WORK SUPPORT" more the instruction of CONIC.	CC Wode vote the distribution of the distribut	PROCEDURE FOR MALFUNCTION ORK SUPPORT" at a temperature with CONSULT-III. en normal operating temperature. It at least 10 seconds. speed between 3,500 and 4,000 rpm andicates more than 70°C (158°F). next step when "COOLAN TEMP/S" DTC P0138) or "HO2S2 (B2) P116 with CONSULT-III.	of 0 to 30 °C (32 to 86 °F). If for at least 1 minute under no load. Indication reaches 70°C (158°F).
DTE: or better Select Start 6 Turn iq Start 6 Let en Check If not, Open Select "DTC Follow NOTE	results, perform "DT "DATA MONITOR" morengine and warm it up to gnition switch OFF and engine idle for 1 minute. It that "COOLAN TEMP warm up engine and gengine hood. "HO2S2 (B1) P1146" WORK SUPPORT" more the instruction of CONIC.	CC Wode vote the light of the l	PROCEDURE FOR MALFUNCTION ORK SUPPORT" at a temperature with CONSULT-III. enormal operating temperature. It at least 10 seconds. It is speed between 3,500 and 4,000 rpm andicates more than 70°C (158°F). In ext step when "COOLAN TEMP/S" DTC P0138) or "HO2S2 (B2) P116 with CONSULT-III.	of 0 to 30 °C (32 to 86 °F). If for at least 1 minute under no load. Indication reaches 70°C (158°F).
DERFO OTE: or better Select Start e Turn ig Start e Let en Check If not, Open Select "DTC Follow NOTE It will t Touch	results, perform "DT: "DATA MONITOR" more engine and warm it up to engine and keep the engine idle for 1 minute. It that "COOLAN TEMP warm up engine and gengine hood. "HO2S2 (B1) P1146" WORK SUPPORT" more the instruction of CON: eake at most 10 minute is played on CONSULT	CC Wode vote the light of the l	PROCEDURE FOR MALFUNCTION ORK SUPPORT" at a temperature with CONSULT-III. enormal operating temperature. It at least 10 seconds. It is speed between 3,500 and 4,000 rpm andicates more than 70°C (158°F). In ext step when "COOLAN TEMP/S" DTC P0138) or "HO2S2 (B2) P116 with CONSULT-III. LT-III.	of 0 to 30 °C (32 to 86 °F). If for at least 1 minute under no load. Indication reaches 70°C (158°F).
DERFO OTE: or better . Select . Start e . Turn iq . Start e . Let en . Check If not, . Open . Select "DTC . Follow NOTE It will t 0. Touch /hich is d OK	results, perform "DT " "DATA MONITOR" more engine and warm it up to genition switch OFF and engine idle for 1 minute. It that "COOLAN TEMP warm up engine and gengine hood. " "HO2S2 (B1) P1146" WORK SUPPORT" more the instruction of CONIC Eake at most 10 minute "SELF-DIAG RESULT isplayed on CONSULT > INSPECTION END	CC Wode vote the light of the l	ORK SUPPORT" at a temperature with CONSULT-III. enormal operating temperature. It at least 10 seconds. speed between 3,500 and 4,000 rpm andicates more than 70°C (158°F). next step when "COOLAN TEMP/S" DTC P0138) or "HO2S2 (B2) P116 with CONSULT-III. LT-III.	of 0 to 30 °C (32 to 86 °F). If for at least 1 minute under no load. Indication reaches 70°C (158°F).
PERFO OTE: or better . Select . Start e . Turn iq . Start e . Let en . Check If not, . Open . Select "DTC . Follow NOTE It will t 0. Touch /hich is d OK NG >	results, perform "DT: "DATA MONITOR" more engine and warm it up to engine and keep the engine idle for 1 minute. It that "COOLAN TEMP warm up engine and gengine hood. "HO2S2 (B1) P1146" WORK SUPPORT" more the instruction of CON: eake at most 10 minute is played on CONSULT	CC Wode vote the limit of the l	PROCEDURE FOR MALFUNCTION ORK SUPPORT" at a temperature with CONSULT-III. In normal operating temperature. It at least 10 seconds. It speed between 3,500 and 4,000 rpm andicates more than 70°C (158°F). Inext step when "COOLAN TEMP/S" DTC P0138) or "HO2S2 (B2) P116 with CONSULT-III. LT-III. It "COMPLETED" is displayed. Creen? S Procedure".	of 0 to 30 °C (32 to 86 °F). If for at least 1 minute under no load. Indication reaches 70°C (158°F).
PERFO OTE: or better Select Start e Turn ig Start e Let en Check If not, Open Select "DTC Follow NOTE It will t O. Touch Vhich is d OK NG CON NO	results, perform "DT " "DATA MONITOR" mo engine and warm it up to gnition switch OFF and engine and keep the en gine idle for 1 minute. It that "COOLAN TEMP warm up engine and g engine hood. " "HO2S2 (B1) P1146" WORK SUPPORT" mo to the instruction of CON It is that most 10 minute "SELF-DIAG RESULT isplayed on CONSULT > INSPECTION END > Go to EC-187, "Diag T BE DIAGNOSED>>0	C Wode vote the ligine of to (for ode with SUL) s untage of the light section of the light se	PROCEDURE FOR MALFUNCTION ORK SUPPORT" at a temperature with CONSULT-III. In normal operating temperature. It at least 10 seconds. It speed between 3,500 and 4,000 rpm andicates more than 70°C (158°F). Inext step when "COOLAN TEMP/S" DTC P0138) or "HO2S2 (B2) P116 with CONSULT-III. LT-III. It "COMPLETED" is displayed. Creen? S Procedure".	of 0 to 30 °C (32 to 86 °F). If for at least 1 minute under no load. Indication reaches 70°C (158°F). If it is in the control of the contr

5.PERFORM COMPONENT FUNCTION CHECK FOR MALFUNCTION B

Perform component function check. Refer to EC-186, "Component Function Check". **NOTE:**

< COMPONENT DIAGNOSIS >

Use component function check to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-187, "Diagnosis Procedure".

Component Function Check

INFOID:0000000003856584

1. PERFORM COMPONENT FUNCTION CHECK-I

⋈Without CONSULT-III

- 1. Start engine and warm it up to the normal operating temperature.
- 2. Turn ignition switch OFF and wait at least 10 seconds.
- 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 4. Let engine idle for 1 minute.
- 5. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM					
DTC	Connec-	+	_	Condition	Voltage	
	tor	Terminal Terminal				
P0138	Eo	33 [HO2S2 (bank 1) signal]	35 (Sensor	Revving up to 4,000 rpm under no	The voltage should be below 0.18 V	
P0158	F8	34 [HO2S2 (bank 2) signal]	ground)	load at least 10 times	at least once during this procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.PERFORM COMPONENT FUNCTION CHECK-II

Check the voltage between ECM harness connector terminals under the following conditions.

	ECM							
DTC	Connec-	+	_	Condition	Voltage			
	tor	r Terminal Term		tor Terminal Terminal				
P0138	F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Keeping engine speed at idle for 10	The voltage should be below 0.18 V			
P0158	P0158	34 [HO2S2 (bank 2) signal]	ground)	minutes	at least once during this procedure.			

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 3.

3.PERFORM COMPONENT FUNCTION CHECK-III

Check the voltage between ECM harness connector terminals under the following conditions.

Α

Е

Ν

Р

INFOID:0000000003856585

DTC Co	ECM					
	Connec-	+	-	Condition	Voltage	
	tor	Terminal	Terminal			
P0138	F8	33 [HO2S2 (bank 1) signal] 35		Coasting from 80 km/h (50 MPH) in D	The voltage should be below 0.18 V	
P0158	ГО	34 [HO2S2 (bank 2) signal]	(Sensor ground)	position	at least once during this procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-187, "Diagnosis Procedure".

Diagnosis Procedure

1. INSPECTION START

Confirm the detected malfunction (A or B). Refer to EC-184, "DTC Logic".

Which malfunction is detected?

A >> GO TO 2.

B >> GO TO 9.

2.CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- 2. Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace ground connection.

${f 3.}$ CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Disconnect heated oxygen sensor 2 harness connector.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between heated oxygen sensor 2 (HO2S2) harness connector and ECM harness connector.

DTC		HO2S2		E	CM	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0138	1	F70	1	F8	35	Existed
P0158	2	F71	1	10	33	LAISIEU

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

f 4.CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between HO2S2 harness connector and ECM harness connector.

DTC		HO2S2		Е	Continuity	
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0138	1	F70	4	F8	33	Existed
P0158	2	F71	4	1.0	34	LAISIEU

2. Check the continuity between HO2S2 harness connector or ECM harness connector and ground.

EC-187

DTC	HO2S2			E	:CM	Ground	Continuity	
DIC	Bank	Connector	Terminal Connector Te		Terminal	Giodila	Continuity	
P0138	1	F70	4	F8	33	Ground	Not existed	
P0158	2	F71	4	10	34	Giodila	INOL EXISTED	

Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK HO2S2 CONNECTOR FOR WATER

Check connectors for water.

Water should not exist.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2

Refer to EC-190, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 7.

7.REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

8. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

9. CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace ground connection.

10.clear mixture ratio self-learning value

- Clear the mixture ratio self-learning value. Refer to <u>EC-18</u>, "MIXTURE RATIO SELF-LEARNING VALUE <u>CLEAR</u>: Special Repair Requirement".
- 2. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC P0172 or P0175 detected? Is it difficult to start engine?

YES >> Perform trouble diagnosis for DTC P0172, P0175. Refer to <u>EC-202, "DTC Logic"</u>.

NO >> GO TO 11.

11. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

< COMPONENT DIAGNOSIS >

- Turn ignition switch OFF.
- Disconnect heated oxygen sensor 2 harness connector.
- 3. Disconnect ECM harness connector.
- Check the continuity between HO2S2 harness connector and ECM harness connector.

DTC		HO2S2		E	Continuity	
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0138	1	F70	1	F8	35	Existed
P0158	2	F71	1	10	33	LXISIGU

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

>> GO TO 12. YES

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

12.check ho2s2 input signal circuit for open and short

Check the continuity between HO2S2 harness connector and ECM harness connector.

DTC		HO2S2		E	Continuity	
ыс	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0138	1	F70	4	F8	33	Existed
P0158	2	F71	4	ГО	34	Existed

Check the continuity between HO2S2 harness connector or ECM harness connector and ground.

DTC		HO2S2		ECM		Ground	Continuity	
DIC	Bank	Connector	onnector Terminal Connecto		Terminal	Giodila	Continuity	
P0138	1	F70	4	F8	33	Ground	Not existed	
P0158	2	F71	4	10	34	Sibula	NOT EXISTED	

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 13.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

13. CHECK HEATED OXYGEN SENSOR 2

Refer to EC-190, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 15.

NO >> GO TO 14.

14. REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2.

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

15. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

EC

Α

Е

F

K

M

Р

Component Inspection

INFOID:0000000003856586

1.INSPECTION START

Will CONSULT-III be used?

Will CONSULT-III be used?


YES >> GO TO 2. NO >> GO TO 3.

NO >> GO TO 3.

2.CHECK HEATED OXYGEN SENSOR 2

(P)With CONSULT-III

- 1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-III.
- 2. Start engine and warm it up to the normal operating temperature.
- 3. Turn ignition switch OFF and wait at least 10 seconds.
- 4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 5. Let engine idle for 1 minute.
- Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-III.
- 7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to ±25%.



"HO2S2 (B1)/(B2)" should be above 0.68 V at least once when the "FUEL INJECTION" is +25%. "HO2S2 (B1)/(B2)" should be below 0.18 V at least once when the "FUEL INJECTION" is -25%.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

3. CHECK HEATED OXYGEN SENSOR 2-I

⋈Without CONSULT-III

- 1. Start engine and warm it up to the normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- Let engine idle for 1 minute.
- 5. Check the voltage between ECM harness connector terminals under the following conditions.

ECM					
Connector	+	_	Condition	Voltage	
	Terminal	Terminal			
F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Revving up to 4,000 rpm under no load at	The voltage should be above 0.68 V at least once during this procedure.	
F8	34 [HO2S2 (bank 2) signal]	ground)	least 10 times	The voltage should be below 0.18 V at least once during this procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 4.

4.CHECK HEATED OXYGEN SENSOR 2-II

Α

EC

D

Е

Н

K

Ν

Р

ECM					
Connector	+ -		Condition	Voltage	
	Terminal	Terminal			
F8 -	33 [HO2S2 (bank 1) signal] 35		Keeping engine at idle for 10 minutes	The voltage should be above 0.68 V at least once during this procedure.	
	34 [HO2S2 (bank 2) signal]	(Sensor ground)	Reeping engine at idle for 10 minutes	The voltage should be below 0.18 V at least once during this procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK HEATED OXYGEN SENSOR 2-III

Check the voltage between ECM harness connector terminals under the following conditions.

ECM					
Connector	+	_	Condition	Voltage	
	Terminal	Terminal			
F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Coasting from 80 km/h (50 MPH) in D po-	The voltage should be above 0.68 V at least once during this procedure.	
10	34 [HO2S2 (bank 2) signal]	ground)	sition	The voltage should be below 0.18 V at least once during this procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

6. REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

INFOID:0000000003856588

P0139, P0159 HO2S2


Description

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1 V in richer conditions to 0 V in leaner conditions.


Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



DTC Logic

DTC DETECTION LOGIC

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during various driving conditions such as fuel cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0139	Heated oxygen sensor 2 (bank 1) circuit slow response	It takes more time for the sensor to respond be-	 Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2
P0159	Heated oxygen sensor 2 (bank 2) circuit slow response	tween rich and lean than the specified time.	Fuel pressureFuel injectorIntake air leaks

DTC CONFIRMATION PROCEDURE

1. INSPECTION START

Will CONSULT-III be used?

Will CONSULT-III be used?

YES >> GO TO 2.

NO >> GO TO 5.

2.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

For better results, perform "DTC WORK SUPPORT" at a temperature of 0 to 30 °C (32 to 86 °F).

>> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE

[VQ25DE, VQ35DE] < COMPONENT DIAGNOSIS >

- Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-III.
- Start engine and warm it up to the normal operating temperature. 2.
- Turn ignition switch OFF and wait at least 10 seconds.
- Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 5. Let engine idle for 1 minute.
- Open engine hood.
- 7. Select "HO2S2 (B1) P0139" or "HO2S2 (B2) P0159" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-III.
- Follow the instruction of CONSULT-III.

NOTE:

It will take at most 10 minutes until "COMPLETED" is displayed.

9. Touch "SELF-DIAG RESULTS".

Which is displayed on CONSULT-III screen?

OK >> INSPECTION END

NG >> Go to EC-194, "Diagnosis Procedure".

CAN NOT BE DIAGNOSED>>GO TO 4.

f 4 . PERFORM DTC CONFIRMATION PROCEDURE AGAIN

- Turn ignition switch OFF and leave the vehicle in a cool place (soak the vehicle).
- Perform DTC confirmation procedure again.

>> GO TO 3.

${f 5.}$ PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to EC-193, "Component Function Check".

NOTE:

Use component function check to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-194, "Diagnosis Procedure".

Component Function Check

1.PERFORM COMPONENT FUNCTION CHECK-I

Without CONSULT-III

- Start engine and warm it up to the normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load. 3.
- Let engine idle for 1 minute.
- Check the voltage between ECM harness connector terminals under the following conditions.

	ECM					
DTC	Connec-	+	_	Condition	Voltage	
	tor	Terminal	Terminal			
P0139	F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Revving up to 4,000 rpm under no	A change of voltage should be more than 0.12 V for 1 second during this	(
P0159	10	34 [HO2S2 (bank 2) signal]	ground)	load at least 10 times	procedure.	F

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.PERFORM COMPONENT FUNCTION CHECK-II

Check the voltage between ECM harness connector terminals under the following conditions.

EC-193

EC

Α

D

Е

Н

INFOID:0000000003856589

K

M

N

<	COMPONENT	DIAGN

	ECM					
DTC	Connec-	+	_	Condition	Voltage	
	tor	Terminal	Terminal			
P0139	[HO2S2	33 [HO2S2 (bank 1) signal]	35 (Sensor	Keeping engine at idle for 10 minutes	A change of voltage should be more than 0.12 V for 1 second during this	
P0159	F8	34 [HO2S2 (bank 2) signal]	ground)	Reeping engine at idle for 10 minutes	procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 3.

${f 3.}$ PERFORM COMPONENT FUNCTION CHECK-III

Check the voltage between ECM harness connector terminals under the following conditions.

	ECM					
DTC	Connec-	+ -		Condition	Voltage	
	tor	Terminal	Terminal			
P0139	F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Coasting from 80 km/h (50 MPH) in	A change of voltage should be more than 0.12 V for 1 second during this procedure.	
P0159	F0	34 [HO2S2 (bank 2) signal]	ground)	D position ,		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-194, "Diagnosis Procedure".

Diagnosis Procedure

INFOID:0000000003856590

1. CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CLEAR MIXTURE RATIO SELF-LEARNING VALUE

- Clear the mixture ratio self-learning value. Refer to <u>EC-18</u>, "MIXTURE RATIO SELF-LEARNING VALUE CLEAR: Special Repair Requirement".
- 2. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected? Is it difficult to start engine?

YES >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to EC-198, "DTC Logic".

NO >> GO TO 3.

$3. \mathsf{CHECK} \ \mathsf{HO2S2} \ \mathsf{GROUND} \ \mathsf{CIRCUIT} \ \mathsf{FOR} \ \mathsf{OPEN} \ \mathsf{AND} \ \mathsf{SHORT}$

- Turn ignition switch OFF.
- Disconnect heated oxygen sensor 2 harness connector.
- 3. Disconnect ECM harness connector.
- Check the continuity between heated oxygen sensor 2 (HO2S2) harness connector and ECM harness connector.

DTC		HO2S2		E	Continuity	
DIC	Bank Connector Terminal		Connector	Terminal	Continuity	
P0139	1	F70	1	F8	35	Existed
P0159	2	F71	1	10	33	Existed

EC

Α

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

>> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

f 4.CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between HO2S2 harness connector and ECM harness connector.

DTC		HO2S2		E	Continuity		
DIC	Bank	Bank Connector Terminal		Connector	Terminal	Continuity	
P0139	1	F70	4	F8	33	Existed	
P0159	2	F71	4	ГО	34	EXISTEC	

2. Check the continuity between HO2S2 harness connector or ECM harness connector and ground.

DTC		HO2S2		E	СМ	Ground	Continuity
	Bank	Connector	Terminal	Connector	Terminal	Oround	
P0139	1	F70	4	F8	33	Ground	Not existed
P0159	2	F71	4	10	34		

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to EC-195, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

O.REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

.CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

1.INSPECTION START

Will CONSULT-III be used?

EC-195

D

Е

M

INFOID:0000000003856591

Will CONSULT-III be used?


YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK HEATED OXYGEN SENSOR 2

(P)With CONSULT-III

- 1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-III.
- 2. Start engine and warm it up to the normal operating temperature.
- 3. Turn ignition switch OFF and wait at least 10 seconds.
- 4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 5. Let engine idle for 1 minute.
- Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-III.
- 7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to ±25%.



"HO2S2 (B1)/(B2)" should be above 0.68 V at least once when the "FUEL INJECTION" is +25%. "HO2S2 (B1)/(B2)" should be below 0.18 V at least once when the "FUEL INJECTION" is -25%.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

3. CHECK HEATED OXYGEN SENSOR 2-1

(R) Without CONSULT-III

- 1. Start engine and warm it up to the normal operating temperature.
- 2. Turn ignition switch OFF and wait at least 10 seconds.
- Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 4. Let engine idle for 1 minute.
- 5. Check the voltage between ECM harness connector terminals under the following conditions.

ECM					
Connector	+	_	Condition	Voltage	
Connector	Terminal	Terminal			
F8	33 [HO2S2 (bank 1) signal] 34 [HO2S2 (bank 2) signal]	35 (Sensor ground)	Revving up to 4,000 rpm under no load at least 10 times	The voltage should be above 0.68 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure.	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 4.

f 4.CHECK HEATED OXYGEN SENSOR 2-II

Check the voltage between ECM harness connector terminals under the following conditions.

Α

EC

D

Е

Н

K

Ν

Р

ECM					
Connector	+	_	Condition	The voltage should be above 0.68 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure.	
	Terminal	Terminal			
F8	33 [HO2S2 (bank 1) signal] 34 [HO2S2 (bank 2) signal]	35 (Sensor ground)	Keeping engine at idle for 10 minutes		

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK HEATED OXYGEN SENSOR 2-III

Check the voltage between ECM harness connector terminals under the following conditions.

ECM						
Connector	+	_	Condition	Voltage		
Connector	Terminal	Terminal				
F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Coasting from 80 km/h (50 MPH) in D po-	The voltage should be above 0.68 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure.		
F8 -	34 [HO2S2 (bank 2) signal]	ground)	sition			

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

6. REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

[VQ25DE, VQ35DE]

P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

DTC Logic INFOID:0000000003856592

DTC DETECTION LOGIC

< COMPONENT DIAGNOSIS >

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from A/F sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (the actual mixture ratio is too lean), the ECM judges the condition as the fuel injection system malfunction and illuminates the MI (2 trip detection logic).

Sensor	Input signal to ECM	ECM function	Actuator	
A/F sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injector	

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0171	Fuel injection system too lean (bank 1)	A/F sensor 1	
P0174	Fuel injection system too lean (bank 2)	 Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	 Fuel injector Exhaust gas leaks Incorrect fuel pressure Lack of fuel Mass air flow sensor Incorrect PCV hose connection

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE-I

- Clear the mixture ratio self-learning value. Refer to EC-18, "MIXTURE RATIO SELF-LEARNING VALUE CLEAR: Special Repair Requirement".
- Start engine.

Is it difficult to start engine?

YES >> GO TO 3.

>> GO TO 4. NO

3. RESTART ENGINE

If it is difficult to start engine, the fuel injection system has a malfunction, too.

Crank engine while depressing accelerator pedal.

 When depressing accelerator pedal three-fourths (3/4) or more, the control system does not start the engine. Do not depress accelerator pedal too much.

Does engine start?

YES >> Go to EC-199, "Diagnosis Procedure".

NO >> Check exhaust and intake air leak visually.

f 4 .PERFORM DTC CONFIRMATION PROCEDURE-II

- Keep engine idle for at least 10 minutes.
- 2. Check 1st trip DTC.

Is 1st trip DTC detected?

>> Go to EC-199, "Diagnosis Procedure". YES

NO >> GO TO 5.

P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

5. PERFORM DTC CONFIRMATION PROCEDURE-III

1. Turn ignition switch OFF and wait at least 10 seconds.

Start engine and drive the vehicle under similar conditions to (1st trip) Freeze Frame Data for 10 minutes.
 Refer to the table below.

Hold the accelerator pedal as steady as possible.

Similar conditions to (1st trip) Freeze Frame Data mean that the following conditions should be satisfied at the same time.

Engine speed	Engine speed in the freeze frame data $\pm400~\text{rpm}$		
Vehicle speed	Vehicle speed in the freeze frame data \pm 10 km/h (6 MPH)		
Engine coolant temperature (T) condition	When the freeze frame data shows lower than 70 °C (158 °F), T should be lower than 70 °C (158 °F).		
Engine coolant temperature (1) condition	When the freeze frame data shows higher than or equal to 70 °C (158 °F), T should be higher than or equal to 70 °C (158 °F).		

3. Check 1st trip DTC.

Is 1st trip DTC detected?


YES >> Go to EC-199, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1. CHECK EXHAUST GAS LEAK

Start engine and run it at idle.
 Listen for an exhaust gas leak before three way catalyst (manifold).



Is exhaust gas leak detected?

YES >> Repair or replace malfunctioning part.

NO >> GO TO 2.

2.CHECK FOR INTAKE AIR LEAK

- 1. Listen for an intake air leak after the mass air flow sensor.
- 2. Check PCV hose connection.

Is intake air leak detected?

YES >> Repair or replace malfunctioning part.

NO >> GO TO 3.

3.CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT

Turn ignition switch OFF.

- Disconnect corresponding A/F sensor 1 harness connector.
- 3. Disconnect ECM harness connector.
- 4. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

EC

Α

D

F

INFOID:0000000003856593

Н

J

L

Ν

DTC	A/F sensor 1			E	Continuity		
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity	
P0171	1	F27	1		45		
FUITI	'	1 21	2	F8	49	Existed	
P0174	2	F64	1	10	53	LAISIEU	
P0174	2		2		57		

5. Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

DTC	A/F sensor 1			E	CM	Ground	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Giodila	Continuity
P0171	1	F27	1	F8	45	Ground	Not existed
P0171			2		49		
D0174	2	F64	1		53		
P0174	2		2		57		

6. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4.CHECK FUEL PRESSURE

- 1. Release fuel pressure to zero. Refer to EC-411, "Inspection".
- 2. Install fuel pressure gauge and check fuel pressure. Refer to EC-411. "Inspection".

At idling: Approximately 350 kPa (3.50 bar, 3.57 kg/cm², 51 psi)

Is the inspection result normal?

YES >> GO TO 6. NO >> GO TO 5.

DETECT MALFUNCTIONING PART

Check fuel hoses and fuel tubes for clogging.

Is the inspection result normal?

YES >> Replace "fuel filter and fuel pump assembly".

NO >> Repair or replace malfunctioning part.

6.CHECK MASS AIR FLOW SENSOR

(P)With CONSULT-III

- 1. Install all removed parts.
- Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-III. For specification, refer to <u>EC-414</u>, "Mass Air Flow Sensor".

With GST

- 1. Install all removed parts.
- Check mass air flow sensor signal in Service \$01 with GST. For specification, refer to <u>EC-414</u>, "Mass Air Flow Sensor".

Is the measurement value within the specification?

YES >> GO TO 7.

NO >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or ground. Refer to <u>EC-150</u>, "<u>Diagnosis Procedure</u>".

7. CHECK FUNCTION OF FUEL INJECTOR

(P) With CONSULT-III

- Start engine.
- Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-III.

P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

3. Check that each circuit produces a momentary engine speed drop.


With GST

- 1. Let engine idle.
- 2. Listen to each fuel injector operating sound.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Perform trouble diagnosis for FUEL INJECTOR, refer to <u>EC-334, "Diagnosis Procedure"</u>.



8. CHECK FUEL INJECTOR

- 1. Turn ignition switch OFF.
- 2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
- 3. Disconnect all fuel injector harness connectors.
- 4. Remove fuel tube assembly. Refer to <u>EM-44</u>, "<u>Removal and Installation</u>". Keep fuel hose and all fuel injectors connected to fuel tube.
- 5. For DTC P0171, reconnect fuel injector harness connectors on bank 1. For DTC P0174, reconnect fuel injector harness connectors on bank 2.
- 6. Disconnect all ignition coil harness connectors.
- 7. Prepare pans or saucers under each fuel injector.
- 8. Crank engine for about 3 seconds.

For DTC P0171, check that fuel sprays out from fuel injectors on bank 1.

For DTC P0174, check that fuel sprays out from fuel injectors on bank 2.

Fuel should be sprayed evenly for each fuel injector.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace fuel injectors from which fuel does not spray out. Always replace O-ring with new ones.

9. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

EC

Α

_

D

Е

F

Н

K

L

M

N

Р

[VQ25DE, VQ35DE]

P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

DTC Logic

DTC DETECTION LOGIC

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from A/F sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (the actual mixture ratio is too rich), the ECM judges the condition as the fuel injection system malfunction and illuminates the MI (2 trip detection logic).

Sensor	Input signal to ECM	ECM function	Actuator	
A/F sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injector	

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0172	Fuel injection system too rich (bank 1)	Fuel injection system does not operate properly.	A/F sensor 1 Fuel injector
P0175	Fuel injection system too rich (bank 2)	The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.)	Exhaust gas leaksIncorrect fuel pressureMass air flow sensor

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE-I

- Clear the mixture ratio self-learning value. Refer to <u>EC-18</u>, "MIXTURE RATIO SELF-LEARNING VALUE CLEAR: Special Repair Requirement".
- 2. Start engine.

Is it difficult to start engine?

YES >> GO TO 3.

NO >> GO TO 4.

3. RESTART ENGINE

If it is difficult to start engine, the fuel injection system has a malfunction, too.

Crank engine while depressing accelerator pedal.

NO IE:

 When depressing accelerator pedal three-fourths (3/4) or more, the control system does not start the engine. Do not depress accelerator pedal too much.

Does engine start?

YES >> Go to EC-203, "Diagnosis Procedure".

NO >> Remove spark plugs and check for fouling, etc.

4. PERFORM DTC CONFIRMATION PROCEDURE-II

- 1. Keep engine idle for at least 10 minutes.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-203, "Diagnosis Procedure".

NO >> GO TO 5.

5. PERFORM DTC CONFIRMATION PROCEDURE-III

1. Turn ignition switch OFF and wait at least 10 seconds.

P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Α

EC

D

Е

Н

K

M

Ν

Р

INFOID:0000000003856595

2. Start engine and drive the vehicle under similar conditions to (1st trip) Freeze Frame Data for 10 minutes. Refer to the table below.

Hold the accelerator pedal as steady as possible.

Similar conditions to (1st trip) Freeze Frame Data mean that the following conditions should be satisfied at the same time.

Engine speed	Engine speed in the freeze frame data $\pm400~\text{rpm}$
Vehicle speed in the freeze frame data \pm 10 km/h (6 MPH)	
Engine coolant temperature (T) condition	When the freeze frame data shows lower than 70 °C (158 °F), T should be lower than 70 °C (158 °F).
Engine coolant temperature (1) condition	When the freeze frame data shows higher than or equal to 70 °C (158 °F), T should be higher than or equal to 70 °C (158 °F).

3. Check 1st trip DTC.

Is 1st trip DTC detected?


YES >> Go to EC-203, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1. CHECK EXHAUST GAS LEAK

- Start engine and run it at idle.
- Listen for an exhaust gas leak before three way catalyst (manifold).



Is exhaust gas leak detected?

YES >> Repair or replace malfunctioning part.

NO >> GO TO 2.

2.CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

Is intake air leak detected?

YES >> Repair or replace malfunctioning part.

NO >> GO TO 3.

3.check a/f sensor 1 input signal circuit

- Turn ignition switch OFF.
- Disconnect corresponding A/F sensor 1 harness connector.
- 3. Disconnect ECM harness connector.
- 4. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

DTC	A/F sensor 1			E	Continuity	
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0172	1	F27	1		45	
P0172	1	Γ21	2	F8	49	Existed
P0175	2	F64	1	ГО	53	Existed
	2	1 04	2		57	

Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

EC-203

DTC		A/F sensor 1		ECM		Ground	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Giodila	Continuity
P0172	1	F27	1		45		
FUITZ	•	F64 -	2	F8	49	Ground	Not existed
P0175	2		1	10	53	Giodila	NOI EXISIEU
F0173	2	1 04	2		57		

6. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4.CHECK FUEL PRESSURE

- 1. Release fuel pressure to zero. Refer to EC-411, "Inspection".
- 2. Install fuel pressure gauge and check fuel pressure. Refer to EC-411, "Inspection".

At idling: Approximately 350 kPa (3.50 bar, 3.57 kg/cm², 51 psi)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace "fuel filter and fuel pump assembly".

${f 5.}$ CHECK MASS AIR FLOW SENSOR

(II) With CONSULT-III

- Install all removed parts.
- Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-III. For specification, refer to <u>EC-414, "Mass Air Flow Sensor"</u>.

With GST

- 1. Install all removed parts.
- Check mass air flow sensor signal in "Service \$01" with GST. For specification, refer to <u>EC-414, "Mass Air Flow Sensor"</u>.

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or ground. Refer to EC-150, "Diagnosis Procedure".

6.CHECK FUNCTION OF FUEL INJECTOR

(II) With CONSULT-III

- 1. Start engine.
- 2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-III.
- 3. Check that each circuit produces a momentary engine speed drop.


With GST

- 1. Let engine idle.
- 2. Listen to each fuel injector operating sound.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Perform trouble diagnosis for FUEL INJECTOR, refer to <u>EC-334, "Diagnosis Procedure"</u>.



7. CHECK FUEL INJECTOR

Remove fuel injector assembly. Refer to <u>EM-44, "Removal and Installation"</u>.

P0172, P0175 FUEL INJECTION SYSTEM FUNCTION [VQ25DE, VQ35DE] < COMPONENT DIAGNOSIS > Keep fuel hose and all fuel injectors connected to fuel tube. Confirm that the engine is cooled down and there are no fire hazards near the vehicle. Α 3. Disconnect all fuel injector harness connectors. 4. Disconnect all ignition coil harness connectors. 5. Prepare pans or saucers under each fuel injector. EC 6. Crank engine for about 3 seconds. Check the fuel does not drip from fuel injector. Is the inspection result normal? YES >> GO TO 8. NO >> Replace the fuel injectors from which fuel is dripping. Always replace O-ring with new one. 8. CHECK INTERMITTENT INCIDENT D Refer to GI-35, "Intermittent Incident". Е >> INSPECTION END F Н K L M Ν


Р

P0222, P0223 TP SENSOR

Description INFOID:0000000003857789

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has two sensors. These sensors are a kind of potentiometer which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and controls the throttle valve opening angle in response to driving conditions via the throttle control motor.



DTC Logic

INFOID:0000000003856613

DTC DETECTION LOGIC

NOTE:

If DTC P0222 or P0223 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222	Throttle position sensor 1 circuit low input	An excessively low voltage from the TP sensor 1 is sent to ECM.	Harness or connectors (TP sensor 1 circuit is open or shorted.)
P0223	Throttle position sensor 1 circuit high input	An excessively high voltage from the TP sensor 1 is sent to ECM.	Electric throttle control actuator (TP sensor 1)

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for 1 second.
- Check DTC.

Is DTC detected?

YES >> Go to EC-206, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856614

CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.check throttle position sensor 1 power supply circuit-i

- Disconnect electric throttle control actuator harness connector.
- Turn ignition switch ON.

[VQ25DE, VQ35DE]

3. Check the voltage between electric throttle control actuator harness connector and ground.

Electric throttle	control actuator	Ground	Voltage	
Connector	Terminal	Glound		
F29	1	Ground	Approx. 5 V	

EC

Е

Н

M

Α

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

3.check throttle position sensor 1 ground circuit for open and short

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between electric throttle control actuator and ECM harness connector.

Electric throttle	control actuator	E	ECM	
Connector	Terminal	Connector	Terminal	Continuity
F29	4	F8	36	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

f 4.CHECK THROTTLE POSITION SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between electric throttle control actuator and ECM harness connector.

Electric throttle	Electric throttle control actuator		СМ	Continuity
Connector	Terminal	Connector	Terminal	Continuity
F29	2	F8	37	Existed

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5.CHECK THROTTLE POSITION SENSOR

Refer to EC-207, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6.REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- Refer to <u>EC-208</u>, "Special Repair Requirement".

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

1. CHECK THROTTLE POSITION SENSOR

INFOID:0000000003857982

EC-207

< COMPONENT DIAGNOSIS >

- Turn ignition switch OFF.
- Reconnect all harness connectors disconnected.
- 3. Perform EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".
- 4. Turn ignition switch ON.
- 5. Selector lever position is D.
- 6. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM					
Connector + -		Condition		Voltage		
Connector	Terminal	Terminal				
	37 (TP sensor 1	36 (Sensor ground)	signal)		Fully released	More than 0.36 V
F8	signal)			Accelerator pedal	Fully depressed	Less than 4.75 V
го	38 (TP sensor 2		Accelerator pedar	Fully released	Less than 4.75 V	
	signal)	ignal)		Fully depressed	More than 0.36 V	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.replace electric throttle control actuator

- 1. Replace electric throttle control actuator.
- 2. Go to EC-162, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

INFOID:0000000003857985

1. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement"

>> GO TO 2.

2. PERFORM IDLE AIR VOLUME LEARNING

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement"

>> END

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P0300, P0301, P0302, P0303, P0304, P0305, P0306 MISFIRE

DTC Logic INFOID:0000000003856617

DTC DETECTION LOGIC

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the crankshaft position (CKP) sensor (POS) signal to vary, ECM can determine that a misfire is occurring.

Sensor	Input signal to ECM	ECM function
Crankshaft position sensor (POS)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

1. One Trip Detection Logic (Three Way Catalyst Damage)

On the 1st trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MI will blink.

When a misfire condition occurs, the ECM monitors the CKP sensor signal every 200 engine revolutions for a change.

When the misfire condition decreases to a level that will not damage the TWC, the MI will turn off. If another misfire condition occurs that can damage the TWC on a second trip, the MI will blink. When the misfire condition decreases to a level that will not damage the TWC, the MI will remain on.

If another misfire condition occurs that can damage the TWC, the MI will begin to blink again.

Two Trip Detection Logic (Exhaust quality deterioration)

For misfire conditions that will not damage the TWC (but will affect vehicle emissions), the MI will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor signal every 1,000 engine revolutions.

A misfire malfunction can be detected in any one cylinder or in multiple cylinders.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0300	Multiple cylinder misfires detected	Multiple cylinder misfire.	Improper spark plug
P0301	No.1 cylinder misfire detected	No. 1 cylinder misfires.	Insufficient compression Incorrect fuel pressure
P0302	No. 2 cylinder misfire detected	No. 2 cylinder misfires.	The fuel injector circuit is open or shorted
P0303	No. 3 cylinder misfire detected	No. 3 cylinder misfires.	Fuel injector Intake air leak
P0304	No. 4 cylinder misfire detected	No. 4 cylinder misfires.	The ignition signal circuit is open or shorted
P0305	No. 5 cylinder misfire detected	No. 5 cylinder misfires.	Lack of fuel Signal plate
P0306	No. 6 cylinder misfire detected	No. 6 cylinder misfires.	A/F sensor 1 Incorrect PCV hose connection

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE-I

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- Restart engine and let it idle for about 15 minutes.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-210. "Diagnosis Procedure".

NO >> GO TO 3.

3.PERFORM DTC CONFIRMATION PROCEDURE-II

Turn ignition switch OFF and wait at least 10 seconds.

EC

Α

D

Е

F

Н

Ν

Р

P0300, P0301, P0302, P0303, P0304, P0305, P0306 MISFIRE

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

2. Start engine and drive the vehicle under similar conditions to (1st trip) Freeze Frame Data for a certain time. Refer to the table below.

Hold the accelerator pedal as steady as possible.

Similar conditions to (1st trip) Freeze Frame Data mean that the following conditions should be satisfied at the same time.

CAUTION:

Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws when driving.

Engine speed in the freeze frame data \pm 400 rpm		
Vehicle speed in the freeze frame data ± 10 km/h (6 MPH)		
Engine coolant temperature (T) condition	When the freeze frame data shows lower than 70 °C (158 °F), T should be lower than 70 °C (158 °F).	
	When the freeze frame data shows higher than or equal to 70 °C (158 °F), T should be higher than or equal to 70 °C (158 °F).	

Driving time varies according to the engine speed in the freeze frame data.

Engine speed	Time		
Around 1,000 rpm	Approximately 10 minutes		
Around 2,000 rpm	Approximately 5 minutes		
More than 3,000 rpm	Approximately 3.5 minutes		

3. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-210, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856618

1. CHECK FOR INTAKE AIR LEAK AND PCV HOSE

- 1. Start engine and run it at idle speed.
- Listen for the sound of the intake air leak.
- 3. Check PCV hose connection.

Is intake air leak detected?

YES >> Discover air leak location and repair.

NO >> GO TO 2.

2. CHECK FOR EXHAUST SYSTEM CLOGGING

Stop engine and visually check exhaust tube, three way catalyst and muffler for dents.

Is the inspection result normal?

YES-1 >> With CONSULT-III: GO TO 3.

YES-2 >> Without CONSULT-III: GO TO 4.

NO >> Repair or replace malfunctioning part.

3.PERFORM POWER BALANCE TEST

(II) With CONSULT-III

- Start engine.
- 2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-III.
- 3. Check that each circuit produces a momentary engine speed drop.

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 4.

4. CHECK FUNCTION OF FUEL INJECTOR

1. Start engine and let it idle.

P0300, P0301, P0302, P0303, P0304, P0305, P0306 MISFIRE

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]


Listen to each fuel injector operation.

Clicking sound should be heard.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Perform trouble diagnosis for FUEL INJECTOR, refer to EC-334. "Diagnosis Procedure".



${f 5.}$ CHECK FUNCTION OF IGNITION COIL-I

Perform the following procedure in a place with no combustible objects and good ventilation.

- Turn ignition switch OFF.
- Remove fuel pump fuse in IPDM E/R to release fuel pressure.

NOTE:


Do not use CONSULT-III to release fuel pressure, or fuel pressure applies again during the following procedure.

- Start engine.
- 4. After engine stalls, crank it 2 or 3 times to release all fuel pressure.
- Turn ignition switch OFF.
- 6. Remove all ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
- 7. Remove ignition coil and spark plug of the cylinder to be checked.
- 8. Crank engine for 5 seconds or more to remove combustion gas in the cylinder.
- 9. Connect spark plug and harness connector to ignition coil.
- 10. Fix ignition coil using a rope etc. with gap of 13 17 mm (0.52 -0.66 in) between the edge of the spark plug and grounded metal portion as shown in the figure.
- 11. Crank engine for about 3 seconds, and check whether spark is generated between the spark plug and the grounded metal por-

Spark should be generated.

CAUTION:

 Never place to the spark plug and the ignition coil within 50 cm (19.7 in) each other. Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20 kV or more.



It might damage the ignition coil if the gap of more than 17 mm (0.66 in) is made.

When the gap is less than 13 mm (0.52 in), a spark might be generated even if the coil is a malfunctioning.

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 6.

6. CHECK FUNCTION OF IGNITION COIL-II

- Turn ignition switch OFF.
- Disconnect spark plug and connect a non-malfunctioning spark plug.
- Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded metal portion.

Spark should be generated.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Check ignition coil, power transistor and their circuits. Refer to EC-341, "Diagnosis Procedure".

13 - 17 mm (0.52-0.66 in) Grounded metal portion (Cylinder head, cylinder block, etc.)

Α

EC

D

Н

M

Ν

< COMPONENT DIAGNOSIS >


7.CHECK SPARK PLUG

Check the initial spark plug for fouling, etc.

Is the inspection result normal?

YES >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to EM-136, "Spark Plug".

NO >> Repair or clean spark plug. Then GO TO 8.



[VQ25DE, VQ35DE]

8. CHECK FUNCTION OF IGNITION COIL-III

- 1. Reconnect the initial spark plugs.
- 2. Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded portion.

Spark should be generated.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to EM-136, "Spark Plug".

9. CHECK COMPRESSION PRESSURE

Check compression pressure. Refer to EM-22, "Inspection".

Is the inspection result normal?

YES >> GO TO 10.

NO >> Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

10. CHECK FUEL PRESSURE

- 1. Install all removed parts.
- Release fuel pressure to zero. Refer to <u>EC-411, "Inspection"</u>.
- 3. Install fuel pressure gauge and check fuel pressure. Refer to EC-411, "Inspection".

At idle: Approximately 350 kPa (3.50 bar, 3.57 kg/cm², 51 psi)

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 11.

11. DETECT MALFUNCTIONING PART

Check fuel hoses and fuel tubes for clogging.

Is the inspection result normal?

YES >> Replace "fuel filter and fuel pump assembly".

NO >> Repair or replace malfunctioning part.

12. CHECK IGNITION TIMING

Check idle speed and ignition timing.

For procedure, refer to EC-11, "BASIC INSPECTION: Special Repair Requirement".

For specification, refer to EC-414, "Idle Speed" and EC-414, "Ignition Timing".

Is the inspection result normal?

YES >> GO TO 13.

NO >> Follow the EC-11, "BASIC INSPECTION: Special Repair Requirement".

13.check a/f sensor 1 input signal circuit

Turn ignition switch OFF.

P0300, P0301, P0302, P0303, P0304, P0305, P0306 MISFIRE

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Α

EC

D

Е

M

Ν

- 2. Disconnect corresponding A/F sensor 1 harness connector.
- 3. Disconnect ECM harness connector.
- 4. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

A/F sensor 1			E	Continuity		
Bank	Connector	Terminal	Connector	Terminal	Continuity	
1	1 F27	1	F8	45		
ı		2		49	Existed	
	2 F64	FC4	1	ГО	53	EXISIEU
2		2		57		

5. Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

	A/F sensor 1		A/F sensor 1 ECM		ECM		Ground	Continuity
Bank	Connector	Terminal	Connector	Terminal	Giodila	Continuity		
	1 F27 2 F64	1		45				
Į.		Γ21	2	F8	49	Ground	Not existed	
		1	го	53	Ground	Not existed		
2		2		57				

6. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

14. CHECK A/F SENSOR 1 HEATER

Refer to EC-142, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 15.

NO >> Replace (malfunctioning) A/F sensor 1.

15. CHECK MASS AIR FLOW SENSOR

(P)With CONSULT-III

- 1. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-III.
- For specification, refer to <u>EC-414</u>, "Mass Air Flow Sensor".

- 1. Check mass air flow sensor signal in Service \$01 with GST.
- 2. For specification, refer to EC-414, "Mass Air Flow Sensor".

Is the measurement value within the specification?

YES >> GO TO 16.

NO >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or ground. Refer to EC-150, "Diagnosis Procedure".

16. CHECK SYMPTOM TABLE

Check items on the rough idle symptom in EC-400, "Symptom Table".

Is the inspection result normal?

YES >> GO TO 17.

NO >> Repair or replace malfunctioning part.

17.ERASE THE 1ST TRIP DTC

Some tests may cause a 1st trip DTC to be set.

Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to <u>EC-102</u>, "<u>Diagnosis Description</u>".

>> GO TO 18.

P0300, P0301, P0302, P0303, P0304, P0305, P0306 MISFIRE

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

18.CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

[VQ25DE, VQ35DE]

INFOID:0000000003856620

INFOID:000000000385662:

P0327, P0328, P0332, P0333 KS

Description INFOID:0000000038556619

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.

а

EC

D

F

Н

Ν

Α

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name DTC detected condition		Possible cause
P0327	Knock sensor (bank 1) circuit low input	An excessively low voltage from the sensor is sent to ECM.	
P0328	Knock sensor (bank 1) circuit high input	An excessively high voltage from the sensor is sent to ECM.	Harness or connectors (The sensor circuit is open or shorted.)
P0332	Knock sensor (bank 2) circuit low input	An excessively low voltage from the sensor is sent to ECM.	Knock sensor
P0333	Knock sensor (bank 2) circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- 1. Start engine and run it for at least 5 seconds at idle speed.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-215, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1. CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- 2. Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK KNOCK SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- Disconnect knock sensor harness connector and ECM harness connector.
- Check the continuity between knock sensor harness connector and ECM harness connector.

EC-215

INFOID:0000000003856622

DTC	Knock sensor			ECM		Continuity	
ыс	Bank	Connector	Terminal	Connector	Terminal	Continuity	
P0327, P0328	1	F201	2	F8	67	Existed	
P0332, P0333	2	F202	2	- FO 07	01	LAISIEU	

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4. NO >> GO TO 3.

3.DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F204, F91 (VQ25DE engine)
- Harness connectors F200, F78 (VQ35DE engine)
- Harness for open or short between knock sensor and ECM

>> Repair open circuit, short to ground or short to power in harness or connectors.

4. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between knock sensor harness connector and ECM harness connector.

DTC	Knock sensor			ECM		Continuity	
ыс	Bank	Connector	Terminal	Connector	Terminal	Continuity	
P0327, P0328	1	F201	1	F8	61	Existed	
P0332, P0333	2	F202	1	10	62	LXISIEU	

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 6. NO >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F204, F91 (VQ25DE engine)
- Harness connectors F200, F78 (VQ35DE engine)
- Harness for open or short between knock sensor and ECM

>> Repair open circuit, short to ground or short to power in harness or connectors.

6. CHECK KNOCK SENSOR

Refer to EC-216, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace malfunctioning knock sensor.

7. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

1. CHECK KNOCK SENSOR

- 1. Turn ignition switch OFF.
- Disconnect knock sensor harness connector.

P0327, P0328, P0332, P0333 KS

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Check resistance between knock sensor terminal as per the following.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 M Ω .

-	Terminals	Resistance
	1 and 2	Approx. 532 - 588 kΩ [at 20°C (68°F)]

CAUTION:

Never use any knock sensors that have been dropped or physically damaged. Use only new ones.

Is the inspection result normal?

>> INSPECTION END YES

NO >> Replace malfunctioning knock sensor. EC

Α

D

Е

F

G

Н

J

K

L

M

Ν

0

P0335 CKP SENSOR (POS)

Description INFOID.000000003856623

The crankshaft position sensor (POS) is located on the oil pan facing the gear teeth (cogs) of the signal plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet and Hall IC.


When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.


The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

ECM receives the signals as shown in the figure.





DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335	Crankshaft position sensor (POS) circuit	 The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking. The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running. The crankshaft position sensor (POS) signal is not in the normal pattern during engine running. 	Harness or connectors [CKP sensor (POS) circuit is open or shorted.] (APP sensor 2 circuit is shorted.) (Refrigerant pressure sensor circuit is shorted.) Crankshaft position sensor (POS) Accelerator pedal position sensor Refrigerant pressure sensor Signal plate

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V with ignition switch ON.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for at least 5 seconds.
 If engine does not start, crank engine for at least 2 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

YES >> Go to EC-219, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856625

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.check crankshaft position (ckp) sensor (pos) power supply circuit-i

- Disconnect crankshaft position (CKP) sensor (POS) harness connector.
- Turn ignition switch ON.
- Check the voltage between CKP sensor (POS) harness connector and ground.

CKP sen	sor (POS)	Ground	Voltage (V)	
Connector	Connector Terminal		voltage (v)	
F20	1	Ground	Approx. 5	

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 3.

3.check crankshaft position (ckp) sensor (pos) power supply circuit-ii

- Turn ignition switch ON.
- Disconnect ECM harness connector. 2.
- Check the continuity between CKP sensor (POS) harness connector and ECM harness connector.

CKP sen	sor (POS)	E	CM	Continuity	
Connector	Terminal	Connector Terminal		Continuity	
F20	1	F8	76	Existed	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit.

f 4.CHECK SENSOR POWER SUPPLY CIRCUIT

Check harness for short to power and short to ground, between the following terminals.

EC	M	Sensor		
Connector	Terminal	Name	Connector	Terminal
F8	72	Refrigerant pressure sensor	E300	1
го	76	CKP sensor (POS)	F20	1
E16	87	APP sensor	E110	5

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair short to ground or short to power in harness or connectors.

${f 5.}$ CHECK REFRIGERANT PRESSURE SENSOR

Refer to EC-348, "Diagnosis Procedure".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace malfunctioning components.

EC-219

EC

Α

D

Е

F

Н

N

6. CHECK APP SENSOR

Refer to EC-306, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 7.

7. REPLACE ACCELERATOR PEDAL ASSEMBLY

- 1. Replace accelerator pedal assembly.
- 2. Refer to EC-306, "Special Repair Requirement".

>> INSPECTION END

8. CHECK CKP SENSOR (POS) GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between CKP sensor (POS) harness connector and ECM harness connector.

CKP sen	sor (POS)	E	Continuity	
Connector	Terminal	Connector Terminal		
F20	2	F8	60	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

9.CHECK CKP SENSOR (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between CKP sensor (POS) harness connector and ECM harness connector.

CKP sensor (POS)		E	Continuity		
Connector	Terminal	Connector Terminal		Continuity	
F20	3	F8	65	Existed	

Continuity should exist.

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

10.CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to EC-221, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 11.

NO >> Replace crankshaft position sensor (POS).

11. CHECK GEAR TOOTH

Visually check for chipping signal plate gear tooth.

Is the inspection result normal?

YES >> GO TO 12.

NO >> Replace the signal plate.

12. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003856626

Α

EC

D

Е


${\bf 1.} {\sf CHECK} \; {\sf CRANKSHAFT} \; {\sf POSITION} \; {\sf SENSOR} \; ({\sf POS}) {\sf -I}$

- 1. Loosen the fixing bolt of the sensor.
- 2. Disconnect crankshaft position sensor (POS) harness connector.
- 3. Remove the sensor.
- 4. Visually check the sensor for chipping.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace crankshaft position sensor (POS)



2.CHECK CRANKSHAFT POSITION SENSOR (POS)-II

Check resistance crankshaft position sensor (POS) terminals as per the following.

Terminal No. (Polarity)	Resistance
1 (+) - 2 (-)	
1 (+) - 3 (-)	Except 0 or ∞Ω [at 25°C (77°F)]
2 (+) - 3 (-)	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace crankshaft position sensor (POS)

Н

K

L

M

Ν

0

P0340, P0345 CMP SENSOR (PHASE)

Description

The camshaft position sensor (PHASE) senses the retraction of camshaft (INT) to identify a particular cylinder. The camshaft position sensor (PHASE) senses the piston position.

When the crankshaft position sensor (POS) system becomes inoperative, the camshaft position sensor (PHASE) provides various controls of engine parts instead, utilizing timing of cylinder identification signals.


The sensor consists of a permanent magnet and Hall IC.


When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

ECM receives the signals as shown in the figure.





DTC Logic

DTC DETECTION LOGIC

NOTE:

If DTC P0340 or P0345 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0340	Camshaft position sensor (PHASE) (bank 1) circuit		Harness or connectors (The sensor circuit is open or shorted) Camshaft position sensor (PHASE)
P0345	Camshaft position sensor (PHASE) (bank 2) circuit	 The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking. The cylinder No. signal is not sent to ECM during engine running. The cylinder No. signal is not in the normal pattern during engine running. 	Camshaft (INT) Starter motor [VQ25DE engine (Refer to STR-5)] Starter motor [VQ35DE engine (Refer to STR-6)] Starting system circuit [VQ25DE engine (Refer to STR-5.)] Starting system circuit [VQ35DE engine (Refer to STR-6.)] Dead (Weak) battery

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V with ignition switch ON.

P0340, P0345 CMP SENSOR (PHASE)

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

>> GO TO 2.

2.perform dtc confirmation procedure-i

Start engine and let it idle for at least 5 seconds.

If engine does not start, crank engine for at least 2 seconds.

Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-223, "Diagnosis Procedure".

NO >> GO TO 3.

3.PERFORM DTC CONFIRMATION PROCEDURE-I

Maintaining engine speed at more than 800 rpm for at least 5 seconds.

2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-223, "Diagnosis Procedure".

>> INSPECTION END NO

Diagnosis Procedure

CHECK STARTING SYSTEM

Turn ignition switch to START position.

Does the engine turn over? Does the starter motor operate?

YES >> GO TO 2.

NO >> Check starting system. (Refer to STR-2, "Work Flow".)

2. CHECK GROUND CONNECTION

Turn ignition switch OFF.

Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace ground connection.

3.check camshaft position (cmp) sensor (phase) power supply circuit

- Disconnect camshaft position (CMP) sensor (PHASE) harness connector.
- Turn ignition switch ON.
- Check the voltage between CMP sensor (PHASE) harness connector and ground

DTC	CMF	P sensor (PH	Ground	Voltage (V)	
ыс	Bank	Connector	Terminal	Ground	voltage (v)
P0340	1	F26	1	Ground	Approx. 5
P0345	2	F69	1	Giodila	Αρρίοχ. 5

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

f 4.CHECK CMP SENSOR (PHASE) GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check the continuity between CMP sensor (PHASE) harness connector and ECM harness connector.

DTC	CMP sensor (PHASE)			E	CM	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0340	1	F26	2	F8	64	Existed
P0345	2	F69	2	1.0	68	LAISIEU

Also check harness for short to ground and short to power.

Α

EC

Е

INFOID:0000000003856629

Н

N

< COMPONENT DIAGNOSIS > Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5.CHECK CMP SENSOR (PHASE) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between CMP sensor (PHASE) harness connector and ECM harness connector.

DTC	CMP sensor (PHASE)			EC	CM	Continuity
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P0340	1	F26	3	F8	70	Existed
P0345	2	F69	3	10	69	LXISIEU

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

6.CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to EC-224, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace malfunctioning camshaft position sensor (PHASE).

7.CHECK CAMSHAFT (INT)


Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- · Chipping signal plate of camshaft rear end

Is the inspection result normal?

YES >> GO TO 8.

NO >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



8. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003856630

1. CHECK CAMSHAFT POSITION SENSOR (PHASE)-I

- 1. Turn ignition switch OFF.
- 2. Loosen the fixing bolt of the sensor.
- 3. Disconnect camshaft position sensor (PHASE) harness connector.
- 4. Remove the sensor.

P0340, P0345 CMP SENSOR (PHASE)

< COMPONENT DIAGNOSIS >


[VQ25DE, VQ35DE]

5. Visually check the sensor for chipping.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace malfunctioning camshaft position sensor (PHASE).



$2. {\sf CHECK\ CAMSHAFT\ POSITION\ SENSOR\ (PHASE)-II}$

Check resistance camshaft position sensor (PHASE) terminals as per the following.

Terminal No. (Polarity)	Resistance
1 (+) - 2 (-)	
1 (+) - 3 (-)	Except 0 or ∞Ω [at 25°C (77°F)]
2 (+) - 3 (-)	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace malfunctioning camshaft position sensor (PHASE).

Α

EC

С

D

Е

F

Н

J

Κ

L

M

Ν

0

P0420, P0430 THREE WAY CATALYST FUNCTION


DTC Logic

DTC DETECTION LOGIC

The ECM monitors the switching frequency ratio of air fuel ratio (A/F) sensor 1 and heated oxygen sensor 2.

A three way catalyst (manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of A/F sensor 1 and heated oxygen sensor 2 approaches a specified limit value, the three way catalyst (manifold) malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0420	Catalyst system efficiency below threshold (bank 1)	Three way catalyst (manifold) does not operate properly.	Intake air leaks
P0430	Catalyst system efficien- cy below threshold (bank 2)	-	Fuel injectorFuel injector leaksSpark plugImproper ignition timing

DTC CONFIRMATION PROCEDURE

1. INSPECTION START

Will CONSULT-III be used?

Will CONSULT-III be used?

YES >> GO TO 2.

NO >> GO TO 7.

2.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Do not hold engine speed for more than the specified minutes below.

>> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-I

(P)With CONSULT-III

- Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-III.
- 2. Start engine and warm it up to the normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- 4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 5. Let engine idle for 1 minute.
- 6. Check that "COOLAN TEMP/S" indicates more than 70°C (158°F). If not, warm up engine and go to next step when "COOLAN TEMP/S" indication reaches to 70°C (158°F).
- Open engine hood.
- 8. Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT-III.
- Rev engine between 2,000 and 3,000 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely.
- 10. Check the indication of "CATALYST".

Which is displayed on CONSULT-III screen?

P0420, P0430 THREE WAY CATALYST FUNCTION

[VQ25DE, VQ35DE] < COMPONENT DIAGNOSIS >

CMPLT>> GO TO 6. INCMP >> GO TO 4.

4. PERFORM DTC CONFIRMATION PROCEDURE-II

Wait 5 seconds at idle.

Rev engine between 2,000 and 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes).

Does the indication change to "CMPLT"?

YES >> GO TO 6. NO >> GO TO 5.

${f 5.}$ PERFORM DTC CONFIRMATION PROCEDURE AGAIN

- Stop engine and cool it down to less than 70°C (158°F).
- Perform DTC CONFIRMATION PROCEDURE again.

>> GO TO 3.

O.PERFORM DTC CONFIRMATION PROCEDURE-III

Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-228, "Diagnosis Procedure".

NO >> INSPECTION END

7.PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to EC-227, "Component Function Check",

NOTE:

Use component function check to check the overall function of the three way catalyst (manifold). During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-228, "Diagnosis Procedure".

Component Function Check

1. PERFORM COMPONENT FUNCTION CHECK

Without CONSULT-III

- Start engine and warm it up to the normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 4. Let engine idle for 1 minute.
- Open engine hood. 5.
- Check the voltage between ECM harness connector terminals under the following conditions.

		ECM				
DTC	Connec-	+	_	Condition	Voltage (V)	
	tor	Terminal	Terminal			
P0420	F8	33 [HO2S2 (bank 1) signal]	35 (Sensor	Keeping engine speed at 2,500 rpm	The voltage fluctuation cycle takes more than 5 seconds.	
P0430	F0	34 [HO2S2 (bank 2) signal]	ground)	constant under no load	• 1 cycle: 0.6 - 1.0 → 0 - 0.3 → 0.6 - 1.0	F

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-228, "Diagnosis Procedure".

EC-227

EC

Α

Е

INFOID:0000000003856632

K

L

M

N

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Diagnosis Procedure

INFOID:0000000003856633

1. CHECK EXHAUST SYSTEM

Visually check exhaust tubes and muffler for dents.


Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning part.

2. CHECK EXHAUST GAS LEAK

- 1. Start engine and run it at idle.
- 2. Listen for an exhaust gas leak before the three way catalyst (manifold).



Is exhaust gas leak detected?

YES >> Repair or replace malfunctioning part.

NO >> GO TO 3.

3. CHECK INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

Is intake air leak detected?

YES >> Repair or replace malfunctioning part.

NO >> GO TO 4.

4. CHECK IGNITION TIMING

Check idle speed and ignition timing.

For procedure, refer to EC-11, "BASIC INSPECTION: Special Repair Requirement".

For specification, refer to EC-414, "Ignition Timing".

Is the inspection result normal?

YES >> GO TO 5.

NO >> Follow the EC-11, "BASIC INSPECTION: Special Repair Requirement".

5.CHECK FUEL INJECTORS

- 1. Stop engine and then turn ignition switch ON.
- Check the voltage between ECM harness connector and ground.

ECM		Ground	Voltage	
Connector	Terminal	Glound	voitage	
	1			
	3		Battery voltage	
F7	29	Ground		
17	30			
	31			
	32			

Is the inspection result normal?

YES >> GO TO 6.

NO >> Perform EC-334, "Diagnosis Procedure".

P0420, P0430 THREE WAY CATALYST FUNCTION

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

6. CHECK FUNCTION OF IGNITION COIL-I

CAUTION


Perform the following procedure in a place with no combustible objects and good ventilation.

- 1. Turn ignition switch OFF.
- 2. Remove fuel pump fuse in IPDM E/R to release fuel pressure.

NOTE:

Do not use CONSULT-III to release fuel pressure, or fuel pressure applies again during the following procedure.

- 3. Start engine.
- 4. After engine stalls, crank it 2 or 3 times to release all fuel pressure.
- 5. Turn ignition switch OFF.
- 6. Remove all ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
- 7. Remove ignition coil and spark plug of the cylinder to be checked.
- 8. Crank engine for 5 seconds or more to remove combustion gas in the cylinder.
- 9. Connect spark plug and harness connector to ignition coil.
- 10. Fix ignition coil using a rope etc. with gap of 13 17 mm (0.52 0.66 in) between the edge of the spark plug and grounded metal portion as shown in the figure.
- 11. Crank engine for about 3 seconds, and check whether spark is generated between the spark plug and the grounded metal portion.



Spark should be generated.

CAUTION:

- Never place to the spark plug and the ignition coil within 50 cm (19.7 in) each other. Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20 kV or more.
- It might damage the ignition coil if the gap of more than 17 mm (0.66 in) is made.
 NOTE:

When the gap is less than 13 mm (0.52 in), a spark might be generated even if the coil is a malfunctioning.

Is the inspection result normal?

YES >> GO TO 10.

NO >> GO TO 7.

.CHECK FUNCTION OF IGNITION COIL-II

- Turn ignition switch OFF.
- 2. Disconnect spark plug and connect a non-malfunctioning spark plug.
- 3. Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded metal portion.

Spark should be generated.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Check ignition coil, power transistor and their circuit. Refer to EC-341, "Diagnosis Procedure".

8. CHECK SPARK PLUG

EC

D

Е

F

G

Н

. 1

K

M

N

P0420, P0430 THREE WAY CATALYST FUNCTION

< COMPONENT DIAGNOSIS >


[VQ25DE, VQ35DE]

Check the initial spark plug for fouling, etc.

Is the inspection result normal?

YES >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to EM-136, "Spark Plug".

NO >> Repair or clean spark plug. Then GO TO 9.



9. CHECK FUNCTION OF IGNITION COIL-III

- 1. Reconnect the initial spark plugs.
- 2. Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded portion.

Spark should be generated.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to <u>EM-136, "Spark Plug"</u>.

10. CHECK FUEL INJECTOR

- 1. Turn ignition switch OFF.
- 2. Remove fuel injector assembly.

Refer to EM-44, "Removal and Installation".

Keep fuel hose and all fuel injectors connected to fuel tube.

- 3. Disconnect all ignition coil harness connectors.
- 4. Reconnect all fuel injector harness connectors disconnected.
- 5. Turn ignition switch ON.

Check the fuel does not drip from fuel injector.

Does fuel drip from fuel injector?

YES >> Replace the fuel injector(s) from which fuel is dripping.

NO >> GO TO 11.

11. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

Is the inspection result norma?

YES >> Replace three way catalyst assembly.

NO >> Repair or replace harness or connector.

P0444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P0444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Description INFOID:000000003856644

The EVAP canister purge volume control solenoid valve is used to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0444	EVAP canister purge volume control solenoid valve circuit open	An excessively low voltage signal is sent to ECM through the valve	Harness or connectors (The solenoid valve circuit is open or shorted.) EVAP canister purge volume control solenoid valve

DTC CONFIRMATION PROCEDURE

1.CONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- 1. Start engine and let it idle for at least 13 seconds.
- 2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-231, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1.CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
- Turn ignition switch ON.
- 4. Check the voltage between EVAP canister purge volume control solenoid valve harness connector and ground.

EVAP canister purge volume control solenoid valve		Ground	Voltage
Connector	Terminal		
F30	1	Ground	Battery voltage

Is the inspection result normal?

EC

Α

Е

D

F

Н

J

K

M

Ν

0

P0444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

< COMPONENT DIAGNOSIS >

YES >> GO TO 3. >> GO TO 2.

2.DETECT MALFUNCTIONING PART

Check the following.

NO

- Harness connectors F121, E7
- Harness for open or short between EVAP canister purge volume control solenoid valve and IPDM E/R
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM
 - >> Repair open circuit, short to ground or short to power in harness or connectors.

3.check evap canister purge volume control solenoid valve output signal circuit FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- 3. Check the continuity between EVAP canister purge volume control solenoid valve harness connector and ECM harness connector.

•	urge volume con- noid valve	ECM		Continuity
Connector	Terminal	Connector	Terminal	
F30	2	F7	25	Existed

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES-1 >> With CONSULT-III: GO TO 4.

YES-2 >> Without CONSULT-III: GO TO 5.

>> Repair open circuit, short to ground or short to power in harness or connectors.

f 4.CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

(P) With CONSULT-III

- Reconnect all harness connectors disconnected.
- Start engine.
- Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-III. Check that engine speed varies according to the valve opening.

Does engine speed vary according to the valve opening?

YFS >> GO TO 6.

NO >> GO TO 5.

${f 5}.$ CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to EC-232, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 6.

>> Replace EVAP canister purge volume control solenoid valve. NO

6.CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

 ${f 1}$.CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

(I) With CONSULT-III

- Turn ignition switch OFF.
- 2. Reconnect all harness connectors disconnected.
- Disconnect EVAP purge hoses connected to EVAP canister purge volume control solenoid valve.

EC-232

INFOID:0000000003856647


[VQ25DE, VQ35DE]

P0444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ25DE, VQ35DE] < COMPONENT DIAGNOSIS >

- Turn ignition switch ON.
- 5. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-III.
- Touch "Qd" and "Qu" on CONSULT-III screen to adjust "PURG VOL CONT/V" opening and check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.


Condition (PURG VOL CONT/V value)	Air passage continuity between (A) and (B)
100%	Existed
0%	Not existed



Without CONSULT-III

- Turn ignition switch OFF.
- 2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
- 3. Disconnect EVAP purge hoses connected to EVAP canister purge volume control solenoid valve.
- 4. Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.


Condition	Air passage continuity between (A) and (B)
12 V direct current supply between terminals 1 and 2	Existed
No supply	Not existed



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace EVAP canister purge volume control solenoid valve



EC

Α

D

Е

F

Н

K

L

M

Ν

P0500 VSS

Description

The vehicle speed signal is sent to the combination meter from the "ABS actuator and electric unit (control unit)" by CAN communication line. The combination meter then sends a signal to the ECM by CAN communication line.

DTC Logic

DTC DETECTION LOGIC

NOTE:

- If DTC P0500 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to EC-135, "DTC Logic".
- If DTC P0500 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to <u>EC-242</u>, "<u>DTC Logic"</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed signal is sent to ECM even when vehicle is being driven.	Harness or connectors (The CAN communication line is open or shorted) Harness or connectors (The vehicle speed signal circuit is open or shorted) Wheel sensor Combination meter ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Will CONSULT-III be used?

Will CONSULT-III be used?

YES >> GO TO 2.

NO >> GO TO 5.

2.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 3.

3.CHECK VEHICLE SPEED SIGNAL

NOTE

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

(P)With CONSULT-III

- 1. Start engine (VDC switch OFF).
- Read "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-III. The vehicle speed on CON-SULT-III should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Go to EC-235, "Diagnosis Procedure".

4. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Select "DATA MONITOR" mode with CONSULT-III.
- 2. Warm engine up to normal operating temperature.
- Maintain the following conditions for at least 50 consecutive seconds. CAUTION:

ENG SPEED	1,600 - 6,000 rpm	
COOLAN TEMP/S	More than 70°C (158°F)	
B/FUEL SCHDL	5.5 - 31.8 msec	
Selector lever	Except P or N position	
PW/ST SIGNAL	OFF	
4. Check 1st trip DTC.	CIT	
Is 1st trip DTC detected?		
YES >> Go to <u>EC-235</u> NO >> INSPECTION	<u>5, "Diagnosis Procedure"</u> . N END	
5.PERFORM COMPON	ENT FUNCTION CHECK	
YES >> INSPECTION NO >> Go to EC-235	N END 5. "Diagnosis Procedure".	
Component Function	n Check	INFOID:000000003856687
1. PERFORM COMPON	ENT FUNCTION CHECK	
The vehicle speed significant suitable gear position as the inspection result not YES >> INSPECTION	ormal?	(6 MPH) when rotating wheels with
Diagnosis Procedur	e	INFOID:000000003856688
	BS ACTUATOR AND ELECTRIC UNIT (CONTR	OL UNIT)"
Refer to BRC-80, "CONS	ULT-III Function".	
Is the inspection result no	<u>rmal?</u>	
YES >> GO TO 2.		
NO >> Repair or rep	lace malfunctioning part.	
	<u> </u>	
NO $>>$ Repair or rep 2. CHECK COMBINATION	<u> </u>	
NO $>>$ Repair or rep 2. CHECK COMBINATION	ON METER FUNCTION ULT-III Function (METER/M&A)".	
NO >> Repair or rep 2.CHECK COMBINATIO Refer to MWI-33, "CONS	ON METER FUNCTION ULT-III Function (METER/M&A)".	

P0550 PSP SENSOR

Description INFOID:0000000003856695

Power steering pressure (PSP) sensor is installed to the power steering high-pressure tube and detects a power steering load.

This sensor is a potentiometer which transforms the power steering load into output voltage, and emits the voltage signal to the ECM. The ECM controls the electric throttle control actuator and adjusts the throttle valve opening angle to increase the engine speed and adjusts the idle speed for the increased load.

DTC Logic INFOID:0000000003856696

DTC DETECTION LOGIC

NOTE:

If DTC P0550 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0550	Power steering pressure sensor circuit	An excessively low or high voltage from the sensor is sent to ECM.	 Harness or connectors (The sensor circuit is open or shorted) Power steering pressure sensor

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- 1. Start engine and let it idle for at least 5 seconds.
- 2. Check 1st trip DTC.

Is 1st trip DTC detected?

>> Go to EC-236, "Diagnosis Procedure". YES

>> INSPECTION END NO

Diagnosis Procedure

INFOID:0000000003856697

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.check psp sensor power supply circuit

- Disconnect power steering pressure (PSP) sensor harness connector.
- Turn ignition switch ON.
- Check the voltage between PSP sensor harness connector and ground.

PSP s	sensor	Ground	Voltage	
Connector	Terminal	Ground		
F62	3	Ground	Approx. 5 V	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

$\overline{3}$.check PSP sensor ground circuit for open and short

- 1. Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check the continuity between PSP sensor harness connector and ECM harness connector.

PSP sensor		ECM		Continuity	
Connector	Terminal	Connector Terminal		Continuity	
F62	1	F8	48	Existed	

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground short to power in harness or connectors.

f 4.CHECK PSP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between PSP sensor harness connector and ECM harness connector.

PSP sensor		ECM		Continuity	
Connector	Terminal	Connector Terminal		Continuity	
F62	2	F8	41	Existed	

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5.CHECK PSP SENSOR

Refer to EC-237, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace PSP sensor.

6.CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

1. CHECK POWER STEERING PRESSURE SENSOR

- Reconnect all harness connectors disconnected.
- Start engine and let it idle.
- Check the voltage between ECM terminals under the following conditions.

ECM					
Connector +		_	Condition	Voltage	
Connector -	Terminal	Terminal			
	41	48	Steering wheel: Being turned.	0.5 - 4.5 V	
F8 (Power steering pressur sensor signal)		(Sensor ground)	Steering wheel: Not being turned.	0.4 - 0.8 V	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power steering pressure sensor.

EC-237

EC

Е

F

INFOID:0000000003856698


Ν

INFOID:0000000003856701

P0603 ECM POWER SUPPLY

Description

Battery voltage is supplied to the ECM even when the ignition switch is turned OFF for the ECM memory function of the DTC memory, the air-fuel ratio feedback compensation value memory, the idle air volume learning value memory, etc.



DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0603	ECM power supply circuit	ECM back up RAM system does not function properly.	Harness or connectors [ECM power supply (back up) circuit is open or shorted.] ECM

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.perform dtc confirmation procedure

- 1. Turn ignition switch ON and wait at least 1 second.
- Start engine and let it idle for 1 second.
- 3. Turn ignition switch OFF, wait at least 10 seconds, and then turn it ON.
- 4. Repeat steps 2 and 3 for 4 times.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-238, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1.CHECK ECM POWER SUPPLY

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the voltage between ECM harness connector and ground.

ECM		Ground	Voltage	
Connector	Terminal	Olouliu	voltage	
F8	77	Ground	Battery voltage	

Is the inspection result normal?

YES >> GO TO 3. NO >> GO TO 2.

EC-238


P0603 ECM POWER SUPPLY

< COMPONENT DIAGNOSIS >	[VQ25DE, VQ35DE]
2. DETECT MALFUNCTIONING PART	Α
Check the following. • 15A fuse (No.50)	
IPDM E/R harness connector F12	EC
Harness for open or short between ECM and battery	
>> Repair or replace harness or connectors.	C
3.CHECK INTERMITTENT INCIDENT	
Refer to GI-35, "Intermittent Incident".	D
Is the inspection result normal? YES >> GO TO 4.	
NO >> Repair or replace harness or connectors.	_
4.PERFORM DTC CONFIRMATION PROCEDURE	E
 Turn ignition switch ON. Erase DTC. 	_
3. Perform DTC CONFIRMATION PROCEDURE.	F
See <u>EC-238, "DTC Logic"</u> . <u>Is the 1st trip DTC P0603 displayed again?</u>	
YES >> GO TO 5.	G
NO >> INSPECTION END	
5.REPLACE ECM	Н
 Replace ECM. Go to <u>EC-14</u>, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : 	Special Repair Require-
ment".	1
>> INSPECTION END	
77 INOI ZOTION END	J
	K
	L
	M
	IVI
	Al
	N
	0
	Р

P0605 ECM

Description INFOID:000000003856702

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
		A)	ECM calculation function is a malfunctioning.	
P0605	Engine control module	B)	ECM EEP-ROM system is a malfunctioning.	• ECM
		C)	ECM self shut-off function is a malfunctioning.	

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A

- 1. Turn ignition switch ON.
- 2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-241, "Diagnosis Procedure".

NO >> GO TO 3.

3.perform dtc confirmation procedure for malfunction b

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds, and then turn it ON.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-241, "Diagnosis Procedure".

NO >> GO TO 4.

${f 4.}$ PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION C

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds, and then turn it ON.
- 3. Repeat step 2 for 32 times.
- 4. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-241, "Diagnosis Procedure".

NO >> INSPECTION END

K

L

M

Ν

0

P0607 ECM

Description INFOID:000000003856705

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0607	CAN communication bus	When detecting error during the initial diagnosis of CAN controller of ECM.	• ECM

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check DTC.

Is DTC detected?

YES >> Go to EC-242, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856707

1. INSPECTION START

- 1. Turn ignition switch ON.
- 2. Erase DTC.
- Perform DTC CONFIRMATION PROCEDURE. See <u>EC-242</u>, "<u>DTC Logic</u>".
- 4. Check DTC.

Is the DTC P0607 displayed again?

Yes >> GO TO 2.

No >> INSPECTION END

2.REPLACE ECM

- 1. Replace ECM.
- 2. Go to EC-14, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Special Repair Requirement".
 - >> INSPECTION END

P0643 SENSOR POWER SUPPLY

DTC Logic INFOID:0000000003856708

DTC DETECTION LOGIC

< COMPONENT DIAGNOSIS >

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0643	Sensor power supply circuit short	ECM detects that the voltage of power source for sensor is excessively low or high.	Harness or connectors (APP sensor 1 circuit is shorted.) (TP sensor circuit is shorted.) [CMP sensor (PHASE) circuit is shorted.) (PSP sensor circuit is shorted.) (Battery current sensor circuit is shorted.) Accelerator pedal position sensor Throttle position sensor Camshaft position sensor (PHASE) Power steering pressure sensor Battery current sensor

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Start engine and let it idle for 1 second.
- 3. Check DTC

Is DTC detected?

YES >> Go to EC-243, "Diagnosis Procedure".

>> INSPECTION END NO

Diagnosis Procedure

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK ACCELERATOR PEDAL POSITION SENSOR 1 POWER SUPPLY CIRCUIT

- Disconnect accelerator pedal position (APP) sensor harness connector.
- Turn ignition switch ON.
- Check the voltage between APP sensor harness connector and ground.

APP :	sensor	Ground	Voltage (V)	
Connector	Terminal	Ground		
E110	4	Ground	Approx. 5	

Is the inspection result normal?

YES >> GO TO 7.

[VQ25DE, VQ35DE]

Н

Α

EC

D

Е

F

K

INFOID:0000000003856709

< COMPONENT DIAGNOSIS >

NO >> GO TO 3.

3.check sensor power supply circuit

Check harness for short to power and short to ground, between the following terminals.

E	СМ	Sensor		
Connector	Terminal	Name	Connector	Terminal
	47	TP sensor	F29	1
	51	Battery current sensor	F76	1
F8	55	PSP sensor	F62	3
	59	CMP sensor (PHASE) (bank 1)	F26	1
	63	CMP sensor (PHASE) (bank 2)	F69	1
E16	83	APP sensor	E110	4

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair short to ground or short to power in harness or connectors.

4. CHECK COMPONENTS

Check the following.

- Camshaft position sensor (PHASE) (Refer to EC-224. "Component Inspection".)
- Battery current sensor (Refer to EĆ-259, "Component Inspection".)
- Power steering pressure sensor (Refer to EC-237, "Component Inspection".)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning component.

5. CHECK TP SENSOR

Refer to EC-162, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 6.

6.REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- Go to <u>EC-162</u>, "Special Repair Requirement".

>> INSPECTION END

7. CHECK APP SENSOR

Refer to EC-306, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 8.

8.replace accelerator pedal assembly

- Replace accelerator pedal assembly.
- Go to EC-306, "Special Repair Requirement".

>> INSPECTION END

9. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

P0850 PNP SWITCH

Description INFOID:0000000003856710

When the selector lever position is P or N, park/neutral position (PNP) signal from the TCM (VQ35DE engine) or park/neutral position (PNP) switch (VQ25DE engine) is sent to ECM.

INFOID:0000000003856711

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0850	Park/neutral position switch	The signal of the park/neutral position (PNP) signal does not change during driving after the engine is started.	Harness or connectors [The park/neutral position (PNP) signal circuit is open or shorted.] TCM (VQ35DE engine) Park/neutral position (PNP) switch (VQ25DE engine)

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Will CONSULT-III be used?

Will CONSULT-III be used?

YES >> GO TO 2.

NO >> GO TO 5.

2.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 3.

3. CHECK PNP SIGNAL

(P)With CONSULT-III

1. Turn ignition switch ON.

Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-III. Then check the "P/N POSI SW" signal under the following conditions.

Position (Selector lever)	Known-good signal
N or P position	ON
Except above position	OFF

Is the inspection result normal?

YES >> GO TO 4.

NO-1 >> VQ35DE engine: Go to EC-246, "Diagnosis Procedure (VQ35DE engine)".

NO-2 >> VQ25DE engine: Go to EC-247, "Diagnosis Procedure (VQ25DE engine)".

4. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Select "DATA MONITOR" mode with CONSULT-III.
- 2. Start engine and warm it up to normal operating temperature.
- Maintain the following conditions for at least 50 consecutive seconds.

 CAUTION:

Always drive vehicle at a safe speed.

ENG SPEED	1,100 - 6,375 rpm
COOLAN TEMP/S	More than 70°C (158°F)

EC

D

Е

Α

Н

0

K

L

Ν

1

< COMPONENT DIAGNOSIS >

B/FUEL SCHDL	4.0 - 31.8 msec
VHCL SPEED SE	More than 64 km/h (40 mph)
Selector lever	Suitable position

4. Check 1st trip DTC.

Is 1st trip DTC detected?

YES-1 >> VQ35DE engine: Go to <u>EC-246</u>, "<u>Diagnosis Procedure (VQ35DE engine)</u>". YES-2 >> VQ25DE engine: Go to <u>EC-247</u>, "<u>Diagnosis Procedure (VQ25DE engine)</u>".

NO >> INSPECTION END

PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to EC-246. "Component Function Check".

NOTE:

Use component function check to check the overall function of the park/neutral position (PNP) signal circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO-1 >> VQ35DE engine: Go to EC-246. "Diagnosis Procedure (VQ35DE engine)".

NO-2 >> VQ25DE engine: Go to EC-247, "Diagnosis Procedure (VQ25DE engine)".

Component Function Check

INFOID:0000000003856712

1. PERFORM COMPONENT FUNCTION CHECK

- 1. Turn ignition switch ON.
- 2. Check the voltage between ECM harness connector and ground.

ECM		Ground	Condition		Voltage
Connector	Terminal	Ground	Condition		voltage
E16	102	Ground	Selector lever	P or N	Battery voltage
	102	Giodila	Selector level	Except above	Approx. 0 V

Is the inspection result normal?

YES >> INSPECTION END

NO-1 >> VQ35DE engine: Go to EC-246, "Diagnosis Procedure (VQ35DE engine)".

NO-2 >> VQ25DE engine: Go to EC-247, "Diagnosis Procedure (VQ25DE engine)".

Diagnosis Procedure (VQ35DE engine)

INFOID:0000000003856713

1. CHECK DTC WITH TCM

Refer to EC-389, "DTC Index".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning part.

${f 2.}$ CHECK STARTING SYSTEM

Turn ignition switch OFF, then turn it to START.

Does starter motor operate?

YES >> GO TO 3.

NO >> Refer to BCS-16, "COMMON ITEM: CONSULT-III Function (BCM - COMMON ITEM)".

3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I

- 1. Turn ignition switch OFF.
- 2. Disconnect TCM harness connector.
- Disconnect IPDM E/R harness connector.
- 4. Check the continuity between TCM harness connector and IPDM E/R harness connector.

Α

EC

Е

Н

N

Р

INFOID:0000000003891373

TC	TCM		IPDM E/R	
Connector	Terminal	Connector	Terminal	Continuity
F23	20	F12	72	Existed
. Also check h	Also check harness for short to ground and short to power.			

Is the inspection result normal?

YES >> GO TO 4.

>> Repair open circuit, short to ground or short to power in harness or connectors. NO

f 4.CHECK PNP SIGNAL CIRCUIT FOR OPEN AND SHORT-II

- Disconnect IPDM E/R harness connectors.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between ECM harness connector and IPDM E/R harness connector.

ECM		IPDN	Continuity	
Connector	Terminal	Connector	Terminal	Continuity
E16	102	E10	30	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

$\mathbf{5}.$ check intermittent incident

Refer to GI-35, "Intermittent Incident".

>> Repair or replace malfunctioning part.

Diagnosis Procedure (VQ25DE engine)

1. CHECK DTC WITH TCM

Refer to EC-389, "DTC Index".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning part.

2.CHECK STARTING SYSTEM

Turn ignition switch OFF, then turn it to START.

Does starter motor operate?

>> GO TO 3. YES

NO >> Refer to BCS-16, "COMMON ITEM: CONSULT-III Function (BCM - COMMON ITEM)".

3.CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I

- Turn ignition switch OFF and then ON.
- 2. Check the voltage between Park/neutral position switch harness connector and ground.

Park/neutral p	position switch	Ground	Voltage	
Connector Terminal		Giodila	voltage	
F57	1	Ground	Battery voltage	

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. DETECT MALFUNCTIONING PART

EC-247

< COMPONENT DIAGNOSIS >

Check the following.

- IPDM E/R connector F12
- 10A fuse (No. 42)
- Harness for open or short between Park/neutral position switch and fuse

>> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I

- 1. Turn ignition switch OFF.
- 2. Disconnect Park/neutral position switch harness connector.
- 3. Disconnect IPDM E/R harness connector.
- 4. Check the continuity between Park/neutral position switch and IPDM E/R harness connector.

Park/neutral position switch		IPDN	Continuity	
Connector	Terminal	Connector	Terminal	Continuity
F57	2	F12	72	Existed

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

6.CHECK PNP SIGNAL CIRCUIT FOR OPEN AND SHORT-II

- Disconnect IPDM E/R harness connectors.
- Disconnect ECM harness connector.
- 3. Check the continuity between ECM harness connector and IPDM E/R harness connector.

ECM Connector Terminal		IPDM E/R		Continuity
		Connector	Terminal	Continuity
E16	102	E10	30	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

7. CHECK PARK/NEUTRAL POSITION SWITCH

Refer to TM-214, "Component Inspection (Park/Neutral Position Switch)".

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace Park/neutral position switch.

8.check intermittent incident

Refer to GI-35, "Intermittent Incident".

>> Repair or replace malfunctioning part.

P1212 TCS COMMUNICATION LINE

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P1212 TCS COMMUNICATION LINE

Description INFOID:00000000003856715

This CAN communication line is used to control the smooth engine operation during the TCS operation. Pulse signals are exchanged between ECM and "ABS actuator and electric unit (control unit)".

Be sure to erase the malfunction information such as DTC not only for "ABS actuator and electric unit (control unit)" but also for ECM after TCS related repair.

DTC Logic

DTC DETECTION LOGIC

NOTE:

- If DTC P1212 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to <u>EC-135</u>, "<u>DTC Logic"</u>.
- If DTC P1212 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to <u>EC-242</u>, "<u>DTC Logic"</u>.

Freeze frame data is not stored in the ECM for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1212	TCS communication line	ECM cannot receive the information from "ABS actuator and electric unit (control unit)" continuously.	Harness or connectors (The CAN communication line is open or shorted.) ABS actuator and electric unit (control unit) Dead (Weak) battery

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V at idle.

.....

2.PERFORM DTC CONFIRMATION PROCEDURE

- 1. Start engine and let it idle for at least 10 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-249, "Diagnosis Procedure".

NO >> INSPECTION END

>> GO TO 2.

Diagnosis Procedure

Go to BRC-62, "Work Flow".

INFOID:0000000003856717

F

Α

EC

D

Е

Н

K

M

N

С

Р

EC-249

< COMPONENT DIAGNOSIS >

P1217 ENGINE OVER TEMPERATURE

DTC Logic INFOID:0000000003856718

DTC DETECTION LOGIC

NOTE:

- If DTC P1217 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to EC-135, "DTC Logic".
- If DTC P1217 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to EC-242, "DTC Logic".

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217	Engine over tempera- ture (Overheat)	 Cooling fan does not operate properly (Overheat). Cooling fan system does not operate properly (Overheat). Engine coolant was not added to the system using the proper filling method. Engine coolant is not within the specified range. 	Harness or connectors (The cooling fan circuit is open or shorted.) IPDM E/R (Cooling fan relays) Cooling fan motor Radiator hose Radiator Radiator cap Water pump Thermostat

CAUTION:

When a malfunction is indicated, always replace the coolant. Refer to CO-8, "Draining". Also, replace the engine oil. Refer to LU-8, "Draining".

- 1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Always use coolant with the proper mixture ratio. Refer to MA-12, "Engine Coolant Mixture Ratio".
- After refilling coolant, run engine to ensure that no water-flow noise is emitted.

DTC CONFIRMATION PROCEDURE

1. PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to EC-250, "Component Function Check".

NOTE:

Use component function check to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-251, "Diagnosis Procedure".

Component Function Check

INFOID:0000000003856719

[VQ25DE, VQ35DE]

1.PERFORM COMPONENT FUNCTION CHECK-I

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

P1217 ENGINE OVER TEMPERATURE

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]


Check the coolant level in the reservoir tank and radiator.

Allow engine to cool before checking coolant level.

Is the coolant level in the reservoir tank and/or radiator below the proper range?

YES >> Go to EC-251, "Diagnosis Procedure".

NO >> GO TO 2.



2.PERFORM COMPONENT FUNCTION CHECK-II

Confirm whether customer filled the coolant or not.

Did customer fill the coolant?

YES >> Go to EC-251, "Diagnosis Procedure".

>> GO TO 3. NO

3. PERFORM COMPONENT FUNCTION CHECK-III

(P)With CONSULT-III

- 1. Turn ignition switch ON.
- 2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-III.
- Check that cooling fan motors-1 and -2 operate at each speed (LOW/MID/HI).

Without CONSULT-III

Perform IPDM E/R auto active test and check cooling fan motors operation, refer to PCS-11, "Diagnosis Description".

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-251, "Diagnosis Procedure".

Diagnosis Procedure

1. CHECK COOLING FAN OPERATION

(II) With CONSULT-III

- 1. Turn ignition switch ON.
- Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-III.
- Check that cooling fans-1 and -2 operate at each speed (LOW/MID/HI).

W Without CONSULT-III

- 1. Perform IPDM E/R auto active test and check cooling fan motors operation, refer to PCS-11, "Diagnosis Description".
- 2. Check that cooling fans-1 and -2 operate at each speed (Low/Middle/High).

Is the inspection result normal?

YFS >> GO TO 2.

NO >> Go to EC-324, "Diagnosis Procedure".

2.CHECK COOLING SYSTEM FOR LEAK-I

Check cooling system for leak. Refer to CO-8, "Inspection".

Is leakage detected?

YES >> GO TO 3.

NO >> GO TO 4.

3.CHECK COOLING SYSTEM FOR LEAK-II

Check the following for leak.

- Hose
- Radiator
- Water pump

Α

EC

D

Е

F

INFOID:0000000003856720

K

M

N

>> Repair or replace malfunctioning part.

4. CHECK RADIATOR CAP

< COMPONENT DIAGNOSIS >

Check radiator cap. Refer to CO-12, "RADIATOR CAP: Inspection".

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace radiator cap.

5. CHECK THERMOSTAT

Check thermostat. Refer to CO-24, "Inspection".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace thermostat

6. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to EC-158, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace engine coolant temperature sensor.

7. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, check the following.

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper	Visual	No blocking	_
	2	Coolant mixture	Coolant tester	MA-11, "Fluids and Lubricants"	
	3	Coolant level	Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	CO-8, "Inspection"
	4	Radiator cap	Pressure tester	CO-12, "RADIATOR CAP : Inspection"	
ON*2	5	Coolant leaks	Visual	No leaks	CO-8, "Inspection"
ON* ²	6	Thermostat	Touch the upper and lower radiator hoses	Both hoses should be hot	CO-24, "Inspection"
ON* ¹	7	Cooling fan	CONSULT-III	Operating	EC-324, "Component Function Check"
OFF	8	Combustion gas leak	Color checker chemical tester 4 Gas analyzer	Negative	_
ON* ³	9	Coolant temperature gauge	Visual	Gauge less than 3/4 when driving	_
		Coolant overflow to reservoir tank	Visual	No overflow during driving and idling	CO-8, "Inspection"
OFF* ⁴	10	Coolant return from reservoir tank to radiator	Visual	Should be initial level in reservoir tank	CO-8, "Inspection"
OFF	11	Cylinder head	Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	EM-104, "Inspection"
	12	Cylinder block and pistons	Visual	No scuffing on cylinder walls or piston	EM-119, "Inspection"

^{*1:} Turn the ignition switch ON.

For more information, refer to CO-3, "Troubleshooting Chart".

^{*2:} Engine running at 3,000 rpm for 10 minutes.

^{*3:} Drive at 90 km/h (56 MPH) for 30 minutes and then let idle for 10 minutes.

^{*4:} After 60 minutes of cool down time.

>> INSPECTION END

Α

EC

С

D

Е

F

G

Н

J

Κ

L

M

Ν

0

Ρ


INFOID:0000000003856722

P1225 TP SENSOR

Description INFOID.000000003857978

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has two sensors. These sensors are a kind of potentiometer which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and controls the throttle valve opening angle in response to driving conditions via the throttle control motor.



DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1225	Closed throttle position learning performance	Closed throttle position learning value is excessively low.	Electric throttle control actuator (TP sensor 1 and 2)

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.
- 3. Turn ignition switch ON.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-254, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856723

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

- 1. Turn ignition switch OFF.
- Remove the intake air duct.

P1225 TP SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

3. Check if foreign matter is caught between the throttle valve (1) and the housing.


2: Electric throttle control actuator

Is the inspection result normal?

YES >> GO TO 2.

NO >> Remove 1

>> Remove the foreign matter and clean the electric throttle control actuator inside.



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- 2. Go to EC-255, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

1. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement"

>> GO TO 2.

2.PERFORM IDLE AIR VOLUME LEARNING

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement"

>> END

_

Α

EC

C

D

Е

F

INFOID:0000000003858124

G

Н

ı

K

M

Ν


INFOID:0000000003856726

P1226 TP SENSOR

Description INFOID:000000003857979

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has two sensors. These sensors are a kind of potentiometer which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and controls the throttle valve opening angle in response to driving conditions via the throttle control motor.



DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1226	Closed throttle position learning performance	Closed throttle position learning is not performed successfully, repeatedly.	Electric throttle control actuator (TP sensor 1 and 2)

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Turn ignition switch ON.
- 2. Turn ignition switch OFF and wait at least 10 seconds.
- 3. Turn ignition switch ON.
- 4. Repeat steps 2 and 3 for 32 times.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-256, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003858130

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

- 1. Turn ignition switch OFF.
- 2. Remove the intake air duct.

P1226 TP SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

3. Check if foreign matter is caught between the throttle valve (1) and the housing.


2: Electric throttle control actuator

Is the inspection result normal?

YES >> GO TO 2.

NO >> Remove 1

>> Remove the foreign matter and clean the electric throttle control actuator inside.



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- 2. Go to EC-255, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

1. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement"

>> GO TO 2.

2.PERFORM IDLE AIR VOLUME LEARNING

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement"

>> END

EC

Α

D

Е

INFOID:0000000003858125

Н

K

ı

M

Ν

0

P1550 BATTERY CURRENT SENSOR

< COMPONENT DIAGNOSIS >

Description INFOID:0000000003856732

The power generation voltage variable control enables fuel consumption to be decreased by reducing the engine load which is caused by the power generation of the generator. The battery current sensor is installed to the battery cable at the negative terminal. The sensor measures the charging/discharging current of the battery. Based on the sensor signal, ECM judges whether or not the power generation voltage variable control is performed. When performing the power generation voltage variable control, ECM calculates the target power generation voltage based on the sensor signal. And ECM sends the calculated value as the power generation command value to IPDM E/R. For the details of the power generation voltage variable control, refer to CHG-5, "System Description".

CAUTION:

Never connect the electrical component or the ground wire directly to the battery terminal. The connection causes the malfunction of the power generation voltage variable control, and then the battery discharge may occur.

DTC Logic INFOID:0000000003856733

DTC DETECTION LOGIC

If DTC P1550 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1550	Battery current sensor circuit range/performance	The output voltage of the battery current sensor remains within the specified range while engine is running.	Harness or connectors (The sensor circuit is open or shorted.) Battery current sensor

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and at wait least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and wait at least 10 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-258, "Diagnosis Procedure".

>> INSPECTION END NO

Diagnosis Procedure

INFOID:0000000003856734

[VQ25DE, VQ35DE]

CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK BATTERY CURRENT SENSOR POWER SUPPLY CIRCUIT

- Disconnect battery current sensor harness connector.
- Turn ignition switch ON. 2.
- Check the voltage between battery current sensor harness connector and ground.

P1550 BATTERY CURRENT SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Batterv cu	rrent sensor			-	
Connector	Terminal	Ground	Voltage (V)		
F76	1	Ground	Approx. 5	_	
s the inspection	on result norma	<u>l?</u>		_	
NO >> Re		•		power in harnes	
. Disconnec	on switch OFF. It ECM harness continuity betw		rrent sensor ha	irness connecto	r and ECM harness connector.
Battery cui	rrent sensor	E	CM	0 11 11	
Connector	Terminal	Connector	Terminal	Continuity	
F76	2	F8	44	Existed	
. Also check	k harness for sh	nort to ground a	and short to pov	ver.	
the inspection	on result norma	<u>l?</u>			
	O TO 4.	20 1 44			
	•			power in harnes	
CHECK BA	TIERY CURRI	ENT SENSOR	INPUT SIGNAL	- CIRCUIT FOR	OPEN AND SHORT
Battery cur Connector	rrent sensor Terminal	Connector	CM Terminal	Continuity	
F76	3	F8	42	Existed	
Also check	harness for sh	nort to ground a	and short to pov	ver.	
-	on result norma	<u>l?</u>			
_	O TO 5.	uit abort to arou	and or obort to	aguar in harnag	o or connectors
1	TTERY CURRI	_	ווום טו אווטוג נטן	power in harnes	s of connectors.
	59, "Componen on result norma	•			
	on result norma O TO 6.	<u>1:</u>			
	eplace battery r	negative cable a	assembly.		
	FERMITTENT I	=	•		
efer to GI-35.	, "Intermittent Ir	ncident".			
>> IN	SPECTION EN	ID			
component	Inspection				INFOID:000000003856735
.CHECK BA	TTERY CURRI	ENT SENSOR			
	on switch OFF.				
Reconnect	t harness conn	ectors disconne	ected.		

P1550 BATTERY CURRENT SENSOR


< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

3. Disconnect battery negative cable (1).

- 4. Install jumper cable (A) between battery negative terminal and body ground.
- 5. Turn ignition switch ON.
- 6. Check the voltage between ECM harness connector terminals under the following conditions.

	3		
	ECM		
Connector	+	-	Voltage (V)
	Terminal	Terminal	
F8	42 (Battery current sensor signal)	44 (Sensor ground)	Approx. 2.5



Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to PG-3, "How to Handle Battery".

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace battery negative cable assembly.

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P1551, P1552 BATTERY CURRENT SENSOR

Description INFOID:0000000003858133

The power generation voltage variable control enables fuel consumption to be decreased by reducing the engine load which is caused by the power generation of the generator. The battery current sensor is installed to the battery cable at the negative terminal. The sensor measures the charging/discharging current of the battery. Based on the sensor signal, ECM judges whether or not the power generation voltage variable control is performed. When performing the power generation voltage variable control, ECM calculates the target power generation voltage based on the sensor signal. And ECM sends the calculated value as the power generation command value to IPDM E/R. For the details of the power generation voltage variable control, refer to CHG-5. "System Description".

CAUTION:

Never connect the electrical component or the ground wire directly to the battery terminal. The connection causes the malfunction of the power generation voltage variable control, and then the battery discharge may occur.

DTC Logic INFOID:0000000003856737

DTC DETECTION LOGIC

If DTC P1551 or P1552 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P1551	Battery current sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	Harness or connectors (The sensor circuit is open or shorted)	
P1552	Battery current sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.		

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V with ignition switch ON

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON and wait at least 10 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-261, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK BATTERY CURRENT SENSOR POWER SUPPLY CIRCUIT

EC

Α

D

Н

L

N

INFOID:0000000003858135

P1551, P1552 BATTERY CURRENT SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

- Disconnect battery current sensor harness connector.
- 2. Turn ignition switch ON.
- 3. Check the voltage between battery current sensor harness connector and ground.

Battery cur	rent sensor	Ground	Voltage (V)	
Connector	Terminal	Glound	voltage (v)	
F76	1	Ground	Approx. 5	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

3.CHECK BATTERY CURRENT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between battery current sensor harness connector and ECM harness connector.

Battery current sensor		E	Continuity	
Connector	Terminal	Connector	Terminal	Continuity
F76	2	F8	44	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

f 4.CHECK BATTERY CURRENT SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between battery current sensor harness connector and ECM harness connector.

Battery current sensor		E	Continuity	
Connector	Terminal	Connector	Terminal	Continuity
F76	3	F8	42	Existed

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK BATTERY CURRENT SENSOR

Refer to EC-262, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace battery negative cable assembly.

6. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003858134

1. CHECK BATTERY CURRENT SENSOR

- Turn ignition switch OFF.
- 2. Reconnect harness connectors disconnected.

P1551, P1552 BATTERY CURRENT SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

3. Disconnect battery negative cable (1).

: Vehicle front: To body ground

- Install jumper cable (A) between battery negative terminal and body ground.
- 5. Turn ignition switch ON.
- Check the voltage between ECM harness connector terminals under the following conditions.

d	
S	
	ALBIA0076ZZ

Connector	+	_	Voltage (V)
Connector	Terminal	Terminal	
F8	42 (Battery current sensor signal)	44 (Sensor ground)	Approx. 2.5

Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to PG-3. "How to Handle Battery".

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace battery negative cable assembly.

EC-263

EC

Α

D

Е

F

Н

I

K

L

 \mathbb{N}

Ν

0

[VQ25DE, VQ35DE]

P1553 BATTERY CURRENT SENSOR

Description INFOID:000000003858136

The power generation voltage variable control enables fuel consumption to be decreased by reducing the engine load which is caused by the power generation of the generator. The battery current sensor is installed to the battery cable at the negative terminal. The sensor measures the charging/discharging current of the battery. Based on the sensor signal, ECM judges whether or not the power generation voltage variable control is performed. When performing the power generation voltage variable control, ECM calculates the target power generation voltage based on the sensor signal. And ECM sends the calculated value as the power generation command value to IPDM E/R. For the details of the power generation voltage variable control, refer to CHG-5. "System Description".

CAUTION:

Never connect the electrical component or the ground wire directly to the battery terminal. The connection causes the malfunction of the power generation voltage variable control, and then the battery discharge may occur.

DTC Logic

DTC DETECTION LOGIC

NOTE:

If DTC P1553 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to <u>EC-243, "DTC Logic"</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1553	Battery current sensor perfor- mance	The signal voltage transmitted from the sensor to ECM is higher than the amount of the maximum power generation.	Harness or connectors (The sensor circuit is open or shorted.) Battery current sensor

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V at idle.

>> GO TO 2.

2.perform dtc confirmation procedure

- 1. Start engine and wait at least 10 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-264, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003858137

1. CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- 2. Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK BATTERY CURRENT SENSOR POWER SUPPLY CIRCUIT

- 1. Disconnect battery current sensor harness connector.
- 2. Turn ignition switch ON.
- Check the voltage between battery current sensor harness connector and ground.

P1553 BATTERY CURRENT SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Battery cu	rrent sensor			-	
Connector	Terminal	Ground	Voltage (V)		
F76	1	Ground	Approx. 5	_	
s the inspection	on result norma	<u>l?</u>		_	
NO >> Re		•		power in harness	
. Disconnec	on switch OFF. It ECM harness continuity betw		rrent sensor ha	irness connectoi	and ECM harness connector.
Battery cu	rrent sensor	E	CM	0 11 11	
Connector	Terminal	Connector	Terminal	Continuity	
F76	2	F8	44	Existed	
. Also check	harness for sh	nort to ground a	ind short to pov	ver.	
the inspection	on result norma	<u>l?</u>			
	O TO 4.	2 1 4			
	•			power in harness	
CHECK BA	TIERY CURRI	ENT SENSOR	INPUT SIGNAL	- CIRCUIT FOR	OPEN AND SHORT
Battery cur Connector	rrent sensor Terminal	Connector	CM Terminal	Continuity	
F76	3	F8	42	Existed	
the inspection YES >> GO NO >> Re	c harness for shon result norma O TO 5. epair open circu	<u>l?</u> uit, short to grou	·	ver. power in harnes:	s or connectors.
efer to EC-26	65, "Componen	t Inspection".			_
the inspection	on result norma	<u>l?</u>			
	O TO 6.	and the state of t			
	eplace battery r	•	assembly.		
	TERMITTENT I				
efer to <u>GI-35</u>	, "Intermittent Ir	ncident".			
>> IN	SPECTION EN	ID			
omponent	Inspection				INFOID:000000003858138
.CHECK BA	TTERY CURRI	ENT SENSOR			
	on switch OFF.				
Reconnec	t harness conn	ectors disconne	ected.		

P1553 BATTERY CURRENT SENSOR


< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

3. Disconnect battery negative cable (1).

- 4. Install jumper cable (A) between battery negative terminal and body ground.
- 5. Turn ignition switch ON.
- 6. Check the voltage between ECM harness connector terminals under the following conditions.

Connector	+	_	Voltage (V)
Connector	Terminal	Terminal	
F8	42 (Battery current sensor signal)	44 (Sensor ground)	Approx. 2.5



Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to PG-3, "How to Handle Battery".

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace battery negative cable assembly.

P1554 BATTERY CURRENT SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P1554 BATTERY CURRENT SENSOR

Description INFOID:0000000003858139

The power generation voltage variable control enables fuel consumption to be decreased by reducing the engine load which is caused by the power generation of the generator. The battery current sensor is installed to the battery cable at the negative terminal. The sensor measures the charging/discharging current of the battery. Based on the sensor signal, ECM judges whether or not the power generation voltage variable control is performed. When performing the power generation voltage variable control, ECM calculates the target power generation voltage based on the sensor signal. And ECM sends the calculated value as the power generation command value to IPDM E/R. For the details of the power generation voltage variable control, refer to CHG-5, "System Description".

CAUTION:

Never connect the electrical component or the ground wire directly to the battery terminal. The connection causes the malfunction of the power generation voltage variable control, and then the battery discharge may occur.

DTC Logic INFOID:0000000003856745

DTC DETECTION LOGIC

If DTC P1554 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1554	Battery current sensor performance	The output voltage of the battery current sensor is lower than the specified value while the battery voltage is high enough.	Harness or connectors (The sensor circuit is open or shorted.) Battery current sensor

DTC CONFIRMATION PROCEDURE

1. PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to EC-267, "Component Function Check".

NOTE:

Use component function check to check the overall function of the battery current sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YFS >> INSPECTION END

NO >> Go to EC-268, "Diagnosis Procedure".

Component Function Check

1.PRECONDITIONING

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 12.8 V at idle.
- Before performing the following procedure, confirm that all load switches and A/C switch are turned OFF.

>> GO TO 2.

2.PERFORM COMPONENT FUNCTION CHECK

(P)With CONSULT-III

- 1. Start engine and let it idle.
- Select "BAT CUR SEN" in "DATA MONITOR" mode with CONSULT-III.
- Check "BAT CUR SEN" indication for 10 seconds.

"BAT CUR SEN" should be above 2,300 mV at least once.

Without CONSULT-III

- Start engine and let it idle.
- Check voltage between ECM harness connector terminals under the following conditions.

EC

Α

D

Н

K

M

INFOID:0000000003856746

Ν

< COMPONENT DIAGNOSIS >

	ECM	Ground	Voltage (V)	
Connector	Terminal	Giodila		
F8	42 (Battery current sensor signal)	Ground	Above 2.3 at least once	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-268, "Diagnosis Procedure"

Diagnosis Procedure

INFOID:0000000003858140

1. CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- 2. Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2. CHECK BATTERY CURRENT SENSOR POWER SUPPLY CIRCUIT

- Disconnect battery current sensor harness connector.
- Turn ignition switch ON.
- 3. Check the voltage between battery current sensor harness connector and ground.

Battery cur	rent sensor	Ground	Voltage (V)
Connector Terminal		Glound	voltage (v)
F76	1	Ground	Approx. 5

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

3.check battery current sensor ground circuit for open and short

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- 3. Check the continuity between battery current sensor harness connector and ECM harness connector.

Battery cur	rrent sensor	E(Continuity	
Connector	Terminal	Connector Terminal		Continuity
F76	2	F8	44	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4. CHECK BATTERY CURRENT SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between battery current sensor harness connector and ECM harness connector.

Battery cur	rrent sensor	E	Continuity	
Connector	Terminal	Connector Terminal		Continuity
F76	3	F8	42	Existed

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

P1554 BATTERY CURRENT SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Α

EC

D

Е

F

Н

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK BATTERY CURRENT SENSOR

Refer to EC-269, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace battery negative cable assembly.

6. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003858141

1. CHECK BATTERY CURRENT SENSOR

- 1. Turn ignition switch OFF.
- 2. Reconnect harness connectors disconnected.
- 3. Disconnect battery negative cable (1).

: Vehicle front

: To body ground

- 4. Install jumper cable (A) between battery negative terminal and body ground.
- 5. Turn ignition switch ON.
- 6. Check the voltage between ECM harness connector terminals under the following conditions.

ALBIA0076ZZ

Connector	+	_	Voltage (V)
Connector	Terminal	Terminal	
F8	42 (Battery current sensor signal)	44 (Sensor ground)	Approx. 2.5

Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to PG-3, "How to Handle Battery".

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace battery negative cable assembly.

M

Ν

[VQ25DE, VQ35DE]

P1564 ASCD STEERING SWITCH

Description INFOID.000000003856749

ASCD steering switch has variant values of electrical resistance for each button. ECM reads voltage variation of switch, and determines which button is operated.

Refer to EC-51, "System Diagram" for the ASCD function.

DTC Logic

DTC DETECTION LOGIC

NOTE:

If DTC P1564 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to EC-240, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1564	ASCD steering switch	 An excessively high voltage signal from the ASCD steering switch is sent to ECM. ECM detects that input signal from the ASCD steering switch is out of the specified range. ECM detects that the ASCD steering switch is stuck ON. 	 Harness or connectors (The switch circuit is open or shorted.) ASCD steering switch ECM

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Turn ignition switch ON and wait at least 10 seconds.
- 2. Press MAIN switch for at least 10 seconds, then release it and wait at least 10 seconds.
- 3. Press CANCEL switch for at least 10 seconds, then release it and wait at least 10 seconds.
- Press RESUME/ACCELERATE switch for at least 10 seconds, then release it and wait at least 10 seconds
- 5. Press SET/COAST switch for at least 10 seconds, then release it and wait at least 10 seconds.
- Check DTC.

Is DTC detected?

YES >> Go to EC-270, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856751

1.CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.check ascd steering switch circuit

(P) With CONSULT-III

- 1. Turn ignition switch ON.
- Select "MAIN SW", "CANCEL SW", "RESUME/ACC SW" and "SET SW" in "DATA MONITOR" mode with CONSULT-III.

< COMPONENT DIAGNOSIS >

3. Check each item indication under the following conditions.

Monitor item	Condition		Indication
MAIN SW	MAIN switch	Pressed	ON
MAIN SW	WAIN SWILCH	Released	OFF
CANCEL SW	CANCEL switch	Pressed	ON
CANCLL SW	CANCEL SWILLI	Released	OFF
RESUME/ACC SW	RESUME/ACCEL-	Pressed	ON
KLGOWIL/ACC GW	ERATE switch	Released	OFF
SET SW	SET/COAST switch	Pressed	ON
SET SW	SET/COAST SWILLI	Released	OFF

Without CONSULT-III

- Turn ignition switch ON.
- 2. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM				
Con-	+	_	Condition	Voltage (V)	
nector	Terminal	Terminal			
	85 (ASCD steering switch signal)	92 (ASCD steering switch ground)	MAIN switch: Pressed	Approx. 0	
			CANCEL switch: Pressed	Approx. 1	
E16			SET/COAST switch: Pressed	Approx. 2	
			RESUME/ACCELERATE switch: Pressed	Approx. 3	
			All ASCD steering switches: Released	Approx. 4	

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 3.

3.check ascd steering switch ground circuit for open and short

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Disconnect combination switch harness connector.
- Check the continuity between combination switch and ECM harness connector.

Combina	Combination switch		ECM		
Connector	Terminal	Connector Terminal		Continuity	
M33	16	E16	92	Existed	

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M11, E105
- Combination switch (spiral cable)
- · Harness for open and short between ECM and combination switch

>> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK ASCD STEERING SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between combination switch and ECM harness connector.

EC

Α

D

Е

F

G

Ы

.

L

IV

Ν

0

< COMPONENT DIAGNOSIS >

Combina	Combination switch		ECM		
Connector	Terminal	Connector Terminal		Continuity	
M33	13	E16	85	Existed	

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 7. NO >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M11, E105
- Combination switch (spiral cable)
- Harness for open and short between ECM and combination switch

>> Repair open circuit, short to ground or short to power in harness or connectors.

7. CHECK ASCD STEERING SWITCH

Refer to EC-272, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace ASCD steering switch.

8. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003856752

1. CHECK ASCD STEERING SWITCH

- 1. Turn ignition switch OFF.
- 2. Disconnect combination switch (spiral cable) harness connector.
- 3. Check resistance between combination switch harness connector terminals as per the following.

Combinat	ion switch	Condition	Resistance [Ω]	
Connector	Terminals	Condition		
		MAIN switch: Pressed	Approx. 0	
		CANCEL switch: Pressed	Approx. 250	
M33	13 and 16	SET/COAST switch: Pressed	Approx. 660	
		RESUME/ACCELERATE switch: Pressed	Approx. 1,480	
		All ASCD steering switches: Released	Approx. 4,000	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ASCD steering switch

[VQ25DE, VQ35DE]

P1572 ASCD BRAKE SWITCH

Description INFOID:0000000003856753

When the brake pedal is depressed, ASCD brake switch is turned OFF and stop lamp switch is turned ON. ECM detects the state of the brake pedal by two kinds of input (ON/OFF signal).

Refer to EC-51, "System Diagram" for the ASCD function.

DTC Logic INFOID:0000000003856754

DTC DETECTION LOGIC

NOTE:

- If DTC P1572 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to EC-240, "DTC Logic".
- This self-diagnosis has the one trip detection logic. When malfunction A is detected, DTC is not stored in ECM memory. And in that case, 1st trip DTC and 1st trip freeze frame data are displayed. 1st trip DTC is erased when ignition switch is turned OFF. And even when malfunction A is detected in two consecutive trips, DTC is not stored in ECM memory.

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
		A)	When the vehicle speed is above 30 km/h (19 MPH), ON signals from the stop lamp switch and the ASCD brake switch are sent to the ECM at the same time.	(The ASCD brake switch circuit is shorted.)
P1572	ASCD brake switch	B)	ASCD brake switch signal is not sent to ECM for extremely long time while the vehicle is being driver.	 Stop lamp switch ASCD brake switch Incorrect stop lamp switch installation Incorrect ASCD brake switch installation ECM

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

NOTE:

Procedure for malfunction B is not described here. It takes extremely long time to complete procedure for malfunction B. By performing procedure for malfunction A, the incident that causes malfunction B can be detected.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

(P)With CONSULT-III

- 1. Start engine (VDC switch OFF).
- Select "DATA MONITOR" mode with CONSULT-III.
- 3. Press MAIN switch and check that CRUISE lamp illuminates.
- 4. Drive the vehicle for at least 5 consecutive seconds under the following conditions.

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

VHCL SPEED SE	More than 30 km/h (19 mph)
Selector lever	Suitable position

Check 1st trip DTC.

EC-273

EC

Α

D

F

Н

K

L

M

N

[VQ25DE, VQ35DE]

< COMPONENT DIAGNOSIS >

Follow the procedure "With CONSULT-III" above.

Is 1st trip DTC detected?

YES >> Go to EC-274, "Diagnosis Procedure".

NO >> GO TO 3.

3.PERFORM DTC CONFIRMATION PROCEDURE

(P)With CONSULT-III

1. Drive the vehicle for at least 5 consecutive seconds under the following conditions.

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

VHCL SPEED SE	More than 30 km/h (19 mph)
Selector lever	Suitable position
Driving location	Depress the brake pedal for more than 5 seconds so as not to come off from the above-mentioned vehicle speed.

2. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT-III" above.

Is 1st trip DTC detected?

YES >> Go to EC-274, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856755

1. CHECK OVERALL FUNCTION-I

(P) With CONSULT-III

- 1. Turn ignition switch ON.
- 2. Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-III.
- 3. Check "BRAKE SW1" indication under the following conditions.

Monitor item	Condition	Indication	
BRAKE SW1	Brake pedal	Slightly depressed	OFF
Brake pedal		Fully released	ON

⋈ Without CONSULT-III

- 1. Turn ignition switch ON.
- 2. Check the voltage between ECM harness connector and ground.

ECM							
+		_		Condition		Voltage	
Connector	Terminal	Connector	Terminal				
E16	110	E16	112	Brake pedal	Slightly depressed	Approx. 0V	
	(ASCD brake switch signal)		112	biane pedal	Fully released	Battery voltage	

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK OVERALL FUNCTION-II

(P) With CONSULT-III

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

< COMPONENT DIAGNOSIS >

Monitor item	Co	Indication	
BRAKE SW2	Brake podal	Slightly depressed	ON
	Brake pedal	Fully released	OFF

EC

Α

Without CONSULT-III

Check the voltage between ECM harness connector and ground.

ECM						
+		_		Condition		Voltage
Connector	Terminal	Connector	Terminal			
E16	106	E16	112	Brake pedal	Slightly depressed	Battery voltage
L10	(Stop lamp switch signal)	al) E16 112		Біаке рецаі	Fully released	Approx. 0V

D

Е

Is the inspection result normal?

YES >> GO TO 12. NO >> GO TO 7.

F

3.check ascd brake switch power supply circuit

- 1. Turn ignition switch OFF.
- Disconnect ASCD brake switch harness connector.
- 3. Turn ignition switch ON.
- 4. Check the voltage between ASCD brake switch harness connector and ground.

ASCD brake switch		Ground	Voltage	
Conne	onnector Terminal		Giodila	voltage
E49	9	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5. NO >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Κ

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse (No.3)
- · Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit, short to ground or short to power in harness or connectors.

M

$5. \mathsf{CHECK}$ ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.

Ν

3. Check the continuity between ASCD brake switch harness connector and ECM harness connector.

Existed

ASCD brake switch ECM Connector Terminal Connector Terminal

E16

Р

4.	Also ch	neck harnes	ss for short	to ground	and short to	power.

110

Is the inspection result normal?

YES >> GO TO 6.

E49

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

O.CHECK ASCD BRAKE SWITCH

Refer to EC-277, "Component Inspection (ASCD Brake Switch)"

[VQ25DE, VQ35DE]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 12.

NO >> Replace ASCD brake switch.

7.CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect stop lamp switch harness connector.
- 3. Check the voltage between stop lamp switch harness connector and ground.

Stop lan	np switch	Ground	Voltage
Connector Terminal		Ground	voltage
E115	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse (No.7)
- · Harness for open or short between stop lamp switch and battery

>> Repair open circuit, short to ground or short to power in harness or connectors.

$9. \mathsf{CHECK}$ STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Disconnect ECM harness connector.
- 2. Check the continuity between stop lamp switch harness connector and ECM harness connector.

Stop lamp switch		ECM		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E115	2	E16	106	Existed

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 11.

NO >> GO TO 10.

10. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- Harness for open or short between stop lamp switch and ECM

>> Repair open circuit, short to ground or short to power in harness or connectors.

11. CHECK STOP LAMP SWITCH

Refer to EC-277, "Component Inspection (Stop Lamp Switch)"

Is the inspection result normal?

YES >> GO TO 12.

NO >> Replace stop lamp switch.

12. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

P1572 ASCD BRAKE SWITCH

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Component Inspection (ASCD Brake Switch)

INFOID:0000000003856756

1. CHECK ASCD BRAKE SWITCH-I

- Turn ignition switch OFF.
- 2. Disconnect ASCD brake switch harness connector.
- Check the continuity between ASCD brake switch terminals under the following conditions.

Terminals	Condition		Continuity
1 and 2	Brake pedal	Fully released.	Existed
	Drake pedal	Slightly depressed.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK ASCD BRAKE SWITCH-II

- Adjust ASCD brake switch installation. Refer to BR-6, "Inspection and Adjustment".
- 2. Check the continuity between ASCD brake switch terminals under the following conditions.

Terminals		Condition	Continuity
1 and 2	Brake pedal	Fully released.	Existed
i and z	brake pedar	Slightly depressed.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ASCD brake switch.

Component Inspection (Stop Lamp Switch)

INFOID:0000000003856757

1.CHECK STOP LAMP SWITCH-I

- Turn ignition switch OFF.
- Disconnect stop lamp switch harness connector.
- Check harness continuity between stop lamp switch terminals under the following conditions.

Terminals	C	Continuity	
1 and 2	Brake pedal	Fully released	Not existed
	Diake pedai	Slightly depressed	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK STOP LAMP SWITCH-II

- Adjust stop lamp switch installation. Refer to BR-6, "Inspection and Adjustment".
- Check harness continuity between stop lamp switch terminals under the following conditions.

Terminals	C	Continuity	
1 and 2	Brake pedal	Fully released	Not existed
	Brake pedar	Slightly depressed	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch.

EC-277

EC

Α

D

Е

F

Н

K

L

M

Ν

< COMPONENT DIAGNOSIS >

P1574 ASCD VEHICLE SPEED SENSOR

Description INFOID:0000000003856758

The ECM receives two vehicle speed signals via CAN communication line. One is sent from combination meter, and the other is from TCM (Transmission control module). The ECM uses these signals for ASCD control. Refer to EC-51, "System Diagram" for ASCD functions.

DTC Logic INFOID:0000000003856759

DTC DETECTION LOGIC

- If DTC P1574 is displayed with DTC U1000, U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to EC-135, "DTC Logic".
- If DTC P1574 is displayed with DTC P0500, first perform the trouble diagnosis for DTC P0500. Refer to EC-234, "DTC Logic".
- If DTC P1574 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to EC-240, "DTC Logic".
- If DTC P1574 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to EC-242. "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1574	ASCD vehicle speed sensor	The difference between the two vehicle speed signals is out of the specified range.	Harness or connectors (The CAN communication line is open or shorted.) Combination meter ABS actuator and electric unit (control unit) Wheel sensor TCM ECM

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Start engine (VDC switch OFF).
- Drive the vehicle at more than 40 km/h (25 MPH).

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

3. Check DTC.

Is DTC detected?

YES >> Go to EC-278, "Diagnosis Procedure".

>> INSPECTION END NO

Diagnosis Procedure

INFOID:0000000003856760

[VQ25DE, VQ35DE]

1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to TM-35, "Diagnosis Description".

Is the inspection result normal?

YES >> GO TO 2.

P1574 ASCD VEHICLE SPEED SENSOR < COMPONENT DIAGNOSIS >	[VQ25DE, VQ35DE]	
NO >> Perform trouble shooting relevant to DTC indicated.		
2.CHECK DTC WITH "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"		A
Refer to BRC-80, "CONSULT-III Function".		
Is the inspection result normal?		EC
YES >> GO TO 3.		LO
NO >> Repair or replace malfunctioning part.		
3.CHECK COMBINATION METER FUNCTION		С
Refer to MWI-33, "CONSULT-III Function (METER/M&A)".		
>> INSPECTION END		D
		Е
		F
		0
		G
		Н
		I
		J
		K
		L
		M
		Ν
		0

P1700 CVT CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P1700 CVT CONTROL SYSTEM

Description INFOID:000000003856761

This DTC is displayed with other DTC regarding TCM. Perform the trouble diagnosis for corresponding DTC. Refer to EC-389, "DTC Index". When this DTC is detected, the ASCD control is canceled.

P1715 INPUT SPEED SENSOR (PRIMARY SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P1715 INPUT SPEED SENSOR (PRIMARY SPEED SENSOR)

Description INFOID:000000003856762

ECM receives primary speed sensor signal from TCM through CAN communication line. ECM uses this signal for engine control.

INFOID:0000000003856763

Α

EC

F

Н

L

N

Р

DTC Logic

DTC DETECTION LOGIC

NOTE:

- If DTC P1715 is displayed with DTC U1000, U1001 first perform the trouble diagnosis for DTC U1000, U1001. Refer to <u>EC-135</u>, "<u>DTC Logic"</u>.
- If DTC P1715 is displayed with DTC P0335, first perform the trouble diagnosis for DTC P0335. Refer to EC-218, "DTC Logic".
- If DTC P1715 is displayed with DTC P0340, P0345, first perform the trouble diagnosis for DTC P0340, P0345. Refer to <u>EC-222, "DTC Logic"</u>.
- If DTC P1715 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to <u>EC-240</u>, "<u>DTC Logic</u>".
- If DTC P1715 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to EC-242, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1715	Input speed sensor (Primary speed sensor) (TCM output)	Primary speed sensor signal is different from the theoretical value calculated by ECM from secondary sensor signal and engine rpm signal.	Harness or connectors (The CAN communication line is open or shorted) Harness or connectors (Primary speed sensor circuit is open or shorted) TCM

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Start engine.
- 2. Drive vehicle at a speed of more than 50 km/h (31 MPH) for at least 5 seconds.
- 3. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-281, "Diagnosis Procedure".

NO >> INSPECTION END

INFOID:0000000003856764

Diagnosis Procedure 1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to TM-121, "DTC Index".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble shooting relevant to DTC indicated.

2.REPLACE TCM

Replace TCM. Refer to TM-153, "Removal and Installation".

EC-281

P1715 INPUT SPEED SENSOR (PRIMARY SPEED SENSOR)

[VQ25DE, VQ35DE]

< COMPONENT DIAGNOSIS >

CHEITI BIRTOTTOS

>> INSPECTION END

[VQ25DE, VQ35DE]

INFOID:0000000003856766

P1720 VSS

Description

ECM receives two vehicle speed signals via the CAN communication line. One is sent from "ABS actuator and electric unit (control unit)" via combination meter, and the other is from TCM (Transmission control module). ECM uses these signals for engine control.

d EC

D

Е

Α

DTC Logic

DTC DETECTION LOGIC

NOTE:

• If DTC P1720 is displayed with DTC U1000, U1001 first perform the trouble diagnosis for DTC U1000, U1001. Refer to EC-135, "DTC Logic".

 If DTC P1720 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to <u>EC-242</u>, "<u>DTC Logic"</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	F
P1720	Vehicle speed sensor (TCM output)	The difference between two vehicle speed signals is out of the specified range.	Harness or connectors (Secondary speed sensor circuit is open or shorted.) Harness or connectors (Wheel sensor circuit is open or shorted.) TCM Secondary speed sensor ABS actuator and electric unit (control unit) Wheel sensor Combination meter	G

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

K

M

Ν

Р

2.PERFORM DTC CONFIRMATION PROCEDURE

- Start engine.
- Drive vehicle at a speed of 20 km/h (12 MPH) or more for at least 5 seconds without depressing the brake pedal.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-283, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856767

1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to TM-121, "DTC Index".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble shooting relevant to DTC indicated.

2.CHECK DTC WITH "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"

Refer to BRC-140, "DTC No. Index".

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform trouble shooting relevant to DTC indicated.

3.check combination meter function

Refer to MWI-67, "DTC Index".

>> INSPECTION END

P1800 VIAS CONTROL SOLENOID VALVE 1

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P1800 VIAS CONTROL SOLENOID VALVE 1

Description INFOID:0000000003856768

The VIAS control solenoid valve 1 cuts the intake manifold vacuum signal for power valve 1 control. It responds to ON/OFF signals from the ECM. When the solenoid is OFF, the vacuum signal from the intake manifold is cut. When the ECM sends an ON signal the coil pulls the plunger downward and sends the vacuum signal to the power valve actuator 1.

INFOID:0000000003856769

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1800	VIAS control solenoid valve 1 circuit	An excessively low or high voltage signal is sent to ECM through the VIAS control solenoid valve 1.	Harness or connectors (The solenoid valve 1 circuit is open or shorted.) VIAS control solenoid valve 1

DTC CONFIRMATION PROCEDURE

1.CONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for at least 5 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-285, "Diagnosis Procedure".

>> INSPECTION END NO

Diagnosis Procedure ${f 1}$.CHECK VIAS CONTROL SOLENOID VALVE 1 POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- 2. Disconnect VIAS control solenoid valve 1 harness connector.
- Turn ignition switch ON.
- Check the voltage between VIAS control solenoid valve 1 harness connector and ground.

VIAS control solenoid valve 1		Ground	Voltage
Connector	Terminal	Giodila	vollage
F74	1	Ground	Battery voltage

Is the inspection result normal?

YFS >> GO TO 2.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

2.CHECK VIAS CONTROL SOLENOID VALVE 1 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check the continuity between VIAS control solenoid valve 1 harness connector and ECM harness connector.

EC

Α

D

Е

Н

K

INFOID:0000000003856770

< COMPONENT DIAGNOSIS >

VIAS control s	olenoid valve 1	ECM		Continuity
Connector	Terminal	Connector	Terminal	Continuity
F74	2	F7	27	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

3.CHECK VIAS CONTROL SOLENOID VALVE 1

Refer to EC-286, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace VIAS control solenoid valve 1.

4. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection


INFOID:0000000003856771

1. CHECK VIAS CONTROL SOLENOID VALVE 1

(P)With CONSULT-III

- Turn ignition switch OFF.
- 2. Reconnect all harness connectors disconnected.
- 3. Disconnect vacuum hoses connected to VIAS control solenoid valve 1.
- 4. Turn ignition switch ON.
- 5. Select "VIAS S/V-1" in "ACTIVE TEST" mode with CONSULT-III.
- 6. Check air passage continuity and operation delay time under the following conditions.


Condition (VIAS S/V 1)	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
ON	Existed	Not existed
OFF	Not existed	Existed



®Without CONSULT-III


- 1. Turn ignition switch OFF.
- 2. Disconnect VIAS control solenoid valve 1 harness connector.
- 3. Disconnect vacuum hoses connected to VIAS volume control solenoid valve 1.
- 4. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)	
12 V direct current supply between terminals 1 and 2	Existed	Not existed	
No supply	Not existed	Existed	



>> INSPECTION END

YES



P1800 VIAS CONTROL SOLENOID VALVE 1

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

NO >> Replace VIAS control solenoid valve 1

Α

EC

С

D

Е

F

G

Н

1

J

Κ

L

M

Ν

0

[VQ25DE, VQ35DE]

P1801 VIAS CONTROL SOLENOID VALVE 2

Description

The VIAS control solenoid valve 2 cuts the intake manifold vacuum signal for power valve 2 control. It responds to ON/OFF signals from the ECM. When the solenoid is OFF, the vacuum signal from the intake manifold is cut. When the ECM sends an ON signal the coil pulls the plunger downward and sends the vacuum signal to the power valve actuator 2.

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1801	VIAS control solenoid valve 2 circuit	An excessively low or high voltage signal is sent to ECM through the VIAS control solenoid valve 2.	Harness or connectors (The solenoid valve 2 circuit is open or shorted.) VIAS control solenoid valve 2

DTC CONFIRMATION PROCEDURE

1.conditioning

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Start engine and let it idle for at least 5 seconds.
- 2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to EC-288, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856774

1. CHECK VIAS CONTROL SOLENOID VALVE 2 POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- 2. Disconnect VIAS control solenoid valve 2 harness connector.
- Turn ignition switch ON.
- 4. Check the voltage between VIAS control solenoid valve 2 harness connector and ground.

VIAS control solenoid valve 2		Ground	Voltage
Connector	Terminal	Giodila	voltage
F75	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

2.CHECK VIAS CONTROL SOLENOID VALVE 2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check the continuity between VIAS control solenoid valve 2 harness connector and ECM harness connector.

P1801 VIAS CONTROL SOLENOID VALVE 2

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

VIAS control s	olenoid valve 2	ECM		Continuity
Connector	Terminal	Connector	Terminal	Continuity
F75	2	F7	26	Existed

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 3.

>> Repair open circuit, short to ground or short to power in harness or connectors. NO

$oldsymbol{3}.$ CHECK VIAS CONTROL SOLENOID VALVE 2

Refer to EC-289, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace VIAS control solenoid valve 2.

4. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END


Component Inspection

1. CHECK VIAS CONTROL SOLENOID VALVE 2

(P)With CONSULT-III

- 1. Turn ignition switch OFF.
- Reconnect all harness connectors disconnected.
- 3. Disconnect vacuum hoses connected to VIAS control solenoid valve 2.
- 4. Turn ignition switch ON.
- 5. Select "VIAS S/V-2" in "ACTIVE TEST" mode with CONSULT-III.
- 6. Check air passage continuity and operation delay time under the following conditions.

Condition (VIAS S/V 2)	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
ON	Existed	Not existed
OFF	Not existed	Existed




Without CONSULT-III

- 1. Turn ignition switch OFF.
- 2. Disconnect VIAS control solenoid valve 2 harness connector.
- Disconnect vacuum hoses connected to VIAS volume control solenoid valve 2.
- 4. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12 V direct current supply between terminals 1 and 2	Existed	Not existed
No supply	Not existed	Existed

Is the inspection result normal?

YES >> INSPECTION END



Α

EC

D

Е

INFOID:0000000003856775

Ν

P1801 VIAS CONTROL SOLENOID VALVE 2

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

NO >> Replace VIAS control solenoid valve 2

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P1805 BRAKE SWITCH

Description INFOID:0000000003856776

Brake switch signal is applied to the ECM through the stop lamp switch when the brake pedal is depressed. This signal is used mainly to decrease the engine speed when the vehicle is being driver.

INFOID:0000000003856777

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1805	Brake switch	A brake switch signal is not sent to ECM for extremely long time while the vehicle is being driver.	(Stop Jamp switch circuit is open or sport-

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Fully depress the brake pedal for at least 5 seconds.
- Erase the DTC.
- Check 1st trip DTC.

Is 1st trip DTC detected?

>> Go to EC-291, "Diagnosis Procedure". YES

>> INSPECTION END NO

Diagnosis Procedure

1. CHECK STOP LAMP SWITCH CIRCUIT

- Turn ignition switch OFF.
- Check the stop lamp when depressing and releasing the brake pedal.

Brake pedal	Stop lamp
Fully released	Not illuminated
Slightly depressed	Illuminated

Is the inspection result normal?

YES >> GO TO 4. NO >> GO TO 2.

2.CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

- Disconnect stop lamp switch harness connector.
- Check the voltage between stop lamp switch harness connector and ground.

Stop lan	np switch	Ground	Voltage	
Connector	Terminal	Giodila	voltage	
E115	1	Ground	Battery voltage	

Is the inspection result normal?

YES >> GO TO 4. NO >> GO TO 3.

3.DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse (No.7)

EC

D

Е

Α

F

Н

INFOID:0000000003856778

M

Ν

< COMPONENT DIAGNOSIS >

- Harness for open or short between battery and stop lamp switch
 - >> Repair open circuit, short to ground or short to power in harness or connectors.

4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Disconnect stop lamp switch harness connector.
- Disconnect ECM harness connector.
- Check the continuity between stop lamp switch harness connector and ECM harness connector.

Stop lan	np switch	E	CM	Continuity
Connector	Terminal	Connector	Terminal	Continuity
E115	2	E16	106	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 6. NO >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- · Harness for open or short between ECM and stop lamp switch
 - >> Repair open circuit, short to ground or short to power in harness or connectors.

6. CHECK STOP LAMP SWITCH

Refer to EC-292, "Component Inspection (Stop Lamp Switch)".

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace stop lamp switch.

7.CHECK INTERMITTENT INCIDENT

Refer to GI-35. "Intermittent Incident".

>> INSPECTION END

Component Inspection (Stop Lamp Switch)

INFOID:0000000003858144

1. CHECK STOP LAMP SWITCH-I

- 1. Turn ignition switch OFF.
- 2. Disconnect stop lamp switch harness connector.
- 3. Check harness continuity between stop lamp switch terminals under the following conditions.

Terminals	C	Continuity	
1 and 2	Brake pedal	Fully released	Not existed
i aliu z	втаке редаг	Slightly depressed	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK STOP LAMP SWITCH-II

- 1. Adjust stop lamp switch installation. Refer to BR-6, "Inspection and Adjustment".
- 2. Check harness continuity between stop lamp switch terminals under the following conditions.

P1805 BRAKE SWITCH

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Terminals	C	Continuity	
1 and 2	1 and 2 Brake pedal	Fully released	Not existed
1 and 2		Slightly depressed	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch.

Α

EC

С

D

Е

F

G

Н

1

J

K

L

M

Ν

0

P2100, P2103 THROTTLE CONTROL MOTOR RELAY

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P2100, P2103 THROTTLE CONTROL MOTOR RELAY

Description

Power supply for the throttle control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is controlled ON/OFF by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2100	Throttle control motor relay circuit open	ECM detects that the voltage of power source for throttle control motor is excessively low.	Harness or connectors (Throttle control motor relay circuit is open) Throttle control motor relay
P2103	Throttle control motor relay circuit short	ECM detects that the throttle control motor relay is stuck ON.	Harness or connectors (Throttle control motor relay circuit is shorted) Throttle control motor relay

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V.

Witch DTC is detected?

P2100 >> GO TO 2.

P2103 >> GO TO 3.

2.PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P2100

- 1. Turn ignition switch ON and wait at least 2 seconds.
- 2. Start engine and let it idle for 5 seconds.
- 3. Check DTC.

Is DTC detected?

YES >> Go to EC-294, "Diagnosis Procedure".

NO >> INSPECTION END

3.PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P2103

- Turn ignition switch ON and wait at least 1 second.
- Check DTC.

Is DTC detected?

YES >> Go to EC-294, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856782

1. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- 3. Disconnect IPDM E/R harness connector.
- Check the continuity between IPDM E/R harness connector and ECM harness connector.

P2100, P2103 THROTTLE CONTROL MOTOR RELAY

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

IPDM E/R		EC	CM	Continuity	
Connector	Terminal	Connector	Terminal	Continuity	_
F12	70	F7	15	Existed	
		r short to grou	nd and short	to power.	
	ion result nor	mal?			
	O TO 2.	irquit short to	around or ch	ort to nower in	harness or connectors.
_			•	NPUT SIGNAL	
. Check th	e continuity b	etween IPDM	E/R harness	connector and	ECM harness connector.
IPDI	И E/R	EC	·M		-
Connector	Terminal	Connector	Terminal	Continuity	
F12	54	F7	2	Existed	_
	_	r short to grou			-
	ion result nor	_	iiu aiiu siiUll	to power.	
-	30 TO 3.	mar:			
		ircuit, short to	ground or sh	ort to power in	harness or connectors.
.CHECK F				•	
		No. 51) from I	PDM F/R		
	15A fuse is bl		DIVI 2/14.		
s the inspect	ion result nor	mal?			
	O TO 4.				
4	Replace 15A f				
+.CHECK IN	ITERMITTEN	IT INCIDENT			
· · · · · · · · · · · · · · · · · · ·	<u>5, "Intermitter</u>				
-	ion result nor				
	Replace IPDM		connectors		
NO >> F	kepali oi repia	ace harness o	connectors.		

EC-295

P2101 ELECTRIC THROTTLE CONTROL FUNCTION

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P2101 ELECTRIC THROTTLE CONTROL FUNCTION

Description

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc.

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The current opening angle of the throttle valve is detected by the throttle position sensor. The throttle position sensor provides feedback to the ECM, when opens/closes the throttle valve in response to driving conditions via the throttle control motor.

DTC Logic

DTC DETECTION LOGIC

NOTE:

If DTC P2101 is displayed with DTC P2100, first perform the trouble diagnosis for DTC P2100. Refer to EC-294, "DTC Logic".

If DTC P2101 is displayed with DTC 2119, first perform the trouble diagnosis for DTC P2119. Refer to <u>EC-302, "DTC Logic"</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2101	Electric throttle control performance	Electric throttle control function does not operate properly.	Harness or connectors (Throttle control motor circuit is open or shorted) Electric throttle control actuator

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V when engine is running.

>> GO TO 2.

2.perform dtc confirmation procedure

- 1. Turn ignition switch ON and wait at least 2 seconds.
- 2. Start engine and let it idle for 5 seconds.
- Check DTC.

Is DTC detected?

YES >> Go to EC-296, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000003856785

CHECK GROUND CONNECTION

- 1. Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-I

1. Check the voltage between ECM harness connector and ground.

P2101 ELECTRIC THROTTLE CONTROL FUNCTION

COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Ν

Р

< COMPON	NENT DI	AGNOSIS	S >				[VQ25DE, VQ35DE]	
ECN	M							
Connector	Terminal	Ground	Cond	dition		Voltage		
			Ignition sv	vitch OFF	Α	Approx. 0 V		E
F7	2	Ground	Ignition s	witch ON	Ва	ttery voltage		
Is the inspe			?					
	GO TO 7							
_	GO TO 3		-DOL MO-	TOD DEI	۱ ۸۸		DLV CIDCUIT II	
			ROL MO	IOR REI	_A1 1		PLY CIRCUIT-II	
	nition swinect ECM		connecto	r.				
3. Disconr	nect IPDN	Ͷ E/R har	ness conr	ector.				
4. Check t	the contir	nuity betw	een IPDM	E/R har	ness	connector an	d ECM harness connector.	
IPI	DM E/R		F	CM			_	
Connector	Term	ninal (Connector	Termir	nal	Continuity		
F12	70	0	F7	15		Existed	_	
5. Also ch	eck harne	ess for sh	ort to grou	ind and	short	to power.	_	
s the inspe			?					
	GO TO 4		it abort to	around	or ob	art to namer i	n harness or connectors.	
	•	•	-	•		•	AL CIRCUIT-II	
1. Check t	ine contir	iuity betw	een ipdivi	E/R nar	ness	connector an	d ECM harness connector.	
IPI	DM E/R		E	CM			_	
Connector	Term	ninal (Connector	Termir	nal	Continuity		
F12	54	4	F7	2		Existed	_	
2. Also ch	eck harn	ess for sh	ort to grou	ind and	short	to power.	_	
s the inspe	ction resu	ult normal	?					
	GO TO 5		:		l		n hawa a a a a a a a a a a a a a a a a a	
_	•	pen circu	it, snort to	ground	or sh	oπ to power ir	n harness or connectors.	
5.check	FUSE							

- 1. Disconnect 15A fuse (No. 51) from IPDM E/R.
- 2. Check if 15A fuse is blown.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace 15A fuse.

6.CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace harness or connectors.

7.CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect electric throttle control actuator harness connector.
- Disconnect ECM harness connector.
- Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

< COMPONENT DIAGNOSIS >

Electric throttle	control actuator	ECI	M	Continuity	
Connector	Terminal	Connector Terminal		Continuity	
	5		5	Not existed	
F29	6	F7	6	Existed	
F29		1 7	5	Existed	
	0		6	Not existed	

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace malfunctioning part.

8. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY


- 1. Remove the intake air duct.
- 2. Check if foreign matter is caught between the throttle valve (1) and the housing.
 - 2: Electric throttle control actuator

Is the inspection result normal?

YES >> GO TO 9.

NO >>

>> Remove the foreign matter and clean the electric throttle control actuator inside.



9. CHECK THROTTLE CONTROL MOTOR

Refer to EC-298, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 10.

NO >> GO TO 11.

10. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace harness or connectors.

11. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- 2. Refer to EC-299, "Special Repair Requirement".

>> INSPECTION END

Component Inspection

INFOID:0000000003856786

1. CHECK THROTTLE CONTROL MOTOR

- Turn ignition switch OFF.
- 2. Disconnect electric throttle control actuator harness connector.
- 3. Check resistance between electric throttle control actuator terminals as per the following.

Terminals	Resistance
5 and 6	Approx. 1 - 15 Ω [at 25°C (77°F)]

Is the inspection result normal?

P2101 ELECTRIC THROTTLE CONTROL FUNCTION < COMPONENT DIAGNOSIS > [VQ25DE, VQ35]	DE1
YES >> INSPECTION END	
NO $>>$ GO TO 2. 2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR	А
 Replace electric throttle control actuator. Go to EC-299, "Special Repair Requirement". 	EC
>> INSPECTION END	С
Special Repair Requirement	0
1.PERFORM THROTTLE VALVE CLOSED POSITION LEARNING	D
Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement"	
>> GO TO 2. 2. PERFORM IDLE AIR VOLUME LEARNING	Е
Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement"	F
>> END	G
	Н
	I
	J
	K
	L
	M
	N
	0
	Р

< COMPONENT DIAGNOSIS >

P2118 THROTTLE CONTROL MOTOR

Description INFOID:000000003856788

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The current opening angle of the throttle valve is detected by the throttle position sensor. The throttle position sensor provides feedback to the ECM, when opens/closes the throttle valve in response to driving conditions via the throttle control motor.

DTC Logic INFOID:0000000003856789

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2118	Throttle control motor circuit short	ECM detects short in both circuits between ECM and throttle control motor.	Harness or connectors (Throttle control motor circuit is shorted.) Electric throttle control actuator (Throttle control motor)

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.perform dtc confirmation procedure

- Turn ignition switch ON and wait at least 2 seconds.
- Start engine and let it idle for 5 seconds.
- Check DTC.

Is DTC detected?

YES >> Go to EC-300, "DTC Logic".

>> INSPECTION END NO

Component Inspection

INFOID:0000000003858132

[VQ25DE, VQ35DE]

1.CHECK THROTTLE CONTROL MOTOR

- Turn ignition switch OFF.
- Disconnect electric throttle control actuator harness connector.
- Check resistance between electric throttle control actuator terminals as per the following.

Terminals	Resistance		
5 and 6	Approx. 1 - 15 Ω [at 25°C (77°F)]		

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.replace electric throttle control actuator

- Replace electric throttle control actuator.
- Go to EC-299, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

INFOID:0000000003858127

 ${f 1}$.PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

P2118 THROTTLE CONTROL MOTOR

[VQ25DE, VQ35DE] < COMPONENT DIAGNOSIS > Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement" Α >> GO TO 2. 2.PERFORM IDLE AIR VOLUME LEARNING EC Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement" >> END С D Е F G Н J Κ L M Ν 0

P2119 ELECTRIC THROTTLE CONTROL ACTUATOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

P2119 ELECTRIC THROTTLE CONTROL ACTUATOR

Description INFOID:000000003856793

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc.

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The throttle position sensor detects the throttle valve position, and the opening and closing speed of the throttle valve and sends the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and opens/closes the throttle valve in response to driving conditions via the throttle control motor.

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name		DTC detecting condition	Possible cause
P2119		A)	Electric throttle control actuator does not function properly due to the return spring malfunction.	
	Electric throttle control actuator	B)	Throttle valve opening angle in fail-safe mode is not in specified range.	Electric throttle control actuator
		C)	ECM detects that the throttle valve is stuck open.	

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.perform dtc confirmation procedure for malfunction a and b

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Selector lever position is D and wait at least 3 seconds.
- 3. Selector lever position is P.
- 4. Turn ignition switch OFF and wait at least 10 seconds.
- 5. Turn ignition switch ON and wait at least 1 second.
- 6. Selector lever position is D and wait at least 3 seconds.
- 7. Selector lever position is P.
- 8. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
- 9. Check DTC.

Is DTC detected?

YES >> Go to EC-303, "Diagnosis Procedure".

NO >> GO TO 3.

3.perform dtc confirmation procedure for malfunction ${ t c}$

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Selector lever position is D and wait at least 3 seconds.
- 3. Selector lever position is N or P.
- 4. Start engine and let it idle for 3 seconds.
- 5. Check DTC.

Is DTC detected?

YES >> Go to EC-303, "Diagnosis Procedure".

NO >> INSPECTION END

P2119 ELECTRIC THROTTLE CONTROL ACTUATOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Diagnosis Procedure

INFOID:0000000003858131

$1. \\ \text{check electric throttle control actuator visually}$


- 1. Turn ignition switch OFF.
- 2. Remove the intake air duct.
- 3. Check if foreign matter is caught between the throttle valve (1) and the housing.
 - 2: Electric throttle control actuator

Is the inspection result normal?

YES >> GO TO 2.

NO >> Remove

>> Remove the foreign matter and clean the electric throttle control actuator inside.



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- 2. Go to EC-255, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

INFOID:0000000003858128

1. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement"

>> GO TO 2.

2.PERFORM IDLE AIR VOLUME LEARNING

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement"

>> END

EC

Α

C

D

F

Е

G

K

M

Ν

0

INFOID:0000000003856799


P2122, P2123 APP SENSOR

Description

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometer which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and sends voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for engine operations such as fuel cut.



DTC Logic

DTC DETECTION LOGIC

NOTE:

If DTC P2122 or P2123 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P2122	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	Harness or connectors (APP sensor 1 circuit is open or shorted)	
P2123	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	Accelerator pedal position sensor (APP sensor 1)	

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Start engine and let it idle for 1 second.
- Check DTC.

Is DTC detected?

YES >> Go to EC-304, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- 2. Check ground connection E38. Refer to Ground Inspection in GI-37. "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

EC-304

NO >> Repair or replace ground connection.

$2.\mathsf{CHECK}$ APP SENSOR 1 POWER SUPPLY CIRCUIT

- 1. Disconnect accelerator pedal position (APP) sensor harness connector.
- 2. Turn ignition switch ON.
- 3. Check the voltage between APP sensor harness connector and ground.

	•	
_	v	

Е

F

M

N

Р

Α

APP	sensor	Ground	Voltage (V)	
Connector	Terminal	Ground		
E110	4	Ground	Approx. 5	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

3.CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between APP sensor harness connector and ECM harness connector.

APP :	sensor	E	Continuity	
Connector Terminal		Connector	Terminal	Continuity
E110	2	E16	84	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between APP sensor harness connector and ECM harness connector.

APP :	sensor	E	Continuity	
Connector	Connector Terminal		Connector Terminal	
E110	3	E16	81	Existed

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK APP SENSOR

Refer to EC-306, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6. REPLACE ACCELERATOR PEDAL ASSEMBLY

- 1. Replace accelerator pedal assembly.
- 2. Refer to EC-306, "Special Repair Requirement".

>> INSPECTION END

.CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003856800

1. CHECK ACCELERATOR PEDAL POSITION SENSOR

- 1. Reconnect all harness connectors disconnected.
- 2. Turn ignition switch ON.
- 3. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM			Condition			
+		_				Voltage (V)	
Connector	Terminal	Connector	Terminal				
	81 84			Fully released	0.5 - 1.0		
E16	(APP sensor 1 sig- nal)	(Sen	(Sensor ground)	Accelerator pedal	Fully depressed	4.2 - 4.8	
LIO	82	LIU	100	Accelerator pedar	Fully released	0.25 - 0.50	
	(APP sensor 2 sig- nal)		(Sensor ground)		Fully depressed	2.0 - 2.5	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.REPLACE ACCELERATOR PEDAL ASSEMBLY

- 1. Replace accelerator pedal assembly.
- 2. Go to EC-306, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

INFOID:0000000003856801

1. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

Refer to EC-15, "ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement".

>> GO TO 2.

2. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".

>> GO TO 3.

3. PERFORM IDLE AIR VOLUME LEARNING

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement".

>> END

P2127, P2128 APP SENSOR

Description INFOID:0000000003858145

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometer which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and sends voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for engine operations such as fuel cut.

Accelerator pedal position sensor Sensor 1 Sensor 2 → Depress Release -Accelerator pedal operation

DTC Logic

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P2127	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	Harness or connectors (APP sensor 2 circuit is open or shorted.) [CKP sensor (POS) circuit is shorted.]	ŀ
P2128	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	 (Refrigerant pressure sensor circuit is shorted.) Accelerator pedal position sensor (APP sensor 2) Crankshaft position sensor (POS) Refrigerant pressure sensor 	

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for 1 second.
- Check DTC.

Is DTC detected?

YES >> Go to EC-307, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

EC-307

EC

Α

D

INFOID:0000000003856803

K

M

N

INFOID:0000000003856804

2.check app sensor 2 power supply circuit-i

- 1. Disconnect accelerator pedal position (APP) sensor harness connector.
- 2. Turn ignition switch ON.
- Check the voltage between APP sensor harness connector and ground.

APP s	sensor	Ground	Voltage (V)	
Connector	Terminal	Ground	voitage (v)	
E110	5	Ground	Approx. 5	

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 3.

3.CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-II

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between APP sensor harness connector and ECM harness connector.

APP sensor		E	Continuity		
Connector	Terminal	Connector	Terminal	Continuity	
E110	5	E16	87	Existed	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit.

4. CHECK SENSOR POWER SUPPLY CIRCUIT

Check harness for short to power and short to ground, between the following terminals.

E	CM	Sensor		
Connector	Terminal	Name	Connector	Terminal
F8		Refrigerant pressure sensor	E300	1
		CKP sensor (POS)	F20	1
E16	87	APP sensor	E110	5

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair short to ground or short to power in harness or connectors.

5. CHECK COMPONENTS

Check the following.

- Crankshaft position sensor (POS) (Refer to EC-221. "Component Inspection".)
- Refrigerant pressure sensor (Refer to EC-348, "Diagnosis Procedure".)

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace malfunctioning components.

6.CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check the continuity between APP sensor harness connector and ECM harness connector.

APP sensor		ECM		Continuity
Connector	Terminal	Connector Terminal		Continuity
E110	1	E16	100	Existed

P2127, P2128 APP SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

Also check harness for short to ground and short to power.

Is the inspection result normal?

>> GO TO 7. YES

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

7.CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

Check the continuity between APP sensor harness connector and ECM harness connector.

APP sensor		ECM		Continuity	
Connector	Terminal	Connector Terminal		Continuity	
E110	6	E16	82	Existed	

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to EC-309, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 10.

NO >> GO TO 9.

9. REPLACE ACCELERATOR PEDAL ASSEMBLY

- Replace accelerator pedal assembly.
- Refer to EC-310, "Special Repair Requirement"

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

1. CHECK ACCELERATOR PEDAL POSITION SENSOR

- Reconnect all harness connectors disconnected.
- Turn ignition switch ON.
- Check the voltage between ECM harness connector terminals under the following conditions.

	ECM					
+		_		Condition		Voltage (V)
Connector	Terminal	Connector	Terminal			
	81		84		Fully released	0.5 - 1.0
E16	(APP sensor 1 sig- nal)	E16	(Sensor ground)	Accelerator padal	Fully depressed	4.2 - 4.8
E10	82	Accelerator pedal	Fully released	0.25 - 0.50		
	(APP sensor 2 sig- nal)		(Sensor ground)		Fully depressed	2.0 - 2.5

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.REPLACE ACCELERATOR PEDAL ASSEMBLY

EC-309

EC

Α

Е

K

INFOID:0000000003858146

N

P2127, P2128 APP SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

- 1. Replace accelerator pedal assembly.
- 2. Go to EC-310, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

INFOID:0000000003858147

1. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

Refer to EC-15, "ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement".

>> GO TO 2.

$2.\mathsf{PERFORM}$ THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".

>> GO TO 3.

3.PERFORM IDLE AIR VOLUME LEARNING

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement".


>> END

P2135 TP SENSOR

Description INFOID:0000000003857980

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has two sensors. These sensors are a kind of potentiometer which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and controls the throttle valve opening angle in response to driving conditions via the throttle control motor.



DTC Logic INFOID:0000000003856808

DTC DETECTION LOGIC

NOTE:

If DTC P2135 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2135	Throttle position sensor circuit range/performance	Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2.	Harness or connector (TP sensor 1 or 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 1 or 2)

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V at idle.

>> GO TO 2.

2.perform dtc confirmation procedure

- 1. Start engine and let it idle for 1 second.
- 2. Check DTC.

Is DTC detected?

YES >> Go to EC-311, "Diagnosis Procedure".

>> INSPECTION END NO

Diagnosis Procedure

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT-I

Disconnect electric throttle control actuator harness connector.

EC

Α

Е

Н

K

N

INFOID:0000000003856809

- Turn ignition switch ON.
- 3. Check the voltage between electric throttle control actuator harness connector and ground.

Electric throttle	control actuator	Ground	Voltage (V)	
Connector	Connector Terminal		voltage (v)	
F29	1	Ground	Approx. 5	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

3.check throttle position sensor ground circuit for open and short

- Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

Electric throttle control actuator		ECM		Continuity
Connector	Terminal	Connector Terminal		Continuity
F29	4	F8	36	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4.CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

Electric throttle control actuator		ECM		Continuity
Connector	Terminal	Connector	Terminal	Continuity
F29	2	F8	37	Existed
F29	3	го	38	Existed

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to EC-313, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6.REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- Refer to <u>EC-313</u>, "Special Repair Requirement"

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

INFOID:0000000003857981

INFOID:0000000003858129

Α

EC

C

D

Е

F

K

L

M

Ν

1. CHECK THROTTLE POSITION SENSOR

- 1. Turn ignition switch OFF.
- 2. Reconnect all harness connectors disconnected.
- 3. Perform EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".
- 4. Turn ignition switch ON.
- 5. Selector lever position is D.
- 6. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM					
Connector	+	+ -		Condition		
Connector	Terminal	Terminal				
	37 (TP sensor 1 signal) 38 (TP sensor 2	36 (Sensor ground)	Accelerator pedal	Fully released	More than 0.36 V	
F8				Fully depressed	Less than 4.75 V	
F6				Fully released	Less than 4.75 V	
	signal)			Fully depressed	More than 0.36 V	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- 1. Replace electric throttle control actuator.
- 2. Go to EC-162, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

1. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement"

>> GO TO 2.

2.PERFORM IDLE AIR VOLUME LEARNING

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement"

>> END

INFOID:0000000003856814


P2138 APP SENSOR

Description INFOID:0000000003858148

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometer which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and sends voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for engine operations such as fuel cut.



DTC Logic

DTC DETECTION LOGIC

NOTE:

If DTC P2138 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to EC-243, "DTC Logic".

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2138	Accelerator pedal position sensor circuit range/performance	Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2.	Harness or connector (APP sensor 1 or 2 circuit is open or shorted.) [CKP sensor (POS) circuit is shorted.] (Refrigerant pressure sensor circuit is shorted.) Accelerator pedal position sensor (APP sensor 1 or 2) Crankshaft position sensor (POS) Refrigerant pressure sensor

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Start engine and let it idle for 1 second.
- Check DTC.

Is DTC detected?

YES >> Go to EC-314, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

${f 1}$.CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- 2. Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

< COMPONENT DIAGNOSIS > [VQ25DE, VQ35DE]

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK SENSOR POWER SUPPLY CIRCUIT

- 1. Disconnect accelerator pedal position (APP) sensor harness connector.
- 2. Turn ignition switch ON.
- 3. Check the voltage between APP sensor harness connector and ground.

APP	sensor	Ground	Voltage (V)
Connector	Connector Terminal		voltage (v)
E110 4		Ground	Approx. 5

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

3. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-I

- 1. Turn ignition switch ON.
- 2. Check the voltage between APP sensor harness connector and ground.

APP :	sensor	Ground	Voltage (V)	
Connector Terminal		Giodila	voltage (v)	
E110 5		Ground	Approx. 5	

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 4.

4. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-II

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between APP sensor harness connector and ECM harness connector.

APP :	sensor	E	Continuity	
Connector	Terminal	Connector	Terminal	Continuity
E110	5	E16	87	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit.

5. CHECK SENSOR POWER SUPPLY CIRCUIT

Check harness for short to power and short to ground, between the following terminals.

E	CM	Sensor			
Connector	Terminal	Name	Connector	Terminal	
F8 72		Refrigerant pressure sensor	E300	1	
ГО	76	CKP sensor (POS)	F20	1	
E16	87	APP sensor	E110	5	

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair short to ground or short to power in harness or connectors.

6. CHECK COMPONENTS

Check the following.

_____ EC

Α

Ь

Е

F

Н

. .

J

K

L

 \mathbb{N}

Ν

0

D

INFOID:0000000003858149

< COMPONENT DIAGNOSIS >

- Crankshaft position sensor (POS) (Refer to EC-221, "Component Inspection".)
- Refrigerant pressure sensor (Refer to EC-348, "Diagnosis Procedure".)

Is the inspection result normal?

YES >> GO TO 11.

NO >> Replace malfunctioning components.

7.check app sensor ground circuit for open and short

- Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between APP sensor harness connector and ECM harness connector.

APP :	sensor	E	- Continuity	
Connector	Terminal	Connector Terminal		
E110	2	E16	84	Existed
EIIO	1	E10	100	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

8.CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between APP sensor harness connector and ECM harness connector.

APP	sensor	E	Continuity		
Connector Terminal		Connector Terminal		Continuity	
E110	3	E16	81	Existed	
LIIU	6	LIU	82	LXISIGU	

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

9.check app sensor

Refer to EC-316, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 11.

NO >> GO TO 10.

10. REPLACE ACCELERATOR PEDAL ASSEMBLY

- 1. Replace accelerator pedal assembly.
- Refer to EC-317, "Special Repair Requirement".

>> INSPECTION END

11. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection

1.CHECK ACCELERATOR PEDAL POSITION SENSOR

- 1. Reconnect all harness connectors disconnected.
- 2. Turn ignition switch ON.

3. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM						
+		_		Condition		Voltage (V)	
Connector	Terminal	Connector	Terminal				
	81		84 (Sensor ground)		Fully released	0.5 - 1.0	
E16	(APP sensor 1 sig- nal)	· ·		Accelerator pedal	Fully depressed	4.2 - 4.8	
LIU	82	LIU	100		Fully released	0.25 - 0.50	
	(APP sensor 2 sig- nal)		(Sensor ground)		Fully depressed	2.0 - 2.5	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. REPLACE ACCELERATOR PEDAL ASSEMBLY

- 1. Replace accelerator pedal assembly.
- 2. Go to EC-317, "Special Repair Requirement".

>> INSPECTION END

Special Repair Requirement

INFOID:0000000003858150

1. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

Refer to EC-15, "ACCELERATOR PEDAL RELEASED POSITION LEARNING: Special Repair Requirement".

>> GO TO 2.

2.PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to EC-16, "THROTTLE VALVE CLOSED POSITION LEARNING: Special Repair Requirement".

>> GO TO 3.

3. PERFORM IDLE AIR VOLUME LEARNING

Refer to EC-16, "IDLE AIR VOLUME LEARNING: Special Repair Requirement".

>> END

EC

Α

D

Е

F

Н

1

K

L

M

Ν


P2A00, P2A03 A/F SENSOR 1

Description INFOID:000000003856817


The air fuel ratio (A/F) sensor 1 is a planar one-cell limit current sensor. The sensor element of the A/F sensor 1 is composed an electrode layer, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement $\lambda = 1$, but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide λ range.

The exhaust gas components diffuse through the diffusion layer at the sensor cell. An electrode layer is applied voltage, and this current relative oxygen density in lean. Also this current relative hydrocarbon density in rich.



Therefore, the A/F sensor 1 is able to indicate air fuel ratio by this electrode layer of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of about 800°C (1,472°F).



DTC Logic

DTC DETECTION LOGIC

To judge the malfunction, the A/F signal computed by ECM from the A/F sensor 1 signal is monitored so it will not shift to LEAN side or RICH side.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P2A00	Air fuel ratio (A/F) sensor 1 (bank 1) circuit range/performance	Δ/F sensor 1 signal shifts to the lean side for a	A/F sensor 1 A/F sensor 1 heater Fuel pressure
P2A03	Air fuel ratio (A/F) sensor 1 (bank 2) circuit range/performance		• Fuel injector

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- Clear the mixture ratio self-learning value. Refer to <u>EC-18</u>, "MIXTURE RATIO SELF-LEARNING VALUE <u>CLEAR</u>: Special Repair Requirement".
- 2. Turn ignition switch OFF and wait at least 10 seconds.
- 3. Turn ignition switch ON.
- 4. Turn ignition switch OFF and wait at least 10 seconds.
- 5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for 1 minute under no load.

P2A00, P2A03 A/F SENSOR 1 [VQ25DE, VQ35DE] < COMPONENT DIAGNOSIS > Let engine idle for 1 minute. 7. Keep engine speed between 2,500 and 3,000 rpm for 20 minutes. Α 8. Check 1st trip DTC. Is 1st trip DTC detected? YES >> Go to EC-319, "Diagnosis Procedure". EC NO >> INSPECTION END Diagnosis Procedure INFOID:0000000003856819 1. CHECK GROUND CONNECTION Turn ignition switch OFF. D Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection". Is the inspection result normal? YES >> GO TO 2. Е NO >> Repair or replace ground connection. 2.RETIGHTEN A/F SENSOR 1 Loosen and retighten the A/F sensor 1. Refer to EM-34, "Removal and Installation". >> GO TO 3. 3.CHECK FOR INTAKE AIR LEAK Start engine and run it at idle. Listen for an intake air leak after the mass air flow sensor. Н Is intake air leak detected? YES >> GO TO 4. NO >> Repair or replace malfunctioning part. f 4 .CLEAR THE MIXTURE RATIO SELF-LEARNING VALUE Clear the mixture ratio self-learning value. Refer to EC-18, "MIXTURE RATIO SELF-LEARNING VALUE CLEAR: Special Repair Requirement". Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected? Is it difficult to start engine? K >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to EC-198, "DTC Logic" YES or EC-202, "DTC Logic". NO >> GO TO 5. 5. CHECK HARNESS CONNECTOR L Turn ignition switch OFF. Disconnect A/F sensor 1 harness connector.

Check harness connector for water.

Water should not exit.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness connector.

O.CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

- 1. Disconnect A/F sensor 1 harness connector.
- Turn ignition switch ON.
- Check the voltage between A/F sensor 1 harness connector and ground.

DTC		A/F sensor		Ground	Voltage (V)
	Bank	Connector	Terminal	Ground	voitage (v)
P2A00	1	F27	4	Ground	Battery voltage
P2A03	2	F64	4	Ground	battery voltage

EC-319

N

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 8. NO >> GO TO 7.

7.DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F12
- 15A fuse (No. 46)
- · Harness for open or short between A/F sensor 1 and fuse
 - >> Repair or replace harness or connectors.

8. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

DTC	A/F sensor 1			E	Continuity	
DIC	Bank	Connector	Terminal	Connector	Terminal	Continuity
P2A00	1	F27	1		45	
F 2A00	P2A00 1	1 21	2	F8	49	Existed
P2A03	2	F64	1		53	
F ZAUS	2	1 04	2		57	

4. Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

DTC	A/F sensor 1		ECM		Ground	Continuity	
DIC	Bank	Connector	Terminal	Connector	Terminal	Giodila	Continuity
P2A00	1	F27 1 2	1		45	Ground	Not existed
			2	F8	49		
P2A03	2 F64 —	1	го	53 57	Giouna	Not existed	
		2					

5. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

9. CHECK INTERMITTENT INCIDENT

Perform GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace malfunctioning part.

10. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1.

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

ASCD BRAKE SWITCH

Description INFOID:0000000003858142

When the brake pedal is depressed, ASCD brake switch is turned OFF and stop lamp switch is turned ON. ECM detects the state of the brake pedal by two kinds of input (ON/OFF signal). Refer to EC-51, "System Diagram" for the ASCD function.

INFOID:0000000003856821

Component Function Check

CHECK ASCD BRAKE SWITCH FUNCTION

(P) With CONSULT-III

- 1. Turn ignition switch ON.
- Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-III.
- 3. Check "BRAKE SW1" indication under the following conditions.

Monitor item	Condition		Indication
BRAKE SW1	Brake pedal	Slightly depressed	OFF
	Blake pedal	Fully released	ON

Without CONSULT-III

- 1. Turn ignition switch ON.
- Check the voltage between ECM harness connector and ground.

ECM		Ground	Condition		Voltage	
Connector					voltage	
	110			Slightly depressed	Approx. 0 V	
E16	E16 (ASCD brake Ground Brake pedal switch signal)		Brake pedal	Fully released	Battery voltage	

Is the inspection result normal?

>> INSPECTION END YES

>> Go to EC-321, "Diagnosis Procedure". NO

Diagnosis Procedure

1. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect ASCD brake switch harness connector.
- Turn ignition switch ON.
- Check the voltage between ASCD brake switch harness connector and ground.

ASCD bra	ake switch	Ground	Voltage	
Connector Terminal		Oround	voltage	
E49	1	Ground	Battery voltage	

Is the inspection result normal?

YES >> GO TO 3. NO >> GO TO 2.

2.DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse (No.3)
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit, short to ground or short to power in harness or connectors.

EC-321

EC

Α

D

Е

F

INFOID:0000000003856822

N

< COMPONENT DIAGNOSIS >

${f 3.}$ CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between ASCD brake switch harness connector and ECM harness connector.

ASCD bra	ake switch	E	CM	Continuity
Connector Terminal		Connector	Terminal	Continuity
E49	2	E16	110	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4. CHECK ASCD BRAKE SWITCH

Refer to EC-322, "Component Inspection (ASCD Brake Switch)".

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace ASCD brake switch.

5. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection (ASCD Brake Switch)

INFOID:0000000003858143

1. CHECK ASCD BRAKE SWITCH-I

- 1. Turn ignition switch OFF.
- 2. Disconnect ASCD brake switch harness connector.
- 3. Check the continuity between ASCD brake switch terminals under the following conditions.

Terminals	Condition		Continuity
1 and 2	2 Brake pedal	Fully released.	Existed
1 and 2		Slightly depressed.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK ASCD BRAKE SWITCH-II

- 1. Adjust ASCD brake switch installation. Refer to BR-6, "Inspection and Adjustment".
- 2. Check the continuity between ASCD brake switch terminals under the following conditions.

Terminals	Condition		Continuity
1 and 2	Brako podal	Fully released.	Existed
1 and 2	nd 2 Brake pedal	Slightly depressed.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ASCD brake switch.

ASCD INDICATOR

Description INFOID:0000000003856824

ASCD indicator lamp illuminates to indicate ASCD operation status. Lamp has two indicators, CRUISE and SET, and is integrated in combination meter.

CRUISE lamp illuminates when MAIN switch on ASCD steering switch is turned ON to indicated that ASCD system is ready for operation.

SET lamp illuminates when the following conditions are met.

- CRUISE lamp is illuminated.
- SET/COAST switch on ASCD steering switch is turned ON while vehicle speed is within the range of the ASCD setting.

SET lamp remains lit during ASCD control.

Refer to EC-51, "System Diagram" for the ASCD function.

Component Function Check

1. CHECK ASCD INDICATOR FUNCTION

Check ASCD indicator under the following conditions.

ASCD INDICATOR	CON	SPECIFICATION	
CRUISE LAMP	Ignition switch: ON	MAIN switch: Pressed at the 1st time → at the 2nd time	$ON \to OFF$
	MAIN switch: ON	ASCD: Operating	ON
SET LAMP	When vehicle speed is be- tween 40 km/h (25 MPH) and 144 km/h (89 MPH)	ASCD: Not operating	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-323, "Diagnosis Procedure".

Diagnosis Procedure

1.CHECK DTC

Check that DTC U1000 or U1001 is not displayed.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis for DTC U1000, U1001. Refer to EC-135, "Diagnosis Procedure".

2.CHECK COMBINATION METER FUNCTION

Refer to MWI-33, "CONSULT-III Function (METER/M&A)".

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning part.

3.check intermittent incident

Refer to GI-35. "Intermittent Incident".

Is the inspection result normal?

YES >> Replace combination meter.

>> Repair or replace malfunctioning part. NO

EC

Α

C

D

Е INFOID:0000000003856825

INFOID:0000000003856826

K

Ν

COOLING FAN

Description INFOID:000000003856827

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 4-step control [HIGH/MIDDLE/LOW/OFF].

COOLING FAN MOTOR

The cooling fan operates at each speed when the current flows in the cooling fan motor as per the following.

Cooling fan speed	Cooling fan motor terminals		
Cooling lair speed	(+)	(-)	
	1	3 and 4	
AA' LUL (AAID)	2	3 and 4	
Middle (MID)	1 and 2	3	
	1 and 2	4	
High (HI)	1 and 2	3 and 4	

The cooling fan operates at low (LOW) speed when cooling fan motors-1 and -2 are circuited in series under the middle speed condition.

Refer to EC-60, "System Diagram".

Component Function Check

INFOID:0000000003856828

1. CHECK COOLING FAN FUNCTION

(II) With CONSULT-III

- 1. Turn ignition switch ON.
- 2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-III.
- 3. Check that cooling fan speed varies according to the percent.

Without CONSULT-III

- Perform IPDM E/R auto active test and check cooling fan motors operation, refer to <u>PCS-11, "Diagnosis Description"</u>.
- 2. Check that cooling fan operates.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-324, "Diagnosis Procedure".

Diagnosis Procedure

INFOID:0000000003856829

1. CHECK COOLING FAN RELAY POWER SUPPLY CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect cooling fan relays-2, -3.
- Turn ignition switch ON.
- 4. Check the voltage between cooling fan relays-2, -3 harness connectors and ground.

Cooling fan rel	Ground	Voltage		
Connector	Terminal	Giodila	voltage	
E57	2	Ground		
(cooling fan relay-2)	5		Battery voltage	
E59	2			
(cooling fan relay-3)	5			

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.DETECT MALFUNCTIONING PART

Check the following.

- 40A fusible link (letter K)
- 10A fuse (No.42)
- IPDM E/R harness connector E10
- Harness for open or short between cooling fan relay-2 and battery
- Harness for open or short between cooling fan relay-3 and battery
- Harness for open or short between cooling fan relay-2 and IPDM E/R
- Harness for open or short between cooling fan relay-3 and IPDM E/R

>> Repair open circuit, short to ground or short to power in harness or connectors.

3.check cooling fan relay output signal circuit

- Turn ignition switch OFF.
- Disconnect IPDM E/R harness connectors. 2.
- 3. Check the continuity between cooling fan relay-2, -3 harness connectors and IPDM E/R harness connec-

Cooling fan re	lay	IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E57 (cooling fan relay-2)	1	E11	42	Existed
E59 (cooling fan relay-3)	1	E10	34	LXISIGU

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

f 4 .CHECK COOLING FAN MOTOR POWER SUPPLY CIRCUIT

- Disconnect cooling fan motor-1 harness connector.
- 2. Check the voltage between cooling fan motor-1 harness connector and ground.

Cooling fan r	ing fan motor-1 Ground		Cooling fan motor-1		Voltage
Connector	Terminal	Glound	voltage		
E301	1	Ground	Battery voltage		
L301	2	Glound	Battery voltage		

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

${f 5.}$ DETECT MALFUNCTIONING PART

Check the following.

- Harness connector E70, E305
- 40A fusible link (letter M)
- · Harness for open or short between cooling fan motor-1 and battery

>> Repair open circuit, short to ground or short to power in harness or connectors.

6. CHECK COOLING FAN MOTOR CIRCUIT-I

- Disconnect cooling fan motor-2 harness connector.
- 2. Check the continuity between cooling fan relay-2, -3 harness connectors and cooling fan motor-1, -2 harness connectors.

EC

Е

F

Р

Cooling fan	elay	Cooling fan motor		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E57	3	E302 (Cooling fan motor-2)	2	
(cooling fan relay-2)	7	E301 (Cooling fan motor-1)	3	Existed
E 59	3	E302 (Cooling fan motor-2)	1	LXISIGU
(cooling fan relay-3)	7	E301 (Cooling fan motor-1)	4	

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 8. NO >> GO TO 7.

7.DETECT MALFUNCTIONING PART

Check the following.

- Harness connector E70, E305
- Harness for open or short between cooling fan motor-1 and cooling fan relay-2
- Harness for open or short between cooling fan motor-1 and cooling fan relay-3
- Harness for open or short between cooling fan motor-2 and cooling fan relay-2
- Harness for open or short between cooling fan motor-2 and cooling fan relay-3

>> Repair open circuit, short to ground or short to power in harness or connectors.

8. CHECK COOLING FAN MOTOR CIRCUIT-II

Check the continuity between IPDM E/R harness connector and cooling fan motor-1, -2 harness connector.

IPDI	M E/R	Cooling fan motor		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E10	35	E301 (Cooling fan motor-1)	4	Existed
EIU	38	E302 (Cooling fan motor-2)	1	EXISTECT

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 10. NO >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connector E70, E305
- Harness for open or short between cooling fan motor-1 and IPDM E/R
- Harness for open or short between cooling fan motor-2 and IPDM E/R

>> Repair open circuit, short to ground or short to power in harness or connectors.

10. CHECK COOLING FAN MOTOR CIRCUIT-III

1. Check the continuity between cooling fan relay-2, -3 harness connectors and ground.

Ν

0

Р

INFOID:0000000003856830

Cooling fa	n motor	Ground	Continuity	
Connector	Terminal	Ground	Continuity	,
E57 (cooling fan relay-2)	6	Ground	Existed	-
E59 (cooling fan relay-3)	6			_
	ss for short to grou	nd and short to p	oower.	_
the inspection resul				
YES >> GO TO 1° NO >> Repair op		around or short t	o power in harness	or connectors.
1.CHECK COOLIN		_	о ротот птисто	
			rness connector an	
Oncok the contine	mty between ecomin	g fair motor 2 na	iness connector an	a ground.
Cooling fan	motor-2	O	O a matimus its s	
Connector	Terminal	Ground	Continuity	
E302	3	Ground	Existed	
2002	4	Ground	Existed	
Also check harne	ss for short to grou	nd and short to p	oower.	
the inspection resul				
YES >> GO TO 12 NO >> Repair op		around or short t	o power in harness	or connectors
2.CHECK COOLIN			o power in namess	of confectors.
			olov)"	
efer to <u>EC-328, "Cor</u> the inspection resul		1 (Cooling Fan K	<u>elay)</u> .	
/ES >> GO TO 1;				
	nalfunctioning cool	ing fan relay.		
3.CHECK COOLIN	IG FAN MOTORS-	1 AND -2		
efer to EC-327, "Cor	nponent Inspection	n (Cooling Fan M	otor)".	
the inspection resul	t normal?			
tilo illopootion roodi				
YES >> GO TO 14				
YES >> GO TO 14	nalfunctioning cool	•		

Perform GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace harness connectors.

Component Inspection (Cooling Fan Motor)

1. CHECK COOLING FAN MOTOR

- 1. Turn ignition switch OFF.
- 2. Disconnect cooling fan motor harness connector.
- 3. Supply cooling fan motor terminals with battery voltage and check operation.

INFOID:0000000003856831

	Condition	Terminals		
	Condition	(+)	(-)	
	A B	1	3 and 4	
		2	3 and 4	
Cooling fan motor		1 and 2	3	
		1 and 2	4	
		1, 2	3, 4	

Check that cooling fan speed of condition B is higher than that of A.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace cooling fan motor.

Component Inspection (Cooling Fan Relay)

1. CHECK COOLING FAN RELAY


- 1. Disconnect cooling fan relays -2, -3 harness connectors.
- 2. Check continuity between cooling fan relay -2, -3 terminals under the following conditions.

Terminals	Conditions	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Existed
6 and 7	No current supply	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace cooling fan relay.



INFOID:0000000003856833

ELECTRICAL LOAD SIGNAL

Description INFOID:0000000003856832

The electrical load signal (Headlamp switch signal, rear window defogger switch signal, etc.) is transferred through the CAN communication line from BCM to ECM via IPDM E/R.

EC

Α

Component Function Check

1. CHECK REAR WINDOW DEFOGGER SWITCH FUNCTION

- Turn ignition switch ON.
- Connect CONSULT-III and select "DATA MONITOR" mode. 2.
- Select "LOAD SIGNAL" and check indication under the following conditions.

Monitor item	Condition	Indication	
LOAD SIGNAL	Rear window defogger switch	ON	ON
	rteal willdow delogger switch	OFF	OFF

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to EC-329, "Diagnosis Procedure".

2.CHECK LIGHTING SWITCH FUNCTION

Check "LOAD SIGNAL" indication under the following conditions.

Monitor item	Co	Indication	
LOAD SIGNAL	Lighting switch	ON at 2nd position	ON
LOAD SIGNAL	Lighting Switch	OFF	OFF

Is the inspection result normal?

YES >> GO TO 3.

>> Go to EC-329, "Diagnosis Procedure". NO

3.check heater fan control switch function

Select "HEATER FAN SW" and check indication under the following conditions.

Monitor item	Condition		Indication
HEATER FAN SW	Heater fan control switch	ON	ON
	Treater fair control switch	OFF	OFF

Is the inspection result normal?

YES >> INSPECTION END

>> Go to EC-329, "Diagnosis Procedure".

Diagnosis Procedure

1.INSPECTION START

Confirm the malfunctioning circuit (rear window defogger, headlamp or heater fan). Refer to EC-329, "Component Function Check".

Which circuit is related to the incident?

Rear window defogger>>GO TO 2.

Headlamp>>GO TO 3.

Heater fan>>GO TO 4.

2.CHECK REAR WINDOW DEFOGGER SYSTEM

Refer to DEF-3, "Work Flow".

EC-329

D

Е

F

Н

M

NO

INFOID:0000000003856834

Ν

Р

ELECTRICAL LOAD SIGNAL

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

>> INSPECTION END

3. CHECK HEADLAMP SYSTEM

Refer to EXL-7, "Work Flow" (XENON TYPE) or EXL-198, "Work Flow" (HALOGEN TYPE).

>> INSPECTION END

4. CHECK HEATER FAN CONTROL SYSTEM

Refer to VTL-5, "System Description".

>> INSPECTION END

ELECTRONIC CONTROLLED ENGINE MOUNT

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

ELECTRONIC CONTROLLED ENGINE MOUNT

Description INFOID:0000000003856835

The electronic controlled engine mount control solenoid valve controls the intake manifold vacuum signal for electronic controlled engine mount. The electronic controlled engine mount control solenoid valve is moved by ON/OFF signal from the ECM. When the solenoid is OFF, the vacuum signal from the intake manifold is cut. When the solenoid is ON, the intake manifold vacuum signal is sent to the electronic controlled engine mount.

Component Function Check

1. CHECK OVERALL FUNCTION

- Start engine and warm it up to normal operating temperature.
- 2. Selector level position is D while depressing the brake pedal and parking brake pedal.
- Disconnect electronic controlled engine mount control solenoid valve harness connector.
- Check that body vibration increases compared to the condition of step 2 above (with vehicle stopped).

Is the inspection result normal?

YES >> INSPECTION END

NO >> EC-331, "Diagnosis Procedure".

INFOID:0000000003856837

Diagnosis Procedure

1. CHECK VACUUM SOURCE

- Turn ignition switch OFF.
- Reconnect electronic controlled engine mount control solenoid valve harness connector.
- Disconnect vacuum hose connected to electronic controlled engine mount.
- Start engine and let it idle.
- Check vacuum hose for vacuum existence.

Vacuum should exist.

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 2.

2.CHECK VACUUM HOSES AND VACUUM GALLERY

- Turn ignition switch OFF.
- Check vacuum hoses and vacuum gallery for clogging, cracks or improper connection. Refer to EC-68. "System Diagram".

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace vacuum hoses and vacuum gallery.

3.CHECK ELECTRONIC CONTROLLED ENGINE MOUNT CONTROL SOLENOID VALVE POWER SUPPLY **CIRCUIT**

- 1. Disconnect electronic controlled engine mount control solenoid valve harness connector.
- Turn ignition switch ON.
- Check the voltage between front electronic controlled engine mount harness connector and ground.

Electronic controlled engine mount control solenoid valve		Ground	Voltage	
Connector	Terminal			
F11	1	Ground	Battery voltage	

Is the inspection result normal?

YES >> GO TO 5. NO >> GO TO 4.

f 4.DETECT MALFUNCTIONING PART

EC-331

EC

Α

D

Н

M

Ν

Р

ELECTRONIC CONTROLLED ENGINE MOUNT

< COMPONENT DIAGNOSIS >

Check the following.

- Harness connectors E6, F123
- 10A fuse (No. 3)
- Fuse block (J/B) E103
- Harness for open or short between electronic controlled engine mount control solenoid valve and fuse
 - >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK ELECTRONIC CONTROLLED ENGINE MOUNT CONTROL SOLENOID VALVE OUTPUT SIG-NAL CIRCUIT FOR OPEN AND SHORT

- Disconnect ECM harness connector.
- 2. Check the continuity between ECM harness connector and electronic controlled engine mount control solenoid valve harness connector.

E	СМ	Electronic controlled engine mount control solenoid valve		Continuity
Connector	Terminal	Connector	Terminal	
F7	28	F11	2	Existed

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

>> GO TO 6. YES

NO >> Repair open circuit or short to ground or short to power in harness connectors.

$oldsymbol{6}$.CHECK ELECTRONIC CONTROLLED ENGINE MOUNT CONTROL SOLENOID VALVE

Refer to EC-332, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace electronic controlled engine mount control solenoid valve.

7.check electronic controlled engine mount

- Turn ignition switch OFF.
- Install vacuum pump (A) to electronic controlled engine mount
- Check that a vacuum is maintained when applying the vacuum of -40 kPa (-400 mbar, -300 mmHg, -11.81 inHg) to electronic controlled engine mount.
- Also visually check electronic controlled engine mount.

Is the inspection result normal?

YES >> GO TO 8.

>> Replace electronic controlled engine mount. NO

1 MBIB1237E

8.check intermittent incident

Refer to GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> Replace intake manifold collector.


NO >> Repair or replace malfunctioning part.

Component Inspection

1.check electronic controlled engine mount control solenoid valve

(I) With CONSULT-III

- 1. Turn ignition switch OFF.
- Reconnect electronic controlled engine mount control solenoid valve harness connector.
- 3. Disconnect vacuum hoses connected to electronic controlled engine mount control solenoid valve.
- Turn ignition switch ON.



INFOID:0000000003856838

[VQ25DE, VQ35DE]

ELECTRONIC CONTROLLED ENGINE MOUNT

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

- 5. Select "ENGINE MOUNTING" in "ACTIVE TEST" mode with CONSULT-III.
- 6. Check air passage continuity and operation delay time under the following conditions.


Condition (ENGINE MOUNTING)	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
TRVL	Existed	Not existed
IDLE	Not existed	Existed

JMBIA0180ZZ

W Without CONSULT-III

- 1. Turn ignition switch OFF.
- Disconnect electronic controlled engine mount control solenoid valve harness connector.
- 3. Disconnect vacuum hoses connected to electronic controlled engine mount control solenoid valve.
- Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12 V direct current supply between terminals 1 and 2	Existed	Not existed
No supply	Not existed	Existed



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace electronic controlled engine mount control solenoid valve. Е

Α

EC

C

D

F

Н

K

L

M

Ν


0

Р

FUEL INJECTOR

Description INFOID.000000003856839

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the ball valve back and allows fuel to flow through the fuel injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



Component Function Check

INFOID:0000000003856840

1.INSPECTION START

Turn ignition switch to START.

Are any cylinders ignited?

YES >> GO TO 2.

NO >> Go to EC-334, "Diagnosis Procedure".

2. CHECK FUEL INJECTOR FUNCTION

(P)With CONSULT-III

- 1. Start engine.
- 2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-III.
- 3. Check that each circuit produces a momentary engine speed drop.

Without CONSULT-III


- 1. Start engine.
- 2. Listen to each fuel injector operating sound.

Clicking sound should be heard.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-334, "Diagnosis Procedure".



INFOID:000000000385684

Diagnosis Procedure

1.CHECK FUEL INJECTOR POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect fuel injector harness connector.
- 3. Turn ignition switch ON.
- 4. Check the voltage between fuel injector harness connector and ground.

FUEL INJECTOR

< COMPONENT DIAGNOSIS >

	Fuel injector		Ground	Voltago
Cylinder	Connector	Terminal	Giodila	Voltage
1	F37	1		
2	F38	1	Ground	Battery voltage
3	F39	1		
4	F40	1		
5	F41	1		
6	F42	1		

Is the inspection result normal?

YES >> GO TO 3. NO >> GO TO 2.

2.DETECT MALFUNCTIONING PART

Check the following.

- 10A fuse (No.44)
- IPDM E/R harness connector E11
- Harness for open or short between fuel injector and fuse

>> Repair open circuit, short to ground or short to power in harness or connectors.

${f 3.}$ CHECK FUEL INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector. 2.
- Check the continuity between fuel injector harness connector and ECM harness connector.

	Fuel injector			ECM	
Cylinder	Connector	Terminal	Connector	Terminal	Continuity
1	F37	2		32	
2	F38	2		31	
3	F39	2	F7	30	Existed
4	F40	2	Г	29	Existed
5	F41	2		3	
6	F42	2		1	

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4.CHECK FUEL INJECTOR

Refer to EC-336, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning fuel injector.

5.CHECK INTERMITTENT INCIDENT

Refer to GI-35. "Intermittent Incident".

Is the inspection result normal?

YES >> Replace IPDM E/R.

>> INSPECTION END NO

EC-335

EC

Α

D

Е

F

Ν

Component Inspection

INFOID:0000000003856842

1. CHECK FUEL INJECTOR


- 1. Turn ignition switch OFF.
- 2. Disconnect fuel injector harness connector.
- Check resistance between fuel injector terminals as per the following.

Terminals	Resistance
1 and 2	11.1 - 14.5 Ω [at 10 - 60°C (50 - 140°F)]

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace malfunctioning fuel injector.



Α

EC

D

F

FUEL PUMP

Description INFOID:0000000003856843

Sensor	Input signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*	Fuel pump control	Fuel pump relay ↓
Battery	Battery voltage*	-	Fuel pump

^{*:} ECM determines the start signal status by the signals of engine speed and battery voltage.

The ECM activates the fuel pump for several seconds after the ignition switch is turned ON to improve engine start ability. If the ECM receives a engine speed signal from the camshaft position sensor (PHASE), it knows that the engine is rotating, and causes the pump to operate. If the engine speed signal is not received when the ignition switch is ON, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second.
Engine running and cranking	Operates.
When engine is stopped	Stops in 1.5 seconds.
Except as shown above	Stops.

Component Function Check

1. CHECK FUEL PUMP FUNCTION

- 1. Turn ignition switch ON.
- 2. Pinch fuel feed hose with two fingers.

: Vehicle front (Illustration shows the view with intake air duct removed)

Fuel pressure pulsation should be felt on the fuel feed hose for 1 second after ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> EC-337, "Diagnosis Procedure".

Diagnosis Procedure

1. CHECK FUEL PUMP POWER SUPPLY CIRCUIT-I


- Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Turn ignition switch ON.
- 4. Check the voltage between ECM harness connector and ground.

ECM		Ground	Voltage
Connector	Terminal	Ground	voitage
F7	14	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 2.



000000000045

INFOID:0000000003856845

INFOID:0000000003856844

Ν

F

2.CHECK FUEL PUMP POWER SUPPLY CIRCUIT-II

Check the voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage
Connector	Terminal	Ground	voltage
F12	77	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3. NO >> GO TO 14.

3. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F12
- Harness for open or short between IPDM E/R and ECM

>> Repair open circuit, short to ground or short to power in harness or connectors.

4. CHECK CONDENSER POWER SUPPLY CIRCUIT-I

- 1. Turn ignition switch OFF.
- 2. Reconnect all harness connectors disconnected.
- 3. Disconnect condenser harness connector.
- 4. Turn ignition switch ON.
- 5. Check the voltage between condenser harness connector and ground.

Condenser		Ground	Voltage	
Connector	Terminal	Giodila	voltage	
B81	1	Ground	Battery voltage should exist for 1 second after ignition switch is turned ON.	

Is the inspection result normal?

YES >> GO TO 8. NO >> GO TO 5.

5. CHECK 15A FUSE

- 1. Turn ignition switch OFF.
- 2. Disconnect 15A fuse (No. 41).
- 3. Check 15A fuse.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace 15A fuse.

6.CHECK CONDENSER POWER SUPPLY CIRCUIT-II

- 1. Disconnect IPDM E/R harness connector.
- 2. Check the continuity between IPDM E/R harness connector and condenser harness connector.

IPDN	M E/R	Condenser		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E10	13	B81	1	Existed

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 14. NO >> GO TO 7.

7. DETECT MALFUNCTIONING PART

< COMPONENT DIAGNOSIS >

Check the following.

- Harness connectors E104, B4
- IPDM E/R connector E10
- Harness for open or short between IPDM E/R and condenser

>> Repair open circuit or short to power in harness or connectors.

8.CHECK CONDENSER GROUND CIRCUIT

- Turn ignition switch OFF.
- Check the continuity between condenser harness connector and ground.

Condenser		Ground	Continuity
Connector	Terminal	Ground	Continuity
B81	2	Ground	Existed

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair open circuit or short to power in harness or connectors.

9. CHECK CONDENSER

Refer to EC-340, "Component Inspection (Condenser)".

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace condenser.

10.CHECK FUEL PUMP POWER SUPPLY CIRCUIT-III

- Disconnect "fuel level sensor unit and fuel pump" harness connector.
- 2. Check harness continuity between IPDM E/R harness connector and "fuel level sensor unit and fuel pump" harness connector.

IPDM E/R		Fuel level sensor unit and fuel pump		Continuity
Connector	Terminal	Connector Terminal		
E10	13	B40	1	Existed

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 11.

11. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B4, E104
- Harness for open or short between "fuel level sensor unit and fuel pump" and IPDM E/R

>> Repair open circuit or short to power in harness or connectors.

12. CHECK FUEL PUMP GROUND CIRCUIT

- Disconnect "fuel level sensor unit and fuel pump" harness connector.
- 2. Check the continuity between "fuel level sensor unit and fuel pump" harness connector and ground.

	sor unit and fuel mp	Ground	Continuity
Connector	Terminal		
B40	3	Ground	Existed

Is the inspection result normal?

[VQ25DE, VQ35DE]

EC

Α

Е

Н

N

Р

< COMPONENT DIAGNOSIS >

YES >> GO TO 13.

NO >> Repair open circuit or short to power in harness or connectors.

13.CHECK FUEL PUMP

Refer to EC-340, "Component Inspection (Fuel Pump)".

Is the inspection result normal?

YES >> GO TO 14.

NO >> Replace fuel pump.

14. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace harness or connectors.

Component Inspection (Fuel Pump)

INFOID:0000000003856846

[VQ25DE, VQ35DE]

1. CHECK FUEL PUMP

- 1. Turn ignition switch OFF.
- 2. Disconnect "fuel level sensor unit and fuel pump" harness connector.
- 3. Check resistance between "fuel level sensor unit and fuel pump" terminals as per the following.

Terminals	Resistance
1 and 3	0.2 - 5.0 Ω [at 25°C (77°F)]

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace "fuel level sensor unit and fuel pump"

Component Inspection (Condenser)

INFOID:0000000003856847

1. CHECK CONDENSER

- Turn ignition switch OFF.
- 2. Disconnect condenser harness connector.
- 3. Check resistance between condenser terminals as per the following.

Terminals	Resistance
1 and 2	Above 1 MΩ [at 25°C (77°F)]

Is the inspection result normal?

YES >> INSPECTION END NO >> Replace condenser.

INFOID:0000000003856849

IGNITION SIGNAL

Description INFOID:0000000003856848

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns ON and OFF the ignition coil primary circuit. This ON/OFF operation induces the proper high voltage in the coil secondary circuit.

EC

D

Е

Ν

INFOID:0000000003856850

Α

Component Function Check

1.INSPECTION START

Turn ignition switch OFF, and restart engine.

Does the engine start?

YES-1 >> With CONSULT-III: GO TO 2.

YES-2 >> Without CONSULT-III: GO TO 3.

NO >> Go to EC-341, "Diagnosis Procedure".

2.CHECK IGNITION SIGNAL FUNCTION

(P) With CONSULT-III

- 1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-III.
- 2. Check that each circuit produces a momentary engine speed drop.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-341, "Diagnosis Procedure".

3.CHECK IGNITION SIGNAL FUNCTION

(X) Without CONSULT-III

1. Let engine idle.

2. Read the voltage signal between ECM harness connector ground with an oscilloscope.

ECM		Ground	Voltage signal	
Connector	Terminal	Oround	voltage signal	
	9			
F7	10	- Ground	50mSec/div	
	11			
	18		=	
	19			
	21		2V/div JMBIA0035GB	

NOTE:

The pulse cycle changes depending on rpm at idle.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-341, "Diagnosis Procedure".

Diagnosis Procedure

1. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I

- Turn ignition switch OFF, wait at least 10 seconds and then turn it ON.
- Check the voltage between ECM harness connector and ground.

EC	CM	Ground	Voltage
Connector	Connector Terminal		Voltage
E16 105		Ground	Battery voltage

< COMPONENT DIAGNOSIS >

Is the inspection result normal?
YES >> GO TO 2.

NO >> Refer to EC-132, "Diagnosis Procedure".

2.CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II

- 1. Turn ignition switch OFF.
- Disconnect condenser harness connector.
- 3. Turn ignition switch ON.
- 4. Check the voltage between condenser harness connector and ground.

Cond	lenser	Ground	Voltage
Connector	Connector Terminal		voltage
F13	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III

- Turn ignition switch OFF.
- 2. Disconnect IPDM E/R harness connector.
- 3. Check the continuity between IPDM E/R harness connector and condenser harness connector.

IPDN	M E/R	Condenser		Continuity
Connector	Terminal	Connector Terminal		Continuity
F12	49	F13	1	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> Refer to EC-132, "Diagnosis Procedure".

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4. CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- 2. Check the continuity between condenser harness connector and ground.

Cond	lenser	Ground	Continuity	
Connector Terminal		Ground	Continuity	
F13	2	Ground	Existed	

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to power in harness or connectors.

CHECK CONDENSER

Refer to EC-345, "Component Inspection (Condenser)"

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace condenser.

6.CHECK IGNITION COIL POWER SUPPLY CIRCUIT-V

- Reconnect all harness connectors disconnected.
- 2. Disconnect ignition coil harness connector.
- Turn ignition switch ON.
- 4. Check the voltage between ignition coil harness connector and ground.

1				
Ignition coil			Ground	Voltage
Cylinder	Connector Terminal		Giodila	voltage
1	F31	3		
2	F32	3		
3	F33	3	Ground	Battery voltage
4	F34	3	Giodila	Ballery Vollage
5	F35	3		
6	F36	3		

EC

Α

Е

F

Ν

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace harness or connectors.

7.CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT

Turn ignition switch OFF.

Check the continuity between ignition coil harness connector and ground.

	Ignition coil			Continuity
Cylinder	Connector	Terminal	Ground	Continuity
1	F31	2		Existed
2	F32	2	Ground	
3	F33	2		
4	F34	2	Giodila	
5	F35	2		
6	F36	2		

Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair open circuit or short to power in harness or connectors.

8.check ignition coil output signal circuit for open and short

- Disconnect ECM harness connector.
- Check the continuity between ignition coil harness connector and ECM harness connector.

Ignition coil			ECM		Continuity
Cylinder	Connector	Terminal	Connector	Terminal	Continuity
1	F31	1		11	
2	F32	1	F7	10	
3	F33	1		9	Existed
4	F34	1	17	21	LXISIEU
5	F35	1		19	
6	F36	1		18	

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

9. CHECK IGNITION COIL WITH POWER TRANSISTOR

Refer to EC-344, "Component Inspection (Ignition Coil with Power Transistor)".

Is the inspection result normal?

< COMPONENT DIAGNOSIS >

YES >> GO TO 10.

NO >> Replace malfunctioning ignition coil with power transistor.

10.check intermittent incident

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Component Inspection (Ignition Coil with Power Transistor)

INFOID:0000000003856851

1. CHECK IGNITION COIL WITH POWER TRANSISTOR-I

- 1. Turn ignition switch OFF.
- 2. Disconnect ignition coil harness connector.
- 3. Check resistance between ignition coil terminals as per the following.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]	
1 and 2	Except 0 or ∞	
1 and 3	Except 0	
2 and 3		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace malfunctioning ignition coil with power transistor.

2.CHECK IGNITION COIL WITH POWER TRANSISTOR-II

CAUTION:

Perform the following procedure in a place with no combustible objects and good ventilation.

- Turn ignition switch OFF.
- 2. Reconnect all harness connectors disconnected.
- 3. Remove fuel pump fuse in IPDM E/R to release fuel pressure.

NOTE:

Do not use CONSULT-III to release fuel pressure, or fuel pressure applies again during the following procedure.

- 4. Start engine.
- 5. After engine stalls, crank it 2 or 3 times to release all fuel pressure.
- 6. Turn ignition switch OFF.
- 7. Remove all ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
- 8. Remove ignition coil and spark plug of the cylinder to be checked.
- 9. Crank engine for 5 seconds or more to remove combustion gas in the cylinder.
- 10. Connect spark plug and harness connector to ignition coil.
- 11. Fix ignition coil using a rope etc. with gap of 13 17 mm (0.52 0.66 in) between the edge of the spark plug and grounded metal portion as shown in the figure.
- Crank engine for about 3 seconds, and check whether spark is generated between the spark plug and the grounded metal portion.

Spark should be generated.


CAUTION:

 Never place to the spark plug and the ignition coil within 50 cm (19.7 in) each other. Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20 kV or more.

It might damage the ignition coil if the gap of more than 17 mm (0.66 in) is made.

When the gap is less than 13 mm (0.52 in), a spark might be generated even if the coil is a malfunctioning.

Is the inspection result normal?



001100115	IGNITION SIGNAL	[VQ25DE, VQ35DE]
	NT DIAGNOSIS >	[VQ23DE, VQ33DE]
	SPECTION END eplace malfunctioning ignition coil with power transistor	. A
	t Inspection (Condenser)	
	,	INFOID:000000003856852
1.CHECK CC	NDENSER	EC
2. Disconne	on switch OFF. ct condenser harness connector. istance between condenser terminals as per the follow	ing.
Terminals	Resistance	D
1 and 2	Above 1 MΩ [at 25C° (77C°)]	D
YES >> IN	on result normal? SPECTION END eplace condenser.	E
		F
		G
		Н
		I
		J
		K
		L
		M

Ν

0

Ρ

INFOID:0000000003856854

INFOID:0000000003856855


MALFUNCTION INDICATOR

Description

The Malfunction Indicator MI is located on the combination meter. The MI will illuminate when the ignition switch is turned ON without the engine running. This is a bulb check.

When the engine is started, the MI should turn off. If the MI remains illuminated, the on board diagnostic system has detected an engine system malfunction.

For details, refer to EC-102, "Diagnosis Description".



Component Function Check

1. CHECK MI FUNCTION

- 1. Turn ignition switch ON.
- 2. Check that MI illuminates.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-346, "Diagnosis Procedure".

Diagnosis Procedure

1. CHECK DTC

Check that DTC U1000 or U1001 is not displayed.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis for DTC U1000, U1001. Refer to EC-135, "Description".

2.CHECK COMBINATION METER FUNCTION

Refer to MWI-33, "CONSULT-III Function (METER/M&A)".

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace.

3. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".


Is the inspection result normal?

YES >> Replace combination meter.

NO >> Repair or replace.

POSITIVE CRANKCASE VENTILATION

Description



This system returns blow-by gas to the intake manifold.


The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.

During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.




Component Inspection

1. CHECK PCV VALVE

With engine running at idle, remove PCV valve from rocker cover. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over valve inlet.

Is the inspection result normal?

YES >> INSPECTION END NO >> Replace PCV valve.



EC

Α

С

D

Е

F

Н

1

K

. .

INFOID:0000000003856861

Ν


0

Р

REFRIGERANT PRESSURE SENSOR

Description

The refrigerant pressure sensor is installed at the condenser of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.



Component Function Check

INFOID:0000000003856863

1. CHECK REFRIGERANT PRESSURE SENSOR FUNCTION

- 1. Start engine and warm it up to normal operating temperature.
- Turn A/C switch and blower fan switch ON.
- 3. Check the voltage between ECM harness connector terminals under the following conditions.

	ECM		
Connector	+	_	Voltage (V)
Connector	Terminal	Terminal	
F8	39 (Refrigerant pressure sensor signal)	40 (Sensor ground)	1.0 - 4.0

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to EC-348, "Diagnosis Procedure".

Diagnosis Procedure

INFOID:0000000003856864

1. CHECK GROUND CONNECTION

- 1. Turn A/C switch and blower fan switch OFF.
- Stop engine.
- Turn ignition switch OFF.
- 4. Check ground connection E38. Refer to Ground Inspection in GI-37, "Circuit Inspection".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

- Disconnect refrigerant pressure sensor harness connector.
- Turn ignition switch ON.
- 3. Check the voltage between refrigerant pressure sensor harness connector and ground.

Refrigerant pressure sensor		Ground	Voltage (V)
Connector	Terminal	Ground	voltage (v)
E300	1	Ground	Approx. 5

Is the inspection result normal?

YES >> GO TO 4.

REFRIGERANT PRESSURE SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

NO >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F123, E6
- IPDM E/R harness connectors E10, E346
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit, short to ground or short to power in harness or connectors.

4.CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check the continuity between refrigerant pressure sensor harness connector and ECM harness connector.

Refrigerant pr	essure sensor	E	CM	Continuity
Connector	Terminal	Connector	Terminal	Continuity
E300	3	F8	40	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F123, E6
- IPDM E/R harness connectors E10, E346
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit, short to ground or short to power in harness or connectors.

6.CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between refrigerant pressure sensor harness connector and ECM harness connector.

Refrigerant p	ressure sensor	E	СМ	Continuity
Connector	Terminal	Connector	Terminal	Continuity
E300	2	F8	39	Existed

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F123, E6
- IPDM E/R harness connectors E10, E346
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit, short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

Is the inspection result normal?

EC

Α

D

Е

C

Н

J

K

M

N

Λ

REFRIGERANT PRESSURE SENSOR

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

YES

>> Replace refrigerant pressure sensor. >> Repair or replace malfunctioning part. NO

Α

EC

D

Е

N

INFOID:0000000003856866

VARIABLE INDUCTION AIR SYSTEM

Description

Power Valves 1 and 2 (VQ35DE engine)

The power valves 1 and 2 are installed in intake manifold collector and used to control the suction passage of the variable induction air control system. They are set in the fully closed or fully opened position by the power valve actuators 1 and 2 operated by the vacuum stored in the vacuum tank. The vacuum to power valve actuators is controlled by the VIAS control solenoid valves 1 and 2.

Power Valve (VQ25DE engine)


The power valve is installed in intake manifold collector and used to control the suction passage of the variable induction air control system. It is set in the fully closed or fully opened position by the power valve actuator operated by the vacuum stored in the vacuum tank. The vacuum to power valve actuator is controlled by the VIAS control solenoid valve.

Component Function Check (VQ35DE engine)

1. CHECK OVERALL FUNCTION-I

(P) With CONSULT-III

- 1. Start engine and warm it up to the normal operating temperature.
- 2. Perform "VIAS S/V-1" in "ACTIVE TEST" mode with CONSULT-III.
- 3. Turn VIAS control solenoid valve 1 "ON" and "OFF", and check that power valve actuator 1 rod moves.




- Power valve actuator 1
- Power valve actuator 1 rod
- 3. Power valve actuator 2

- Power valve actuator 2 rod
- : Vehicle front

Without CONSULT-III

- 1. Start engine and warm it up to the normal operating temperature.
- 2. When revving engine up to 5,000 rpm quickly.
- 3. Check that power valve actuator 1 rod moves under the following conditions.



- Power valve actuator 1
- Power valve actuator 1 rod
- Power valve actuator 2

- 4. Power valve actuator 2 rod
- : Vehicle front

EC-351

Condition	Operation
Idle	Existed
When revving engine up to 5,000 rpm quickly	Not existed

Is the inspection result normal?


YES >> GO TO 2.

NO >> EC-353, "Diagnosis Procedure (VQ35DE engine)".

2. CHECK OVERALL FUNCTION-II

(P) With CONSULT-III

- 1. Perform "VIAS S/V-2" in "ACTIVE TEST" mode with CONSULT-III.
- 2. Turn VIAS control solenoid valve 2 "ON" and "OFF", and check that power valve actuator 2 rod moves.




- 1. Power valve actuator 1
- Power valve actuator 1 rod
- 3. Power valve actuator 2

4. Power valve actuator 2 rod

< > : Vehicle front

⋈ Without CONSULT-III

- 1. When revving engine up to 5,000 rpm quickly.
- 2. Check that power valve actuator 2 rod moves under the following conditions.



- 1. Power valve actuator 1
- 2. Power valve actuator 1 rod
- 3. Power valve actuator 2

4. Power valve actuator 2 rod: Vehicle front

Condition	Operation
Idle	Existed
When revving engine up to 5,000 rpm quickly	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> EC-353, "Diagnosis Procedure (VQ35DE engine)".

Component Function Check (VQ25DE engine)


INFOID:0000000003895854

1. CHECK OVERALL FUNCTION

(P) With CONSULT-III

- 1. Start engine and warm it up to the normal operating temperature.
- Perform "VIAS S/V-1" in "ACTIVE TEST" mode with CONSULT-III.
- Turn VIAS control solenoid valve 1 "ON" and "OFF", and check that power valve actuator (1) rod (2) moves.

< > : Vehicle front



Without CONSULT-III

- Start engine and warm it up to the normal operating temperature.
- When revving engine up to 5,000 rpm quickly.
- Check that power valve actuator (1) rod (2) moves under the following conditions.

⟨⇒ : Vehicle front

Condition	Operation
Idle	Existed
When revving engine up to 5,000 rpm quickly	Not existed

Is the inspection result normal?

YES >> INSPECTION END

>> EC-355, "Diagnosis Procedure (VQ25DE engine)". NO

Diagnosis Procedure (VQ35DE engine)

1.INSPECTION START

Confirm the malfunctioning system (power valve 1 or power valve 2). Refer to EC-351, "Component Function Check (VQ35DE engine)".

Which system is related to the incident?

Power valve 1>>GO TO 2.

Power valve 2>>GO TO 6.

2.CHECK VACUUM EXISTENCE-I

(P) With CONSULT-III

- Stop engine and disconnect vacuum hose connected to power valve actuator 1.
- Start engine and let it idle.
- Perform "VIAS S/V-1" in "ACTIVE TEST" mode with CONSULT-III.
- Turn VIAS control solenoid valve 1 "ON" and "OFF", and check vacuum existence under the following conditions.

VIAS S/V 1	Vacuum
ON	Existed
OFF	Not existed

Without CONSULT-III

EC

Α

D

Е

F

Н

K

INFOID:0000000003856867

Ν

< COMPONENT DIAGNOSIS >

- Stop engine and disconnect vacuum hose connected to power valve actuator 1.
- 2. Disconnect VIAS control solenoid valve 1 harness connector.
- 3. Start engine.
- 4. When revving engine up to 5,000 rpm quickly.
- 5. Check vacuum existence under the following conditions.

Condition	Operation
Idle	Existed
When revving engine up to 5,000 rpm quickly	Not existed

Is the inspection result normal?

YES >> Repair or replace power valve actuator 1.

NO >> GO TO 3.

3. CHECK VACUUM TANK

- 1. Stop engine and disconnect vacuum hose connected to intake manifold collector.
- Start engine and let it idle.
- 3. Check vacuum existence from intake manifold collector.

Does vacuum existence from the intake manifold collector?

YES >> GO TO 4.

NO >> Replace intake manifold collector.


4. CHECK VACUUM HOSE

- 1. Stop engine.
- 2. Check vacuum hose for cracks, clogging, improper connection or disconnection. Refer to <u>EC-93</u>, "System Diagram".

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair hoses or tubes.



5. CHECK VIAS CONTROL SOLENOID VALVE 1

Refer to EC-286, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace VIAS control solenoid valve 1.

6.CHECK VACUUM EXISTENCE-II

(P) With CONSULT-III

- 1. Stop engine and disconnect vacuum hose connected to power valve actuator 2.
- 2. Start engine and let it idle.
- 3. Perform "VIAS S/V-2" in "ACTIVE TEST" mode with CONSULT-III.
- Turn VIAS control solenoid valve 2 "ON" and "OFF", and check vacuum existence under the following conditions.

VIAS S/V 2	Vacuum
ON	Existed
OFF	Not existed

₩ Without CONSULT-III

- 1. Stop engine and disconnect vacuum hose connected to power valve actuator 2.
- 2. Disconnect VIAS control solenoid valve 1 harness connector.
- Start engine.

VARIABLE INDUCTION AIR SYSTEM

< COMPONENT DIAGNOSIS >

[VQ25DE, VQ35DE]

- When revving engine up to 5,000 rpm quickly.
- Check vacuum existence under the following conditions.

Condition	Operation	
Idle	Existed	
When revving engine up to 5,000 rpm quickly	Not existed	

EC

D

Е

Н

Α

Is the inspection result normal?

>> Repair or replace power valve actuator 2.

NO >> GO TO 7.


7. CHECK VACUUM HOSE

- Stop engine.
- Check vacuum hose for cracks, clogging, improper connection or disconnection. Refer to EC-93, "System Diagram".

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair hoses or tubes.



8.CHECK VIAS CONTROL SOLENOID VALVE 2

Refer to EC-289, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace VIAS control solenoid valve 2.

9. CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

Diagnosis Procedure (VQ25DE engine)

1.INSPECTION START

Confirm the malfunctioning system (power valve). Refer to EC-353, "Component Function Check (VQ25DE engine)".

Which system is related to the incident?

>> GO TO 2.

2.CHECK VACUUM EXISTENCE

(P) With CONSULT-III

- Stop engine and disconnect vacuum hose connected to power valve actuator.
- Start engine and let it idle.
- Perform "VIAS S/V-1" in "ACTIVE TEST" mode with CONSULT-III.
- Turn VIAS control solenoid valve "ON" and "OFF", and check vacuum existence under the following conditions.

VIAS S/V	Vacuum	
ON	Existed	
OFF	Not existed	

Without CONSULT-III

INFOID:0000000003896867

K

Ν

< COMPONENT DIAGNOSIS >

- 1. Stop engine and disconnect vacuum hose connected to power valve actuator 1.
- 2. Disconnect VIAS control solenoid valve harness connector.
- Start engine.
- 4. When revving engine up to 5,000 rpm quickly.
- 5. Check vacuum existence under the following conditions.

Condition	Operation	
Idle	Existed	
When revving engine up to 5,000 rpm quickly	y Not existed	

Is the inspection result normal?

YES >> Repair or replace power valve actuator.

NO >> GO TO 3.

3. CHECK VACUUM TANK

- 1. Stop engine and disconnect vacuum hose connected to intake manifold collector.
- Start engine and let it idle.
- 3. Check vacuum existence from intake manifold collector.

Does vacuum existence from the intake manifold collector?

YES >> GO TO 4.

NO >> Replace intake manifold collector.


4. CHECK VACUUM HOSE

- 1. Stop engine.
- 2. Check vacuum hose for cracks, clogging, improper connection or disconnection. Refer to <u>EC-93</u>, "System Diagram".

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair hoses or tubes.



5. CHECK VIAS CONTROL SOLENOID VALVE

Refer to EC-286, "Component Inspection".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace VIAS control solenoid valve.

6.CHECK INTERMITTENT INCIDENT

Refer to GI-35, "Intermittent Incident".

>> INSPECTION END

< ECU DIAGNOSIS > [VQ25DE, VQ35DE]

ECU DIAGNOSIS

ECM

Reference Value

Α

C

D

Е

F

Н

K

L

M

Ν

Р

VALUES ON THE DIAGNOSIS TOOL

Remarks:

1 Specification data are reference values.

- 1 Specification data are output/input values which are detected or supplied by the ECM at the connector.
 - * Specification data may not be directly related to their components signals/values/operations.

I.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

Monitor Item	C	Condition	Values/Status
ENG SPEED	Run engine and compare CONSULT-III value with the tachometer indication.		Almost the same speed as the tachometer indication.
MAS A/F SE-B1	See EC-124, "Description".		
B/FUEL SCHDL	See EC-124, "Description".		
A/F ALPHA-B1	See EC-124, "Description".		
A/F ALPHA-B2	See EC-124, "Description".		
COOLAN TEMP/S	Engine: After warming up		More than 70°C (158°F)
A/F SEN1 (B1)	Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 2.2 V
A/F SEN1 (B2)	Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 2.2 V
HO2S2 (B1)	 Revving engine from idle to 3,000 rpm quickly after the following conditions are met. Engine: After warming up After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		0 - 0.3 V ←→ Approx. 0.6 - 1.0 V
HO2S2 (B2)	 Revving engine from idle to 3,000 rpm quickly after the following conditions are met. Engine: After warming up After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		0 - 0.3 V ←→ Approx. 0.6 - 1.0 V
HO2S2 MNTR (B1)	 Revving engine from idle to 3,000 rpm quickly after the following conditions are met. Engine: After warming up After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		LEAN ←→ RICH
HO2S2 MNTR (B2)	 Revving engine from idle to 3,000 rpm quickly after the following conditions are met. Engine: After warming up After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		LEAN ←→ RICH
VHCL SPEED SE	Turn drive wheels and compare CONSULT-III value with the speedometer indication.		Almost the same speed as speedometer indication
BATTERY VOLT	Ignition switch: ON (Engine stopped)		11 - 14 V
ACCEL SEN 4	Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.5 - 1.0 V
ACCEL SEN 1		Accelerator pedal: Fully depressed	4.2 - 4.8 V
ACCEL CEN 0+1	Ignition switch: ON	Accelerator pedal: Fully released	0.5 - 1.0 V
ACCEL SEN 2*1	(Engine stopped)	Accelerator pedal: Fully depressed	4.2 - 4.8 V

Monitor Item	Condition		Values/Status	
	Ignition switch: ON	Accelerator pedal: Fully released	More than 0.36 V	
TP SEN 1-B1	(Engine stopped)Selector lever: D	Accelerator pedal: Fully depressed	Less than 4.75 V	
4	Ignition switch: ON	Accelerator pedal: Fully released	More than 0.36 V	
TP SEN 2-B1* ¹	(Engine stopped)Selector lever: D	Accelerator pedal: Fully depressed	Less than 4.75 V	
INT/A TEMP SE	Ignition Switch: QN		Indicates intake air temperature	
START SIGNAL	• Ignition switch: $ON \rightarrow START \rightarrow O$	ON	$OFF \to ON \to OFF$	
01.00 7111 000	Ignition switch: ON	Accelerator pedal: Fully released	ON	
CLSD THL POS	(Engine stopped)	Accelerator pedal: Slightly depressed	OFF	
	Engine: After warming up, idle the	Air conditioner switch: OFF	OFF	
AIR COND SIG	engine	Air conditioner switch: ON (Compressor operates.)	ON	
D/N DOSLSW	• Ignition quitab: ON	Selector lever: P or N	ON	
P/N POSI SW	Ignition switch: ON	Selector lever: Except above	OFF	
PW/ST SIGNAL	Engine: After warming up, idle the	Steering wheel: Not being turned	OFF	
FW/ST SIGNAL	engine	Steering wheel: Being turned	ON	
LOAD SIGNAL • Ignition switch: ON	Ignition switch: ON	Rear window defogger switch: ON and/or Lighting switch: 2nd position	ON	
		Rear window defogger switch and lighting switch: OFF	OFF	
IGNITION SW	• Ignition switch: $ON \rightarrow OFF \rightarrow ON$	I	$ON \to OFF \to ON$	
	Engine: After warming up, idle the	Heater fan switch: ON	ON	
HEATER FAN SW	engine engine	Heater fan switch: OFF	OFF	
	Ignition switch: ON	Brake pedal: Fully released	OFF	
BRAKE SW		Brake pedal: Slightly depressed	ON	
	Engine: After warming up	Idle	2.0 - 3.0 msec	
INJ PULSE-B1	NJ PULSE-B1 Selector lever: P or N Air conditioner switch: OFF No load	2,000 rpm	1.9 - 2.9 msec	
	Engine: After warming up	Idle	2.0 - 3.0 msec	
INJ PULSE-B2	Selector lever: P or NAir conditioner switch: OFFNo load	2,000 rpm	1.9 - 2.9 msec	
	Engine: After warming up	Idle	7° - 17° BTDC	
IGN TIMING	Selector lever: P or NAir conditioner switch: OFFNo load	2,000 rpm	25° - 45° BTDC	
	Engine: After warming up	Idle	5% - 35%	
CAL/LD VALUE	• Selector lever: P or N • Air conditioner switch: OFF • No load	2,500 rpm	5% - 35%	
	 Engine: After warming up Selector lever: P or N Air conditioner switch: OFF No load 	Idle	2.0 - 6.0 g·m/s	
MASS AIRFLOW		2,500 rpm	7.0 - 20.0 g·m/s	
PURG VOL C/V	Engine: After warming up Selector lever: P or N Air conditioner switch: OFF No load	Idle (Accelerator pedal: Not depressed even slightly, after engine starting.)	0%	
		2,000 rpm	_	

Monitor Item	Condition		Values/Status	
	Engine: After warming up	Idle	−5° - 5°CA	
INT/V TIM (B1)	Selector lever: P or NAir conditioner switch: OFFNo load	2,000 rpm	Approx. 0° - 30°CA	
Engine: After warming up Selector lever: P or N Air conditioner switch: OFF No load		Idle	–5° - 5°CA	
	2,000 rpm	Approx. 0° - 30°CA		
	Engine: After warming up	Idle	0% - 2%	
INT/V SOL (B1)	Selector lever: P or NAir conditioner switch: OFFNo load	2,000 rpm	Approx. 0% - 50%	
	Engine: After warming up	Idle	0% - 2%	
NT/V SOL (B2)	Selector lever: P or NAir conditioner switch: OFFNo load	2,000 rpm	Approx. 0% - 50%	
VIAS S/V-1	 Engine: After warming up Selector lever: P or N Air conditioner switch: OFF No load 	When revving engine up to 5,000 rpm quickly	$OFF \to ON \to OFF$	
VIAS S/V-2	 Engine: After warming up Selector lever: P or N Air conditioner switch: OFF No load 	When revving engine up to 5,000 rpm quickly	$OFF \to ON \to OFF$	
		Air conditioner switch: OFF	OFF	
AIR COND RLY • Engine: After warming engine	Engine: After warming up, idle the engine	Air conditioner switch: ON (Compressor operates)	ON	
ENGINE MOUNT	Engine: After warming up	Below 950 rpm	IDLE	
		Above 950 rpm	TRVL	
FUEL PUMP RLY	For 1 second after turning ignition switch: ON Engine running or cranking		ON	
	Except above		OFF	
THRTL RELAY	Ignition switch: ON		ON	
	Engine: After warming up, idle the engine Air conditioner switch: OFF	Engine coolant temperature: 97°C (206°F) or less	OFF	
COOLING FAN		Engine coolant temperature: Between 98°C (208°F) and 99°C (210°F)	LOW	
COOLING FAN		Engine coolant temperature: Between 100°C (212°F) and 104°C (219°F)	MID	
		Engine coolant temperature: 105°C (221°F) or more	Н	
HO2S2 HTR (B1)	 Engine speed: Below 3,600 rpm after the following conditions are met. Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		ON	
	Engine speed: Above 3,600 rpm	Engine speed: Above 3,600 rpm		
HO2S2 HTR (B2)	 Engine speed: Below 3,600 rpm after the following conditions are met. Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		ON	
	Engine speed: Above 3,600 rpm	Engine speed: Above 3,600 rpm		
I/P PULLY SPD	Vehicle speed: More than 20km/h	(12 MPH)	Almost the same speed as the tachometer indication	
-	Turn drive wheels and compare CONSULT-III value with the speedometer indication.		Almost the same speed as	

Monitor Item	Condition		Values/Status	
	Engine: Running	Idle air volume learning has not been performed yet.	YET	
IDL A/V LEARN		Idle air volume learning has already been performed successfully.	CMPLT	
ENG OIL TEMP	Engine: After warming up		More than 70°C (158°F)	
TRVL AFTER MIL	Ignition switch: ON	Vehicle has traveled after MI has illuminated.	0 - 65,535 km (0 - 40,723 miles)	
A/F S1 HTR (B1)	Engine: After warming up, idle the engine (More than 140 seconds after starting engine)		4 - 100%	
A/F S1 HTR (B2)	Engine: After warming up, idle the (More than 140 seconds after star)		4 - 100%	
AC PRESS SEN	Engine: Idle Both A/C switch and blower fan sv	witch: ON (Compressor operates)	1.0 - 4.0 V	
VHCL SPEED SE	Turn drive wheels and compare C dication.	ONSULT-III value with the speedometer in-	Almost the same speed as the speedometer indication	
SET VHCL SPD	Engine: Running	ASCD: Operating	The preset vehicle speed is displayed	
MAIN SW	Ignition switch: ON	MAIN switch: Pressed	ON	
IVIAIIN OVV	- Ignition switch. ON	MAIN switch: Released	OFF	
CANCEL SW	Ignition switch: ON	CANCEL switch: Pressed	ON	
CANCLE SW	· ignition switch. ON	CANCEL switch: Released	OFF	
DECLIME/ACC CW	Ignition switch: ON	RESUME/ACCELERATE switch: Pressed	ON	
RESUME/ACC SW		RESUME/ACCELERATE switch: Released	OFF	
SET SW	Leading and the College	SET/COAST switch: Pressed	ON	
SELSW	Ignition switch: ON	SET/COAST switch: Released	OFF	
BRAKE SW1	a lamitian autitaly ON	Brake pedal: Fully released	ON	
(ASCD brake switch)	Ignition switch: ON	Brake pedal: Slightly depressed	OFF	
BRAKE SW2		Brake pedal: Fully released	OFF	
(Stop lamp switch)	Ignition switch: ON	Brake pedal: Slightly depressed	ON	
VHCL SPD CUT	Ignition switch: ON		NON	
LO SPEED CUT	Ignition switch: ON		NON	
AT OD MONITOR	Ignition switch: ON		OFF	
AT OD CANCEL	Ignition switch: ON		OFF	
CRUISE LAMP	Ignition switch: ON	MAIN switch: Pressed at the 1st time \rightarrow at the 2nd time	$ON \to OFF$	
	MAIN switch: ON	ASCD: Operating	ON	
SELLAMP	 When vehicle speed is between 40 km/h (25 MPH) and 144 km/h (89 MPH) 	ASCD: Not operating	OFF	
ALT DUTY	• Engine: Idle		0 - 80%	
A/F ADJ-B1	Engine: Running		-0.330 - 0.330	
A/F ADJ-B2	Engine: Running		-0.330 - 0.330	
BAT CUR SEN	Engine speed: Idle Battery: Fully charged* ² Selector lever: P or N Air conditioner switch: OFF No load		Approx. 2,600 - 3,500 mV	

Monitor Item	Condition	Values/Status
ALT DUTY SIG	Power generation voltage variable control: Operating	ON
ALI DOTT SIG	Power generation voltage variable control: Not operating	OFF

Α

EC

D

Е

F

Н


K

Ν

Р

*1: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.

TERMINAL LAYOUT



PHYSICAL VALUES

NOTE:

- ECM is located in the engine room left side near battery. For this inspection, remove passenger side instrument lower panel.
- · Specification data are reference values.
- Pulse signal is measured by CONSULT-III.

Termir	nal No.	Description			Value				
+		Signal name	Input/ Output	Condition	(Approx.)				
1 (P/B)		Fuel injector No. 6			BATTERY VOLTAGE (11 - 14 V)★				
3 (L/W)		Fuel injector No. 5	•					[Engine is running]Warm-up conditionIdle speedNOTE:	50mSec/div
29 (LG/R)	112	Fuel injector No. 4		The pulse cycle changes de- pending on rpm at idle	10V/div JMBIA0047GB				
30 (R/Y)	(B)	Fuel injector No. 3	Output		BATTERY VOLTAGE (11 - 14 V)★				
31 (R/W)		Fuel injector No. 2		[Engine is running] • Warm-up condition	50mSec/div				
32 (R/B)		Fuel injector No. 1		• Engine speed: 2,000 rpm	10V/div JMBIA0048GB				
2 (G/W)	112 (B)	Throttle control motor relay power supply	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)				
4 (BR/Y)	112 (B)	A/F sensor 1 heater (Bank 1)	Output	 [Engine is running] Warm-up condition Idle speed (More than 140 seconds after starting engine) 	2.9 - 8.8 V★ 50mSec/div 5V/div JMBIA0902GB				

^{*2:} Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to PG-3. "How to Handle Battery".

Termir	nal No.	Description			Value				
+	_	Signal name	Input/ Output	Condition	Value (Approx.)				
5	112			[Ignition switch: ON] • Engine stopped • Selector lever: D • Accelerator pedal: Fully depressed	0 - 14 V★ 500μSec/div 5V/div	JMBIA0031GB			
(L)	(B)	Throttle control motor (Open)	Output	[Ignition switch: ON] • Engine stopped • Selector lever: D • Accelerator pedal: Fully released	0 - 14 V★ 500μSec/div 5V/div	JMBIA0032GB			
6 (P)	112 (B)	Throttle control motor (Close)	Output	[Ignition switch: ON] • Engine stopped • Selector lever: D • Accelerator pedal: Fully released	0 - 14 V★ 500μSec/div 5V/div	JMBIA1125GB			
8 (SB)	112 (B)	A/F sensor 1 heater (Bank 2)	Output	[Engine is running]Warm-up conditionIdle speed (More than 140 seconds after starting engine)	2.9 - 8.8 V★ 50mSec/div 5V/div	JMBIA0030GB			
9 (L/B) 10 (G/R)		Ignition signal No. 3 Ignition signal No. 2					[Engine is running] • Warm-up condition • Idle speed NOTE:	0 - 0.2 V★ 50mSec/div	
11 (Y/R)	112	Ignition signal No. 1		The pulse cycle changes depending on rpm at idle	2V/div	JMBIA0035GB			
18 (GR/R)	(B)	Ignition signal No. 6	Output		0.1 - 0.4 V★ 50mSec/div				
19 (P) 21		Ignition signal No. 5		[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	-				
(W)		Ignition signal No. 4			2V/div	JMBIA0036GB			
12 (B)	_	ECM ground	_	_	_				

Termin	nal No.	Description			Value	_
+		Signal name	Input/ Output	Condition	(Approx.)	A
13 (P/B)	112 (B)	Heated oxygen sensor 2 heater (Bank 1)	Output	 [Engine is running] Engine speed: Below 3,600 rpm after the following conditions are met Engine: after warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	10 V★ 50mSec/div 5V/div JMBIA0902GB	C
				[Ignition switch: ON] • Engine stopped [Engine is running] • Engine speed: Above 3,600 rpm	BATTERY VOLTAGE (11 - 14 V)	Е
14 (GR)	112 (B)	Fuel pump relay	Output	[Ignition switch: ON] • For 1 second after turning ignition switch ON [Engine is running]	0 - 1.5 V	F
(GIV)	(b)		More th	[Ignition switch: ON] More than 1 second after turning ignition switch ON	BATTERY VOLTAGE (11 - 14 V)	G
15 (O)	112 (B)	Throttle control motor relay	Output	[Ignition switch: ON → OFF]	0 - 1.0 V → BATTERY VOLTAGE (11 - 14 V) → 0 V 0 - 1.0 V	Н
16 (B/Y)	_	ECM ground	_	[Ignition switch: ON]	—	I
17 (R)	112 (B)	Heated oxygen sensor 2 heater (Bank 2)	Output	 [Engine is running] Engine speed: Below 3,600 rpm after the following conditions are met Engine: after warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	50mSec/div 50mSec/div 5V/div JMBIA0902GB	J
				[Ignition switch: ON] • Engine stopped [Engine is running] • Engine speed: Above 3,600 rpm	BATTERY VOLTAGE (11 - 14 V)	L
24 (W/B)	112 (B)	ECM relay (Self shut-off)	Output	[Engine is running][Ignition switch: OFF]A few seconds after turning ignition switch OFF	0 - 1.5 V	Ν
(VV/D)	(B)	,		[Ignition switch: OFF] • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)	0

Termir	nal No.	Description			Value	
+		Signal name	Input/ Output	Condition	(Approx.)	
25	112	12 EVAP canister purge volume	Output	[Engine is running]Idle speedAccelerator pedal: Not depressed even slightly, after engine starting	BATTERY VOLTAGE (11 - 14 V)★ 50mSec/div 10V/div JMBIA0039GB	
(P/L)	(B)	control solenoid valve	Output	 [Engine is running] Engine speed: About 2,000 rpm (More than 100 seconds after starting engine) 	BATTERY VOLTAGE (11 - 14 V) 50mSec/div 10V/div JMBIA0040GB	
			Output	[Engine is running]Warm-up conditionIdle speed	BATTERY VOLTAGE (11 - 14 V)	
26 (GR/B)	112 (B)			[Engine is running]Warm-up conditionWhen revving engine up to 5,000 rpm quickly	BATTERY VOLTAGE (11 - 14 V) ↓ 0 - 1.0 V ↓ BATTERY VOLTAGE (11 - 14 V)	
	112 (B)	VIAS control colonoid valve 1	Output	[Engine is running]Warm-up conditionIdle speed	BATTERY VOLTAGE (11 - 14 V)	
27 (V)				[Engine is running]Warm-up conditionWhen revving engine up to 5,000 rpm quickly	BATTERY VOLTAGE (11 - 14 V) ↓ 0 - 1.0 V ↓ BATTERY VOLTAGE (11 - 14 V)	
20	112	Electronic controlled engine		[Engine is running] • Idle speed	0 - 1.0 V	
28 (BR/W)	(B)	Electronic controlled engine mount control solenoid valve	Output	[Engine is running] • Engine speed: More than 950 rpm	BATTERY VOLTAGE (11 - 14 V)	
33 (W)	35 (B)	Heated oxygen sensor 2 (Bank 1)	Input	 [Engine is running] Revving engine from idle to 3,000 rpm quickly after the following conditions are met Engine: after warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	0 - 1.0 V	
34 (W/L)	35 (B)	Heated oxygen sensor 2 (Bank 2)	Input	 [Engine is running] Revving engine from idle to 3,000 rpm quickly after the following conditions are met Engine: after warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	0 - 1.0 V	

Terminal No. Description		Description			Value
+		Signal name	Input/ Output	Condition	(Approx.)
35 (B)	_	Sensor ground (Heated oxygen sensor 2)	_	_	_
36 (B)	_	Sensor ground (Throttle position sensor)	_	_	_
37	36	Throttle position sensor 1	Input	[Ignition switch: ON]Engine stoppedSelector lever: DAccelerator pedal: Fully released	More than 0.36 V
(W)	(B)			 [Ignition switch: ON] Engine stopped Selector lever: D Accelerator pedal: Fully depressed 	Less than 4.75 V
38	36		Input	[Ignition switch: ON]Engine stoppedSelector lever: DAccelerator pedal: Fully released	Less than 4.75 V
(R)	(B)	Throttle position sensor 2	input	[Ignition switch: ON]Engine stoppedSelector lever: DAccelerator pedal: Fully depressed	More than 0.36 V
39 (R)	40 (G)	Refrigerant pressure sensor	Input	 [Engine is running] Warm-up condition Both A/C switch and blower fan motor switch: ON (Compressor operates) 	1.0 - 4.0 V
40 (G)	_	Sensor ground (Refrigerant pressure sensor)	_	_	_
41	48	Power steering pressure sen-	Input	[Engine is running] • Steering wheel: Being turned	0.5 - 4.5 V
(O/B)	(B/P)	sor	input	[Engine is running]Steering wheel: Not being turned	0.4 - 0.8 V
42 (BR)	44 (G/B)	Battery current sensor	Input	[Engine is running] • Battery: Fully charged*2 • Idle speed	2.6 - 3.5 V
44 (G/B)	_	Sensor ground (Battery current sensor)	_	_	_
45 (P)	49 (L)	A/F sensor 1 (Bank 1)	Input	[Ignition switch: ON]	2.2 V
46 (Y)	52 (B/R)	Engine coolant temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with engine coolant temperature.
47 (G)	36 (B)	Sensor power supply (Throttle position sensor)	_	[Ignition switch: ON]	5 V
48 (B/P)	_	Sensor ground (Power steering pressure sensor)	_	_	_
49 (L)	112 (B)	A/F sensor 1 (Bank 1)	Input	[Engine is running]Warm-up conditionEngine speed: 2,000 rpm	1.8 V Output voltage varies with air fuel ratio.

Termir	nal No.	Description			
+		Signal name	Input/ Output	Condition	Value (Approx.)
50 (L/Y)	56 (G/B)	Intake air temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with intake air temperature.
51 (R/Y)	44 (G/B)	Sensor power supply (Battery current sensor)	_	[Ignition switch: ON]	5 V
52 (B/R)	_	Sensor ground (Engine coolant temperature sensor/Engine oil tempera- ture sensor)	_	_	_
53 (V)	57 (LG)	A/F sensor 1 (Bank 2)	Input	[Ignition switch: ON]	2.2 V
54 (G)	52 (B/R)	Engine oil temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with engine oil temperature.
55 (SB)	48 (Y)	Sensor power supply (Power steering pressure sensor)	_	[Ignition switch: ON]	5 V
56 (G/B)	_	Sensor ground (Mass air flow sensor/Intake air temperature sensor)	_	_	_
57 (LG)	112 (B)	A/F sensor 1 (Bank 2)	Input	[Engine is running]Warm-up conditionEngine speed: 2,000 rpm	1.8 V Output voltage varies with air fuel ratio.
58	56	Mass air flow sensor	Input	[Engine is running]Warm-up conditionIdle speed	0.9 - 1.2 V
(O)	(G/B)	ividos all now sensor	Input	[Engine is running]Warm-up conditionEngine speed: 2,500 rpm	1.6 - 1.9 V
59 (G/W)	64 (B/R)	Sensor power supply [Camshaft position sensor (PHASE) (Bank 1)]	_	[Ignition switch: ON]	5 V
60 (Y/B)	_	Sensor ground [Crankshaft position sensor (POS)]	_	_	_
61 (B)	67 (GR)	Knock sensor (Bank 1)	Input	[Engine is running] • Idle speed	2.5 V* ¹
62 (W)	67 (GR)	Knock sensor (Bank 2)	Input	[Engine is running] • Idle speed	2.5 V* ¹
63 (R/W)	68 (Y/G)	Sensor power supply [Camshaft position sensor (PHASE) (Bank 2)]	_	[Ignition switch: ON]	5 V
64 (B/R)	_	Sensor ground [Camshaft position sensor (PHASE) (Bank 1)]	_	_	_

Termin	nal No.	Description			Value				
+		Signal name	Input/ Output	Condition	value (Approx.)				
65	60	Crankshaft position sensor	Input	 [Engine is running] Warm-up condition Idle speed NOTE: The pulse cycle changes depending on rpm at idle 	4.0 - 5.0 V★ 1mSec/div 2V/div JMBIA0041GB				
(W/B)	(Y/B)	(POS)	mput	[Engine is running] • Engine speed: 2,000 rpm	4.0 - 5.0 V★ 1mSec/div 2V/div JMBIA0042GB				
67 (GR)	_	Sensor ground (Knock sensor)	_	_	_				
68 (Y/G)		Sensor ground [Camshaft position sensor (PHASE) (Bank 2)]	_	_	_				
69 (BR/W)	68 (Y/G)	Camshaft position sensor (PHASE) (Bank 2)	Input	 [Engine is running] Warm-up condition Idle speed NOTE: The pulse cycle changes depending on rpm at idle 	3.0 - 5.0 V★ 20mSec/div 2V/div JMBIA0045GB				
	(/							[Engine is running] • Engine speed is 2,000 rpm	3.0 - 5.0 V★ 20mSec/div 2V/div JMBIA0046GB
				 [Engine is running] Warm-up condition Idle speed NOTE: The pulse cycle changes depending on rpm at idle 	3.0 - 5.0 V★ 20mSec/div				
70 (W/R)	64 (B/R)	Camshaft position sensor (PHASE) (Bank 1)	Input	[Engine is running] • Engine speed is 2,000 rpm	2V/div JMBIA0045GB 3.0 - 5.0 V★ 20mSec/div 2V/div JMBIA0046GB				

Termin	al No.	Description			Value
+		Signal name	Input/ Output	Condition	(Approx.)
72 (BR/W)	40 (G)	Sensor power supply (Refrigerant pressure sensor)	_	[Ignition switch: ON]	5 V
				[Engine is running]Warm-up conditionIdle speed	BATTERY VOLTAGE (11 - 14 V)
75 (Y)	112 (B)	Intake valve timing control so- lenoid valve (Bank 2)	Output	[Engine is running]Warm-up conditionEngine speed: 2,000rpm	7 - 12 V★ 5V/div JMBIA0038GB
76 (R/G)	60 (Y/B)	Sensor power supply [Crankshaft position sensor (POS)]	_	[Ignition switch: ON]	5 V
77 (W/L)	112 (B)	Power supply for ECM (Back-up)	Input	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14 V)
		Intake valve timing control so- lenoid valve (Bank 1)		[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
78 (R/L)	112 (B)		Output	[Engine is running]Warm-up conditionEngine speed: 2,000rpm	7 - 12 V★ 5V/div JMBIA0038GB
81	84	Accelerator pedal position	loout	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released	0.5 - 1.0 V
(W)	(B)	sensor 1	Input	[Ignition switch: ON] Engine stopped Accelerator pedal: Fully depressed	4.2 - 4.8 V
82	100	Accelerator pedal position	Input	[Ignition switch: ON] Engine stopped Accelerator pedal: Fully released	0.25 - 0.50 V
(O)	(G)	sensor 2		[Ignition switch: ON]Engine stoppedAccelerator pedal: Fully depressed	2.0 - 2.5 V
83 (BR)	84 (B)	Sensor power supply (Accelerator pedal position sensor 1)	_	[Ignition switch: ON]	5 V
84 (B)	_	Sensor ground (Accelerator pedal position sensor 1)	_	_	_


Termin	nal No.	Description			Value	
+		Signal name	Input/ Output	Condition	(Approx.)	
				[Ignition switch: ON] • ASCD steering switch: OFF	4 V	
				[Ignition switch: ON] • MAIN switch: Pressed	0 V	
85 (Y)	92 (BR)	ASCD steering switch	Input	[Ignition switch: ON] • CANCEL switch: Pressed	1 V	
				[Ignition switch: ON] • RESUME/ACCELERATE switch: Pressed	3 V	
				[Ignition switch: ON] • SET/COAST switch: Pressed	2 V	
87 (GR)	100 (G)	Sensor power supply (Accelerator pedal position sensor 2)	_	[Ignition switch: ON]	5 V	
88 (O)	_	Data link connector	Input/ Output	_	_	
92 (BR)	_	Sensor ground (ASCD steering switch)	_	_	_	
93	112			[Ignition switch: OFF]	0 V	
93 (BR)	(B)	Ignition switch	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)	
94 (GR)	112 (B)		Engine speed output signal Output	Output	 [Engine is running] Warm-up condition Idle speed NOTE: The pulse cycle changes depending on rpm at idle 	1 V★ 10mSec/div 2V/div JMBIA0076GB
				[Engine is running] • Engine speed: 2,000 rpm	10mSec/div 2V/div JMBIA0077GB	
97 (P)	_	CAN communication line	Input/ Output	_	_	
98 (L)	_	CAN communication line	Input/ Output	_	_	
100 (G)	_	Sensor ground (Accelerator pedal position sensor 2)	_	_	_	
102	112	PNP signal	Input	[Ignition switch: ON] • Selector lever: P or N	BATTERY VOLTAGE (11 - 14 V)	
(R)	(B)		,	[Ignition switch: ON] • Selector lever: Except above	0 V	
105	112	1		i	BATTERY VOLTAGE	


Termir	nal No.	Description			Value
+		Signal name	Input/ Output	Condition	(Approx.)
106	112			[Ignition switch: OFF] • Brake pedal: Fully released	0 V
(SB)	(B)	Stop lamp switch	Input	[Ignition switch: OFF] • Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14 V)
107 (B) 108 (B)	_	ECM ground	_	_	_
110 (G)	112 (P)	ASCI) brake switch	Input	[Ignition switch: ON] • Brake pedal: Slightly depressed	0 V
(G)	(B)			[Ignition switch: ON] • Brake pedal: Fully released	BATTERY VOLTAGE (11 - 14 V)
111 (B) 112 (B)	_	ECM ground	_	_	_


^{★:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


^{*1:} This may vary depending on internal resistance of the tester.


^{*2:} Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to PG-3, "How to Handle Battery".















JCBWM0565GE


Connector No. E49 Connector Name ASCD BRAKE SWITCH Connector Type MOZFBR-LC Terminal Color No. of Wire Signal Name [Specification] 1 R 2 G	Connector No. E103 Connector Name FUSE BLOCK (J/B) Connector Type NS16FW-CS ALS TF 6F 5F 4F 3F 2F 1F 16F 15F 14F 13F 12F 11F 10F 9F 8F	Terminal Color Signal Name [Specification] 1	EC C
98 L VEHCAN-H 100 G GNIDA-N-PSZ 102 R NEUT-H 106 S W VBR 107 B GND 108 G GND 110 B GND 111 B GND 112 B GND	Connector No. E70 Connector Name WIRE TO WIRE Connector Type MOBMW-LC 1 2 3 1 2 3 4 5 6	No. of Wire Signal Name [Specification] No. of Wire Signal Name [Specification] 2 CR	E F G
Connector No. E16 Connector Name ECM Connector Type RR42#F9-R28-L-LH	Connector No. E59 Connector Name GOOLING FAN RELAY-3 Connector Type M05FBR-R-LC H.S.	No. of Wine Signal Name [Steerification] No. of Wine Signal Name [Steerification]	J K
Commercer Name Company Company	Connector No. E57 Connector Name COOLING FAN RELAV-2 Connector Type MOBFBR-R-LC A.S. (2 1 1 5 6 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Terminal Color Signal Name (Specification) 1 SB	M N
			JCBWM0566GI
			Р



JCBWM0567GE


Р

13 P/B COPHRI 14 GR FPR 15 O MOTRLY-B1 16 BAY GMD 17 R COPHRI 19 W IGN#45 21 W IGN#45 24 W/B SSOFF 25 P/L EVAP 26 GR/B IGN#4 27 V VIASS 28 BR/W EMMNV 30 R/W IGN#4 31 R/W IGN#4 32 R/W IGN#4 33 R/W IGN#4 34 R/W IGN#4 35 R/W IGN#4 36 R/W IGN#4 37 R/W IGN#4 38 R/W IGN#4 39 R/W IGN#4 30 R/W IGN#4 31 R/W IGN#4 32 R/W IGN#4 33 R/W IGN#4 34 R/W IGN#4 35 R/W IGN#4 36 R/W IGN#4 37 R/W IGN#4 38 R/W IGN#4 39 R/W IGN#4 30 R/W IGN#4 31 R/W IGN#4 32 R/W IGN#4 33 R/W IGN#4 34 R/W IGN#4 35 R/W IGN#4 36 R/W IGN#4 37 R/W IGN#4 38 R/W IGN#4 39 R/W IGN#4 30 R/W IGN#4 31 R/W IGN#4 32 R/W IGN#4 33 R/W IGN#4 34 R/W IGN#4 35 R/W IGN#4 36 R/W IGN#4 37 R/W IGN#4 38 R/W IGN#4 39 R/W IGN#4 30 R/W IGN#4 31 R/W IGN#4 32 R/W IGN#4 33 R/W IGN#4 34 R/W IGN#4 35 R/W IGN#4 36 R/W IGN#4 37 R/W IGN#4 38 R/W IGN#4 39 R/W IGN#4 40 R/W IGN#4 41 R/W IGN#4 41 R/W IGN#4 42 R/W IGN#4 43 R/W IGN#4 44 R/W IGN#4 45 R/W IGN#4 45 R/W IGN#4 46 R/W IGN#4 47 R/W IGN#4 47 R/W IGN#4 48 R/W IGN#4 49 R/W IGN#4 40 R/W IGN#4 41 R/W IGN#4 42 R/W IGN#4 43 R/W IGN#4 44 R/W IGN#4 45 R/W IGN#4 45 R/W IGN#4 46 R/W IGN#4 47 R/W IGN#4 48 R/W IG	Terminal Color Signal Name [Spacification] Terminal Color Signal Name [Spacification] Terminal Color Signal Name [Spacification] 1 G.R - 1 G.R - 1 G.R -	EC C
Connector No. F7 Connector Name ECM Connector Type RH24FGY-RZ8-R-LH Connector Type [RH24FGY-RZ8-R-LH Terminal Color No. of Wire No. of Wire Signal Name (Specification) I P. B. NOT-BI A B N.Y NOT-BI NAME VMOT-BI NAME S S A ARH S S B ARH II N.YR II N.YR II N.YR CONNETT CONNET	72 BR/W AVCC2-PDPRES 75 Y CV1G22 77 RVG AVCC2-PDS 77 RVL BR/L 78 R/L CVTC#1	E F G
NE	45 P AF+1 46 Y TW 47 G AVOCG1-TPS-E1 49 L/P GNIDA-PSPRES 49 L/Y AVOC1-TPS-FRI 50 L/Y AVOC1-OURSINTP 52 B/R GVB AVOC1-PSPRES 54 G AVOC1-PARSEI.EP1 56 G/B GA/B GNIDA-TAI 57 LG AF-2 58 G AVOC1-PARSEI.EP1 58 G/B GA/B GNIDA-TAI 57 LG AF-2 58 GA/B GA/CD1-PARSEI.EP1 60 W/B GNID-PHASEI.EP1 61 B/R AVOCC1-PARSEI.EP1 62 W/B GNID-PHASEI.EP1 63 W/B GNID-PHASEI.EP1 64 B/R AVOCC1-PARSEI.EP1 65 W/B GNID-PHASEI.EP1 66 B/R/W AVOCC1-PHASEI.EP1 67 GNID-PHASEI.EP1 68 W/B GNIDA-HASEI.EP1 69 B/R/W AVOCC1-PHASEI.EP1 60 W/B GNIDA-PHASEI.EP1 60 W/B GNID-PHASEI.EP1 61 B/R AVOCC1-PHASEI.EP1 62 W/B GNID-PHASEI.EP1 63 W/B GNIDA-PHASEI.EP2 64 B/R AVOCC1-PHASEI.EP1 65 W/B GNIDA-PHASEI.EP2 66 B/R/W PASEI.EP2 67 W/B GNIDA-PHASEI.EP2 68 W/B GNIDA-PHASEI.EP2 69 B/R/W PASEI.EP2 60 W/R PASEI.EP2	H J K
Connector Name Connector Type Conn	Connector No. F8 Connector Name ECM	M N
	JCBWM0568Gŧ	_




JCBWM0569GE

Corrector No. F33 Corrector Name ICANTITION COIL. No.3 (WITH POWER TRANSISTOR) Corrector Type E03FGY-RS H.S.	Terminal Color Signal Name [Specification] No. of Wire LVB	Connector No. F37 Connector Name FUEL INJECTOR No.1 Connector Type HS02FGY H.S.	Terminal Color Signal Name [Specification] 1 LG 2 R/B -		А ЕС С
Connector No. F22 Connector Name E0MTON COIL No.2 (WITH POWER TRANSISTOR) Connector Type E08FGY-RS	Terminal Golor Signal Name [Specification] No. of Wire G/R	Connector No. F36 Connector Name IGMITION COLL No.6 (WITH POWER Connector Type EGBFGY-RS H.S.	Terminal Color Signal Name [Specification] No. of Wive Signal Name [Specification] 1 GR/R -		E F G
Gomector No. F31 Connector Name IGNITION COIL No.1 (WITH POWER Connector Type EDSFGY-RS H.S.	Terminal Color Signal Name [Specification] 1 Y/R 2 B - -	Connector No. F35 Connector Name IGNITION COIL No.5 (WITH POWER TRANSISTOR) Connector Type EGBFGY-RS H.S.	Terminal Color Signal Name [Specification] Of Wire Color Signal Name [Specification]		J K
ENGINE CONTROL SYSTEM (VQ ENGINE) Commercer Name Commercer Name Commercer Type Commercer T	Terminal Color Signal Name (Specification)	Connector No. F34 Connector Name IGNITION COIL No.4 (WITH POWER Connector Type E03FGY-RS H.S.	Terminal Color Signal Name (Specification] No. Wwire	JCBWM0570Gŧ	M N
					Р





JCBWM0571GE

Connector No. F71 Connector Name HEATED OXYGEN SENSOR 2 (BANK 2) Connector Type AF204FB-P H.S.	Terminal Color Signal Name Specification	Corrector No. F78 Corrector Name WIRE TO WIRE Corrector Type RSO4FL-6 H.S.	Terminal Color Signal Name [Specification]		A
Connector No. F70 Connector Name HEATED OXYGEN SENSOR 2 (BANK 1) Connector Type AFZO4FB-P H.S.	Terminal Golor Signal Name [Specification]	Connector No. F76 Connector Name BATTERY CURRENT SENSOR Connector Type RH03FB H.\$	Terminal Color Nignal Name (Specification) No. of Wire Signal Name (Specification) 1		E F G
NGINE) Comector No. F69 Connector Name (GAMSHAFT POSITION SENSOR (PHASE) Connector Type RH03FB H.S.	Terminal Color Signal Name [Specification] No. of Wire	Ocumector No. F75 Connector Name WAS CONTROL SOLENOD VALVE 2 Connector Type E02FB-RS H.S.	Terminal Color Signal Name [Specification]		I J K
ENGINE CONTROL SYSTEM (VQ ENGORMETOR NO ENGINE OIL TEMPERATURE SENSOR Connector Type EUSFGY-RS	Terminal Color Signal Name [Specification] No. of Wire Of Wire Of Of Of Of Of Of Of	Connector No. F74 Commettor Name VIAS CONTROL SOLENOD VALVE I Commettor Type E02FB-RS LA. LA. LA. LA. LA. LA. LA. LA	Terminal Color Signal Name [Specification] No. of Wire	JCBWM0572Gŧ	M N
					Р



JCBWM0573GE





JCBWM0575GE

INFOID:0000000003856870

NON DTC RELATED ITEM

Fail safe

D

Е

F

Н

Κ

L

Ν

0

Engine operating condition in fail-safe mode	Detected items	Remarks	Reference page	А
Engine speed will not rise more than 2,500 rpm due to the fuel cut	Malfunction indicator circuit	When there is an open circuit on MI circuit, the ECM cannot warn the driver by illuminating MI when there is malfunction on engine control system.		EC
		Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MI circuit is open by means of operating the fail-safe function. The fail-safe function also operates when above diagnoses except MI circuit are detected and demands the driver to repair the malfunction.	EC-346	С

DTC RELATED ITEM

DTC No.	Detected items	Engine operating condition in fail-safe mode						
P0011 P0021	Intake valve timing control	The signal is not energized to the intake valve timing control solenoid valve and the valve control does not function.						
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.						
P0117 P0118	Engine coolant tempera- ture sensor circuit		Engine coolant temperature will be determined by ECM based on the following condition. CONSULT-III displays the engine coolant temperature decided by ECM.					
		Condition	Engine coolant temperature decided (CONSULT-III display)					
		Just as ignition switch is turned ON or START	40°C (104°F)					
		Approx. 4 minutes or more after engine starting	80°C (176°F)					
		Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)					
		When the fail-safe system for engin fan operates while engine is runnin	ne coolant temperature sensor is activated, the cooling ng.					
P0122 P0123 P0222 P0223 P2135	Throttle position sensor	order for the idle position to be with	tle control actuator in regulating the throttle opening in hin +10 degrees. Deed of the throttle valve to be slower than the normal					
P0500	Vehicle speed sensor	The cooling fan operates (Highest)	while engine is running.					
P0605	ECM	(When ECM calculation function is ECM stops the electric throttle confixed opening (approx. 5 degrees) ECM deactivates ASCD operation.	trol actuator control, throttle valve is maintained at a by the return spring.					
P0643	Sensor power supply	ECM stops the electric throttle confixed opening (approx. 5 degrees)	trol actuator control, throttle valve is maintained at a by the return spring.					
P1805	Brake switch	ECM controls the electric throttle cosmall range. Therefore, acceleration will be poo	ontrol actuator by regulating the throttle opening to a r.					
		Vehicle condition	Driving condition					
		When engine is idling	Normal					
		When accelerating	Poor acceleration					
P2100 P2103	Throttle control motor relay	ECM stops the electric throttle confixed opening (approx. 5 degrees)	trol actuator control, throttle valve is maintained at a by the return spring.					
P2101	Electric throttle control function		ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.					
P2118	Throttle control motor	ECM stops the electric throttle confixed opening (approx. 5 degrees)	trol actuator control, throttle valve is maintained at a by the return spring.					

DTC No.	Detected items	Engine operating condition in fail-safe mode
P2119	Electric throttle control actuator	(When electric throttle control actuator does not function properly due to the return spring malfunction:) ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.
		(When throttle valve opening angle in fail-safe mode is not in specified range:) ECM controls the electric throttle control actuator because of regulating the throttle opening to 20 degrees or less.
		(When ECM detects the throttle valve is stuck open:) While the vehicle is being driver, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in N or P position, and engine speed will not exceed 1,000 rpm or more.
P2122 P2123 P2127 P2128 P2138	Accelerator pedal position sensor	The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.

DTC Inspection Priority Chart

INFOID:0000000003856871

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	 U1000 U1001 CAN communication line P0102 P0103 Mass air flow sensor P0112 P0113 Intake air temperature sensor P0117 P0118 Engine coolant temperature sensor P0122 P0123 P0222 P0223 P1225 P1226 P2135 Throttle position sensor P0327 P0328 P0332 P0333 Knock sensor P0335 Crankshaft position sensor (POS) P0340 P0345 Camshaft position sensor (PHASE) P0500 Vehicle speed sensor P0605 P0607 ECM P0643 Sensor power supply P0705 P0850 Park/Neutral position (PNP) switch P1550 P1551 P1552 P1553 P1554 Battery current sensor P1610 - P1615 NATS P1700 CVT control system P2122 P2123 P2127 P2128 P2138 Accelerator pedal position sensor

[VQ25DE, VQ35DE] < ECU DIAGNOSIS >

Priority	Detected items (DTC)	0
2	 P0031 P0032 P0051 P0052 Air fuel ratio (A/F) sensor 1 heater P0037 P0038 P0057 P0058 Heated oxygen sensor 2 heater 	А
	 P0075 P0081 Intake valve timing control solenoid valve P0130 P0131 P0132 P0133 P0150 P0151 P0152 P0153 P2A00 P2A03 Air fuel ratio (A/F) sensor 1 P0137 P0138 P0139 P0157 P0158 P0159 Heated oxygen sensor 2 	EC
	 P0444 EVAP canister purge volume control solenoid valve P0550 Power steering pressure sensor P0603 ECM power supply P0710 P0715 P0720 P0740 P0744 P0745 P0746 P0776 P0778 P0840 P0845 P1740 CVT related sensors, solenoid valves and switches 	С
	 P1217 Engine over temperature (OVERHEAT) P1720 Vehicle speed sensor P1777 P1778 CVT step motor P1800 P1801 VIAS control solenoid valve 	D
	 P1800 P1801 VIAS control solenoid valve P1805 Brake switch P2100 P2103 Throttle control motor relay P2101 Electric throttle control function P2118 Throttle control motor 	Е
3	 P0011 P0021 Intake valve timing control P0171 P0172 P0174 P0175 Fuel injection system function P0300 - P0306 Misfire 	F
	 P0420 P0430 Three way catalyst function P1212 TCS communication line P1564 ASCD steering switch 	G
	 P1572 ASCD brake switch P1574 ASCD vehicle speed sensor P1715 Primary speed sensor P2119 Electric throttle control actuator 	Н

DTC Index INFOID:0000000003856872

×:Applicable —: Not applicable

					x.Applicable –	–. Могаррисавіе	,
Items	DT	C*1				Reference	J
(CONSULT-III screen terms)	CONSULT-III GST* ²	ECM*3	SRT code	Trip	MI	page	
CAN COMM CIRCUIT	U1000	1000*4	_	1	×	EC-135	K
CAN COMM CIRCUIT	U1001	1001*4	_	2	_	EC-135	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	_	_	Flashing ^{∗6}	_	L
INT/V TIM CONT-B1	P0011	0011	_	2	_	EC-136	M
INT/V TIM CONT-B2	P0021	0021	_	2	_	EC-136	IVI
A/F SEN1 HTR (B1)	P0031	0031	_	2	×	EC-140	
A/F SEN1 HTR (B1)	P0032	0032	_	2	×	EC-140	Ν
HO2S2 HTR (B1)	P0037	0037	_	2	×	EC-143	
HO2S2 HTR (B1)	P0038	0038	_	2	×	EC-143	
A/F SEN1 HTR (B2)	P0051	0051	_	2	×	EC-140	0
A/F SEN1 HTR (B2)	P0052	0052	_	2	×	EC-140	
HO2S2 HTR (B2)	P0057	0057	_	2	×	EC-143	Р
HO2S2 HTR (B2)	P0058	0058	_	2	×	EC-143	
INT/V TIM V/CIR-B1	P0075	0075	_	2	×	EC-146	
INT/V TIM V/CIR-B2	P0081	0081	_	2	×	EC-146	
MAF SEN/CIRCUIT-B1	P0102	0102	_	1	×	EC-149	
MAF SEN/CIRCUIT-B1	P0103	0103	_	1	×	EC-149	

< ECU DIAGNOSIS >					[VQZJI	JE, VQJJDEJ
	DTC	C* ¹				
Items (CONSULT-III screen terms)	CONSULT-III GST* ²	ECM*3	SRT code	Trip	MI	Reference page
IAT SEN/CIRCUIT-B1	P0112	0112	_	2	×	EC-154
IAT SEN/CIRCUIT-B1	P0113	0113	_	2	×	EC-154
ECT SEN/CIRC	P0117	0117	_	1	×	EC-157
ECT SEN/CIRC	P0118	0118	_	1	×	EC-157
TP SEN 2/CIRC-B1	P0122	0122	_	1	×	EC-160
TP SEN 2/CIRC-B1	P0123	0123	_	1	×	EC-160
A/F SENSOR1 (B1)	P0130	0130	_	2	×	EC-163
A/F SENSOR1 (B1)	P0131	0131	_	2	×	EC-167
A/F SENSOR1 (B1)	P0132	0132	_	2	×	EC-170
A/F SENSOR1 (B1)	P0133	0133	×	2	×	EC-173
HO2S2 (B1)	P0137	0137	×	2	×	EC-178
HO2S2 (B1)	P0138	0138	×	2	×	EC-184
HO2S2 (B1)	P0139	0139	×	2	×	EC-192
A/F SENSOR1 (B2)	P0150	0150	_	2	×	EC-163
A/F SENSOR1 (B2)	P0151	0151	_	2	×	EC-167
A/F SENSOR1 (B2)	P0152	0152	_	2	×	EC-170
A/F SENSOR1 (B2)	P0153	0153	×	2	×	EC-173
HO2S2 (B2)	P0157	0157	×	2	×	EC-178
HO2S2 (B2)	P0158	0158	×	2	×	EC-184
HO2S2 (B2)	P0159	0159	×	2	×	EC-192
FUEL SYS-LEAN-B1	P0171	0171	_	2	×	EC-198
FUEL SYS-RICH-B1	P0172	0172	_	2	×	EC-202
FUEL SYS-LEAN-B2	P0174	0174	_	2	×	EC-198
FUEL SYS-RICH-B2	P0175	0175	_	2	×	EC-202
TP SEN 1/CIRC-B1	P0222	0222	_	1	×	EC-206
TP SEN 1/CIRC-B1	P0223	0223	_	1	×	EC-206
MULTI CYL MISFIRE	P0300	0300	_	2	×	EC-209
CYL 1 MISFIRE	P0301	0301	_	2	×	EC-209
CYL 2 MISFIRE	P0302	0302	_	2	×	EC-209
CYL 3 MISFIRE	P0303	0303	_	2	×	EC-209
CYL 4 MISFIRE	P0304	0304	_	2	×	EC-209
CYL 5 MISFIRE	P0305	0305	_	2	×	EC-209
CYL 6 MISFIRE	P0306	0306	_	2	×	EC-209
KNOCK SEN/CIRC-B1	P0327	0327	_	2	_	EC-215
KNOCK SEN/CIRC-B1	P0328	0328	_	2	_	EC-215
KNOCK SEN/CIRC-B2	P0332	0332	_	2	_	EC-215
KNOCK SEN/CIRC-B2	P0333	0333	_	2	_	EC-215
CKP SEN/CIRCUIT	P0335	0335	_	2	×	EC-218
CMP SEN/CIRC-B1	P0340	0340	_	2	×	EC-222
CMP SEN/CIRC-B2	P0345	0345	_	2	×	EC-222
TW CATALYST SYS-B1	P0420	0420	×	2	×	EC-226
TW CATALYST SYS-B2	P0430	0430	×	2	×	EC-226
					1	

Α

EC

С

D

Е

F

G

Н

J

Κ

L

M

Ν

0

Ρ

< ECU DIAGNOSIS >			T :		[1 4202	_, vQJJDL]
Items	DTC*1		1			Reference
(CONSULT-III screen terms)	CONSULT-III GST* ²	ECM* ³	SRT code	Trip	MI	page
PURG VOLUME CONT/V	P0444	0444	_	2	×	EC-231
VEH SPEED SEN/CIRC*5	P0500	0500	_	2	×	EC-234
PW ST P SEN/CIRC	P0550	0550	_	2	_	EC-236
ECM BACK UP/CIRCUIT	P0603	0603	_	2	×	EC-238
ECM	P0605	0605	_	1 or 2	× or —	EC-240
ECM	P0607	0607	_	1	×	EC-242
SENSOR POWER/CIRC	P0643	0643	_	1	×	EC-243
PNP SW/CIRC	P0705	0705	_	2	×	<u>TM-47</u>
ATF TEMP SEN/CIRC	P0710	0710	_	1	×	<u>TM-50</u>
INPUT SPD SEN/CIRC	P0715	0715	_	2	×	<u>TM-52</u>
VEH SPD SEN/CIR AT*5	P0720	0720	_	2	×	<u>TM-55</u>
TCC SOLENOID/CIRC	P0740	0740	_	2	×	<u>TM-62</u>
A/T TCC S/V FNCTN	P0744	0744	_	2	×	TM-64
L/PRESS SOL/CIRC	P0745	0745	_	2	×	TM-66
PRS CNT SOL/A FCTN	P0746	0746	_	1	×	TM-68
PRS CNT SOL/B FCTN	P0776	0776	_	2	×	<u>TM-70</u>
PRS CNT SOL/B CIRC	P0778	0778	_	2	×	<u>TM-72</u>
TR PRS SENS/A CIRC	P0840	0840	_	2	×	<u>TM-74</u>
TR PRS SENS/B CIRC	P0845	0845	_	2	×	TM-80
P-N POS SW/CIRCUIT	P0850	0850	_	2	×	EC-245
TCS/CIRC	P1212	1212	_	2	_	EC-249
ENG OVER TEMP	P1217	1217	_	1	×	EC-250
CTP LEARNING-B1	P1225	1225	_	2		EC-254
CTP LEARNING-B1	P1226	1226	_	2	_	EC-256
BAT CURRENT SENSOR	P1550	1550	_	2	_	EC-258
BAT CURRENT SENSOR	P1551	1551	_	2	_	EC-261
BAT CURRENT SENSOR	P1552	1552	_	2	_	EC-261
BAT CURRENT SENSOR	P1553	1553	_	2	_	EC-264
BAT CURRENT SENSOR	P1554	1554	_	2	_	EC-267
ASCD SW	P1564	1564	_	1	_	EC-270
ASCD BRAKE SW	P1572	1572	_	1	_	EC-273
ASCD VHL SPD SEN	P1574	1574	_	1	_	EC-278
LOCK MODE	P1610	1610	_	2	_	SEC-31
ID DISCORD IMM-ECM	P1611	1611	_	2	_	SEC-32
CHAIN OF ECM-IMMU	P1612	1612	_	2	_	SEC-34
CHAIN OF IMMU-KEY	P1614	1614	_	2	_	<u>SEC-35</u>
DIFFERENCE OF KEY	P1615	1615	_	2	_	<u>SEC-38</u>
CVT C/U FUNCT	P1700	1700	_	1	_	EC-280
IN PULY SPEED	P1715	1715	_	2	_	EC-281
V/SP SEN(A/T OUT)	P1720	1720	_	2	_	EC-283
LU-SLCT SOL/CIRC	P1740	1740	_	2	×	<u>TM-94</u>
STEP MOTR CIRC	P1777	1777	_	1	×	<u>TM-97</u>

Items	DTO	C*1	SRT code			Reference
(CONSULT-III screen terms)	CONSULT-III GST* ²	ECM* ³		Trip	MI	page
STEP MOTR FNC	P1778	1778	_	2	×	<u>TM-100</u>
VIAS S/V-1	P1800	1800	_	2	_	EC-285
VIAS S/V-2	P1801	1801	_	2	_	EC-288
BRAKE SW/CIRCUIT	P1805	1805	_	2	_	EC-291
ETC MOT PWR-B1	P2100	2100	_	1	×	EC-294
ETC FNCTN/CIRC-B1	P2101	2101	_	1	×	EC-296
ETC MOT PWR	P2103	2103	_	1	×	EC-294
ETC MOT-B1	P2118	2118	_	1	×	EC-300
ETC ACTR-B1	P2119	2119	_	1	×	EC-302
APP SEN 1/CIRC	P2122	2122	_	1	×	EC-304
APP SEN 1/CIRC	P2123	2123	_	1	×	EC-304
APP SEN 2/CIRC	P2127	2127	_	1	×	EC-307
APP SEN 2/CIRC	P2128	2128	_	1	×	EC-307
TP SENSOR-B1	P2135	2135	_	1	×	EC-311
APP SENSOR	P2138	2138	_	1	×	EC-314
A/F SENSOR1 (B1)	P2A00	2A00	_	2	×	EC-318
A/F SENSOR1 (B2)	P2A03	2A03	_	2	×	EC-318

^{*1: 1}st trip DTC No. is the same as DTC No.

How to Set SRT Code

INFOID:0000000003856873

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

(P)WITH CONSULT-III

Perform corresponding DTC Confirmation Procedure one by one based on Performance Priority in the table on "SRT Item".

WITHOUT CONSULT-III

The most efficient driving pattern in which SRT codes can be properly set is explained below. The driving pattern should be performed one or more times to set all SRT codes.

^{*2:} This number is prescribed by ISO 15031-6.


^{*3:} In Diagnostic Test Mode II (Self-diagnostic results), this number is controlled by NISSAN.

^{*4:} The troubleshooting for this DTC needs CONSULT-III.

^{*5:} When the fail-safe operations for both self-diagnoses occur, the MI illuminates.

^{*6:} When the ECM is in the mode that displays SRT status, MI may flash. For the details, refer to "How to Display SRT Status".

DRIVING PATTERN



- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
 - Zone A refers to the range where the time, required for the diagnosis under normal conditions*, is the shortest.
 - Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

^{*:} Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 30°C (68 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
 Under different conditions [For example: ambient air temperature other than 20 30°C (68 86°F)], diagnosis may also be performed.

Pattern 1:

- The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminal 46 and ground is 3.0 - 4.3 V).
- The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminal 46 and ground is lower than 1.4 V).
- The engine is started at the fuel tank temperature of warmer than 0°C (32°F) (where the voltage between the ECM terminal 95 and ground is less than 4.1 V).

Pattern 2:

• When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

Pattern 3:

- Operate vehicle following the driving pattern shown in the figure.
- Release the accelerator pedal during deceleration of vehicle speed from 90 km/h (56 MPH) to 0 km/h (0 MPH).

Pattern 4:

- The accelerator pedal must be held very steady during steadystate driving.
- If the accelerator pedal is moved, the test must be conducted again.
- *1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.
- *2: Checking the vehicle speed with GST is advised.

Suggested Transmission Gear Position.

Selector lever position is D.


Test Value and Test Limit

The following is the information specified in Service \$06 of ISO 15031-5.

The test value is a parameter used to determine whether a system/circuit diagnostic test is OK or NG while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

These data (test value and test limit) are specified by On Board Monitor ID (OBDMID), Test ID (TID), Unit and Scaling ID and can be displayed on the GST screen.

The items of the test value and test limit will be displayed with GST screen which items are provided by the ECM. (eg., if bank 2 is not applied on this vehicle, only the items of bank 1 is displayed)



Item	OBD- MID	Self-diagnostic test item	DTC	Test value and Test limit (GST display)		Decembring
				TID	Unitand Scaling ID	- Description
HO2S	01H	Air fuel ratio (A/F) sensor 1 (Bank 1)	P0131	83H	0BH	Minimum sensor output voltage for test cycle
			P0131	84H	0BH	Maximum sensor output voltage for test cycle
			P0130	85H	0BH	Minimum sensor output voltage for test cycle
			P0130	86H	0BH	Maximum sensor output voltage for test cycle
			P0133	87H	04H	Response rate: Response ratio (Lean to Rich)
			P0133	88H	04H	Response rate: Response ratio (Rich to Lean)
			P2A00	89H	84H	The amount of shift in air fuel ratio
			P2A00	HA8	84H	The amount of shift in air fuel ratio
			P0130	8BH	0BH	Difference in sensor output voltage
			P0133	8CH	83H	Response gain at the limited frequency
	02H	Heated oxygen sensor 2 (Bank 1)	P0138	07H	0CH	Minimum sensor output voltage for test cycle
			P0137	08H	0CH	Maximum sensor output voltage for test cycle
			P0138	80H	0CH	Sensor output voltage
			P0139	81H	0CH	Difference in sensor output voltage
	03H	Heated oxygen sensor 3 (Bank 1)	P0143	07H	0CH	Minimum sensor output voltage for test cycle
			P0144	08H	0CH	Maximum sensor output voltage for test cycle
			P0146	80H	0CH	Sensor output voltage
			P0145	81H	0CH	Difference in sensor output voltage

 \mathbb{N}

L

Ν

0

Р

Item	OBD- MID	Self-diagnostic test item	DTC	Test value and Test limit (GST display)		Description
item				TID	Unit and Scaling ID	Description
	05H	Air fuel ratio (A/F) sensor 1 (Bank 2)	P0151	83H	0BH	Minimum sensor output voltage for test cycle
			P0151	84H	0BH	Maximum sensor output voltage for test cycle
			P0150	85H	0BH	Minimum sensor output voltage for test cycle
			P0150	86H	0BH	Maximum sensor output voltage for test cycle
			P0153	87H	04H	Response rate: Response ratio (Lean to Rich)
			P0153	88H	04H	Response rate: Response ratio (Rich to Lean)
			P2A03	89H	84H	The amount of shift in air fuel ratio
			P2A03	8AH	84H	The amount of shift in air fuel ratio
HO2S			P0150	8BH	0BH	Difference in sensor output voltage
			P0153	8CH	83H	Response gain at the limited frequency
	06H	Heated oxygen sensor 2 (Bank 2)	P0158	07H	0CH	Minimum sensor output voltage for test cycle
			P0157	08H	0CH	Maximum sensor output voltage for test cycle
			P0158	80H	0CH	Sensor output voltage
			P0159	81H	0CH	Difference in sensor output voltage
	07H	Heated oxygen sensor 3 (Bank2)	P0163	07H	0CH	Minimum sensor output voltage for test cycle
			P0164	08H	0CH	Maximum sensor output voltage for test cycle
			P0166	80H	0CH	Sensor output voltage
			P0165	81H	0CH	Difference in sensor output voltage
CATA- LYST	21H	Three way catalyst function (Bank1)	P0420	80H	01H	O2 storage index
			P0420	82H	01H	Switching time lag engine exhaust index value
			P2423	83H	0CH	Difference in 3rd O2 sensor output voltage
			P2423	84H	84H	O2 storage index in HC trap catalyst
	22H	Three way catalyst function (Bank2)	P0430	80H	01H	O2 storage index
			P0430	82H	01H	Switching time lag engine exhaust index value
			P2424	83H	0CH	Difference in 3rd O2 sensor output voltage
			P2424	84H	84H	O2 storage index in HC trap catalyst

	OBD-			Tes	value and st limit display)	
Item	MID	Self-diagnostic test item	DTC	TID	Unitand Scaling ID	Description
			P0400	80H	96H	Low Flow Faults: EGR temp change rate (short-term)
			P0400	81H	96H	Low Flow Faults: EGR temp change rate (long-term)
EGR SYSTEM	31H	EGR function	P0400	82H	96H	Low Flow Faults: Difference between max EGR temp and EGR temp under idling condition
			P0400	83H	96H	Low Flow Faults: Max EGR temp
			P1402	84H	96H	High Flow Faults: EGR temp increase rate
	39H	EVAP control system leak (Cap Off)	P0455	80H	0CH	Difference in pressure sensor output voltage before and after pull down
	3ВН	EVAP control system leak (Small leak)	P0442	80H	05H	Leak area index (for more than 0.04inch)
EVAP SYSTEM	3СН	EVAP control system	P0456	80H	05H	Leak area index (for more than 0.02inch)
	0011	(Very small leak)	P0456	81H	FDH	Maximum internal pressure of EVAP system during monitoring
	3DH	Purge flow system	P0441	83H	0CH	Difference in pressure sensor output voltage before and after vent control value close
	41H	A/F sensor 1 heater (Bank 1)	Low Input: P0031 High Input: P0032	81H	0BH	Converted value of Heater electric current to voltage
	42H	Heated oxygen sensor 2 (Bank 1)	Low Input: P0037 High Input: P0038	80H	0CH	Converted value of Heater electric current to voltage
O2 SEN- SOR	43H	Heated oxygen sensor 3 (Bank 1)	P0043	80H	0CH	Converted value of Heater electric current to voltage
HEATER	45H	A/F sensor 1 heater (Bank 2)	Low Input: P0051 High Input: P0052	81H	0BH	Converted value of Heater electric current to voltage
	46H	Heated oxygen sensor 2 (Bank 2)	Low Input: P0057 High Input: P0058	80H	0CH	Converted value of Heater electric current to voltage
	47H	Heated oxygen sensor 3 (Bank 2)	P0063	80H	0CH	Converted value of Heater electric current to voltage
			P0411	80H	01H	Secondary Air Injection System Incorrect Flow Detected
			Bank1: P0491 Bank2: P0492	81H	01H	Secondary Air Injection System Insufficient Flow
050			P2445	82H	01H	Secondary Air Injection System Pump Stuck Off
SEC- OND- ARY AIR	71H	Secondary Air system	P2448	83H	01H	Secondary Air Injection System High Airflow
			Bank1: P2440 Bank2: P2442	84H	01H	Secondary Air Injection System Switching Valve Stuck Open
			P2440	85H	01H	Secondary Air Injection System Switching Valve Stuck Open
			P2444	86H	01H	Secondary Air Injection System Pump Stuck On

	OBD-	0.16.15	DTO	Te	ralue and st limit display)	D
Item	Item MID Self-diagnostic test item		DTC	TID	Unit and Scaling ID	Description
	81H	Fuel injection system function	P0171 or P0172	80H	2FH	Long-term fuel trim
FUEL	0111	(Bank 1)	P0171 or P0172	81H	24H	The number of lambda control clamped
SYSTEM	82H	Fuel injection system function	P0174 or P0175	80H	2FH	Long-term fuel trim
	0211	(Bank 2)	P0174 or P0175	81H	24H	The number of lambda control clamped
			P0301	80H	24H	Misfiring counter at 1000 revolution of the first cylinder
			P0302	81H	24H	Misfiring counter at 1000 revolution of the second cylinder
			P0303	82H	24H	Misfiring counter at 1000 revolution of the third cylinder
			P0304	83H	24H	Misfiring counter at 1000 revolution of the fourth cylinder
			P0305	84H	24H	Misfiring counter at 1000 revolution of the fifth cylinder
			P0306	85H	24H	Misfiring counter at 1000 revolution of the sixth cylinder
			P0307	86H	24H	Misfiring counter at 1000 revolution of the seventh cylinder
			P0308	87H	24H	Misfiring counter at 1000 revolution of the eighth cylinder
			P0300	88H	24H	Misfiring counter at 1000 revolution of the multiple cylinders
MISFIRE	A1H	Multiple Cylinder Misfires	P0301	89H	24H	Misfiring counter at 200 revolution of the first cylinder
WIIOI IICE	,,,,,,	Walapie Cymiaer Wishies	P0302	8AH	24H	Misfiring counter at 200 revolution of the second cylinder
			P0303	8BH	24H	Misfiring counter at 200 revolution of the third cylinder
			P0304	8CH	24H	Misfiring counter at 200 revolution of the fourth cylinder
			P0305	8DH	24H	Misfiring counter at 200 revolution of the fifth cylinder
			P0306	8EH	24H	Misfiring counter at 200 revolution of the fifth cylinder
			P0307	8FH	24H	Misfiring counter at 200 revolution of the fifth cylinder
			P0308	90H	24H	Misfiring counter at 200 revolution of the fifth cylinder
			P0300	91H	24H	Misfiring counter at 1000 revolution of the single cylinder
			P0300	92H	24H	Misfiring counter at 200 revolution of the single cylinder
			P0300	93H	24H	Misfiring counter at 200 revolution of the multiple cylinders

[VQ25DE, VQ35DE]

Item	OBD-	Self-diagnostic test item	DTC	Te	value and st limit display)	Description	Δ
item	MID	Gen-diagnostic test item	Dio	TID	Unitand Scaling ID	·	EC
	A2H	No.1 Cylinder Misfire	P0301	0BH	24H	EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles	C
			P0301	0CH	24H	Misfire counts for last/current driving cycles	
	АЗН	No.2 Cylinder Misfire	P0302	0BH	24H	EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driv- ing cycles	D
			P0302	0CH	24H	Misfire counts for last/current driving cycles	Е
	A4H	No.3 Cylinder Misfire	P0303	0BH	24H	EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles	F
			P0303	0CH	24H	Misfire counts for last/current driving cycles	G
	A5H	No.4 Cylinder Misfire	P0304	0BH	24H	EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles	Н
MICEIDE			P0304	0CH	24H	Misfire counts for last/current driving cycles	
MISFIRE	A6H	No.5 Cylinder Misfire	P0305	0BH	24H	EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles	I
			P0305	0CH	24H	Misfire counts for last/current driving cycles	J
	А7Н	No.6 Cylinder Misfire	P0306	0BH	24H	EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles	K
			P0306	0CH	24H	Misfire counts for last/current driving cycles	
	A8H	No.7 Cylinder Misfire	P0307	0BH	24H	EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles	L
			P0307	0CH	24H	Misfire counts for last/current driving cycles	V
	А9Н	No.8 Cylinder Misfire	P0308	0BH	24H	EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driv- ing cycles	Ν
			P0308	0CH	24H	Misfire counts for last/current driving cycles	C

SYMPTOM DIAGNOSIS

ENGINE CONTROL SYSTEM SYMPTOMS

Symptom Table

SYSTEM — BASIC ENGINE CONTROL SYSTEM

							S	/MPT	ОМ						
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	Reference page
Warrant	y symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	НА	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	EC-337
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			EC-411
	Fuel injector circuit	1	1	2	3	2		2	2			2			EC-334
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4			EC-76
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		EC-347
	Incorrect idle speed adjustment						1	1	1	1		1			EC-11
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2		2	EC-296, EC-302
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-11
	Ignition circuit	1	1	2	2	2		2	2			2			EC-341
Power s	upply and ground circuit	2	2	3	3	3		3	3		2	3			EC-132
Mass air	r flow sensor circuit	1			2										EC-149
Engine o	coolant temperature sensor circuit	'					3			3					EC-157
Air fuel r	ratio (A/F) sensor 1 circuit		1	2	3	2		2	2			2			EC-163, EC-167, EC-170, EC-173, EC-318
Throttle	position sensor circuit						2			2					EC-160, EC-206, EC-254, EC-256, EC-311
Accelera	ator pedal position sensor circuit			3	2	1									EC-243, EC-304, EC-307, EC-314
Knock s	ensor circuit			2								3			EC-215

Α

EC

D

Е

F

G

Н

K

L

M

Ν

0

Р

		SYMPTOM												
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	Reference page
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	НА	
Crankshaft position sensor (POS) circuit	2	2												EC-218
Camshaft position sensor (PHASE) circuit	3	2												EC-222
Vehicle speed signal circuit		2	3		3						3			EC-234
Power steering pressure sensor circuit		2					3	3						EC-236
ECM	2	2	3	3	3	3	3	3	3	3	3			EC-238, EC-240
Intake valve timing control solenoid valve circuit		3	2		1	3	2	2	3		3			EC-146
PNP signal circuit			3		3		3	3			3			EC-245
VIAS control solenoid valve 1 circuit					1									EC-285
VIAS control solenoid valve 2 circuit					1									EC-288
Refrigerant pressure sensor circuit		2				3			3		4			EC-348
Electrical load signal circuit							3							EC-329
Air conditioner circuit	2	2	3	3	3	3	3	3	3		3		2	HAC-159
ABS actuator and electric unit (control unit)			4											BRC-80

^{1 - 6:} The numbers refer to the order of inspection. (continued on the next figure)

SYSTEM — ENGINE MECHANICAL & OTHER

EC-401

							SY	/MPT	OM						
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	Reference page
Warranty s	ymptom code	AA	AB	AC	AD	AE	AF	AG	АН	AJ	AK	AL	AM	НА	
Fuel	Fuel tank	5													<u>FL-9</u>
	Fuel piping	J		5	5	5		5	5			5			FL-4
	Vapor lock		5											:	_
	Valve deposit	_			_	_		_	_			_			_
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	5			5			_
Air	Air duct														<u>EM-26</u>
	Air cleaner														<u>EM-26</u>
	Air leakage from air duct (Mass air flow sensor — electric throttle control actuator)		5	5		5		5	5			5			<u>EM-26</u>
	Electric throttle control actuator	5			5		5			5					EM-29
	Air leakage from intake manifold/ Collector/Gasket														EM-29, EM-32
Cranking	Battery	1	1	1		1		1	1					1	PG-109
	Generator circuit	,	l	•		'		'	,						CHG-20
	Starter circuit	3										1			STR-5, STR-6
	Signal plate	6													EM-104
	PNP signal	4													<u>TM-48,</u> <u>TM-214</u>
Engine	Cylinder head	5	5	5	5	5		5	5			5			<u>EM-97</u>
	Cylinder head gasket	J		J	J	J			J		4	J	3		<u>LIVI-31</u>
	Cylinder block														
	Piston												4		
	Piston ring	6	6	6	6	6		6	6			6			<u>EM-110</u>
	Connecting rod			3	J										<u></u>
	Bearing														
	Crankshaft														

Α

D

Е

F

G

Н

Κ

L

M

Ν

0

Р

							S١	/MPT	MC						
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	Reference page
Warranty	symptom code	AA	AB	AC	AD	AE	AF	AG	АН	AJ	AK	AL	AM	НА	
Valve	Timing chain														EM-65
mecha- nism	Camshaft														EM-84
	Intake valve timing control	5	5	5	5	5		5	5			5			EM-65
	Intake valve												3		<u>EM-97</u>
	Exhaust valve												3		<u> </u>
Exhaust	Exhaust manifold/Tube/Muffler/ Gasket	5	5	5	5	5		5	5			5			<u>EM-34</u> , <u>EX-</u>
	Three way catalyst														<u>-</u>
Lubrica- tion	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery/Oil cooler	5	5	5	5	5		5	5			5			<u>LU-7, LU-</u> <u>10, LU-11,</u> <u>LU-13</u>
	Oil level (Low)/Filthy oil														<u>LU-7</u>
Cooling	Radiator/Hose/Radiator filler cap														<u>CO-12</u> , <u>CO-12</u>
	Thermostat									5					CO-23
	Water pump	5	5	5	5	5		5	5		4	5			<u>CO-18</u>
	Water gallery	5	5	5	5	5		5	5		4	5			<u>CO-2</u>
	Cooling fan														<u>CO-16</u>
	Coolant level (Low)/Contaminated coolant									5					<u>CO-8</u>
NVIS (NIS NATS)	SAN Vehicle Immobilizer System —	1	1												<u>SEC-14</u>

^{1 - 6:} The numbers refer to the order of inspection.

EC-403

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[VQ25DE, VQ35DE]

NORMAL OPERATING CONDITION

Description INFOID:0000000003856876

FUEL CUT CONTROL (AT NO LOAD AND HIGH ENGINE SPEED)

If the engine speed is above 1,400 rpm under no load (for example, the selector lever position is P or N and engine speed is over 1,400 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed.

Fuel cut will be operated until the engine speed reaches 1,000 rpm, then fuel cut will be cancelled. **NOTE:**

This function is different from deceleration control listed under Multiport Fuel Injection (MFI) System, <u>EC-27.</u> "System Description".

[VQ25DE, VQ35DE] < PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Baq Module, see the "SRS AIRBAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions For Xenon Headlamp Service

WARNING:

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.


CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

Precaution for Procedure without Cowl Top Cover

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



On Board Diagnostic (OBD) System of Engine and CVT

The ECM has an on board diagnostic system. It will illuminate the malfunction indicator MI to warn the driver of a malfunction causing emission deterioration.

EC

Α

D

Е

INFOID:0000000003856878

Н

K

L

N

Р

INFOID:0000000003856880

INFOID:0000000003856879


INFOID:0000000003856881

CAUTION:

- Always turn the ignition switch OFF and disconnect the negative battery cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to illuminate.
- Always connect and lock the connectors securely after work. A loose (unlocked) connector will
 cause the MI to illuminate due to the open circuit. (Be sure the connector is free from water, grease,
 dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to PG-96, "Description".
- Always to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MI to illuminate due to the short circuit.
- Always connect rubber tubes properly after work. A misconnected or disconnected rubber tube may
 cause the MI to illuminate due to the malfunction of the EVAP system or fuel injection system, etc.
- Always erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission control module) before returning the vehicle to the customer.


General Precautions

- Always use a 12 volt battery as power source.
- Never attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned OFF.
- Before removing parts, turn ignition switch OFF and then disconnect battery ground cable.



- Never disassemble ECM.
- If a battery cable is disconnected, the memory will return to the ECM value.
 The ECM will now start to self-control at its initial value. Thus, engine operation can vary slightly in this case. However, this is not an indication of a malfunction. Never replace parts because of a slight variation.
- If the battery is disconnected, the following emission-related diagnostic information will be lost within 24 hours.
- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values
- When connecting ECM harness connector, fasten (B) it securely with a lever (1) as far as it will go as shown in the figure.

2 : ECM A : Loosen





< PRECAUTION > [VQ25DE, VQ35DE]


 When connecting or disconnecting pin connectors into or from ECM, never damage pin terminals (bends or break).
 Check that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.


Securely connect ECM harness connectors.
 A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.

- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.
- Before replacing ECM, perform ECM Terminals and Reference Value inspection and check ECM functions properly. Refer to EC-357, "Reference Value".
- Handle mass air flow sensor carefully to avoid damage.
- Never clean mass air flow sensor with any type of detergent.
- Never disassemble electric throttle control actuator.
- Even a slight leak in the air intake system can cause serious incidents.
- Never shock or jar the camshaft position sensor (PHASE), crankshaft position sensor (POS).









EC

Α

С

D

Е

F

Н

K


M

L


Ν

 \cap


- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact.
 - Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Never use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



- B1 indicates bank 1, B2 indicates bank 2 as shown in the figure.
- Never operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.



- Never depress accelerator pedal when starting.
- · Immediately after starting, never rev up engine unnecessarily.
- · Never rev up engine just prior to shutdown.




PRECAUTIONS

< PRECAUTION > [VQ25DE, VQ35DE]

 When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.

- Keep the antenna as far as possible from the electronic control units.
- Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls.
 - Never let them run parallel for a long distance.
- Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
- Be sure to ground the radio to vehicle body.



Α

EC

С

D

Е

F

G

Н

K

L

M

Ν

0

PREPARATION

PREPARATION

Special Service Tools

INFOID:0000000003943273

Description
Measuring fuel pressure
2
13E

Commercial Service Tools

INFOID:0000000003943274

Tool name		Description
Quick connector re- lease	PBIC0198E	Removes fuel tube quick connectors in engine room
Socket wrench	19 mm (0.75 in) More than 32 mm (1.26 in)	Removes and installing engine coolant temperature sensor
Oxygen sensor thread cleaner	a b b watting surface shave cylinder Flutes AEM488	Reconditions the exhaust system threads before installing a new oxygen sensor. Use with antiseize lubricant shown below. a: 18 mm diameter with pitch 1.5 mm for Zirconia Oxygen Sensor b: 12 mm diameter with pitch 1.25 mm for Titania Oxygen Sensor
Anti-seize lubricant i.e.: (Permatex TM 133AR or equivalent meeting MIL specifica- tion MIL-A-907)	S-NT779	Lubricates oxygen sensor thread cleaning tool when reconditioning exhaust system threads.

[VQ25DE, VQ35DE]

Α

Е

F

Н

K

L

ON-VEHICLE MAINTENANCE

FUEL PRESSURE

Inspection INFOID:0000000003856884 EC

FUEL PRESSURE RELEASE

(P) With CONSULT-III

- 1. Turn ignition switch ON.
- Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-III.
- 3. Start engine.
- 4. After engine stalls, crank it 2 or 3 times to release all fuel pressure.
- Turn ignition switch OFF.

₩ Without CONSULT-III

- 1. Remove fuel pump fuse located in IPDM E/R.
- 2. Start engine.
- 3. After engine stalls, crank it 2 or 3 times to release all fuel pressure.
- 4. Turn ignition switch OFF.
- Reinstall fuel pump fuse after servicing fuel system.

FUEL PRESSURE CHECK

CAUTION:


Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

NOTE:

- Prepare pans or saucers under the disconnected fuel line because the fuel may spill out. The fuel pressure cannot be completely released because J32 models do not have fuel return system.
- Be careful not to scratch or get the fuel hose connection area dirty when servicing, so that the quick connector o-ring maintains seal ability.
- 1. Release fuel pressure to zero.
- 2. Remove fuel hose using Quick Connector Release.
 - Do not twist or kink fuel hose because it is plastic hose.
 - Keep fuel hose connections clean.
- Install Fuel pressure adapter (B) and Fuel pressure gauge (A) as shown in figure.
 - Do not distort or bend fuel rail tube when installing fuel pressure gauge adapter.
 - When reconnecting fuel hose, check the original fuel hose for damage and abnormality.
- 4. Turn ignition switch ON (reactivate fuel pump) and check for fuel leakage.
- Start engine and check for fuel leakage.
- 6. Read the indication of fuel pressure gauge kit.
 - During fuel pressure check, check for fuel leakage from fuel connection every 3 minutes.

At idling : Approximately 350 kPa (3.5 bar, 3.57 kg/cm², 51 psi)

- 7. If result is unsatisfactory, go to next step.
- 8. Check the following.
 - Fuel hoses and fuel tubes for clogging
 - · Fuel filter for clogging
 - Fuel pump
 - · Fuel pressure regulator for clogging
- 9. If OK, replace fuel pressure regulator. If NG, repair or replace malfunctioning part.



EC-411

Р

Ν

FUEL PRESSURE

[VQ25DE, VQ35DE]


10. Before disconnecting Fuel Pressure Gauge and Fuel Pressure Adapter, release fuel pressure to zero.

ON-VEHICLE REPAIR


EVAPORATIVE EMISSION SYSTEM

Inspection INFOID:0000000003932067 EC

- Visually inspect EVAP vapor lines for improper attachment and for cracks, damage, loose connections, chafing and deterioration.
- Check EVAP canister as per the following:
- Block port (B). Orally blow air through port (A). Check that air flows freely through port (C).
- Block port (A). Orally blow air through port (B). Check that air flows freely through port (C).



- 3. Inspect fuel tank filler cap vacuum relief valve for clogging, sticking, etc.
- Wipe clean valve housing.



Check valve opening pressure and vacuum.


15.3 - 20.0 kPa (0.153 - 0.200 bar, 0.156 - 0.204 kg/ Pressure:

cm², 2.22 - 2.90 psi)

-6.0 to -3.4 kPa (-0.06 bar to --0.034bar, -0.061 to -Vacuum:

 0.035 kg/cm^2 , -0.87 to -0.49 psi)

If out of specification, replace fuel filler cap as an assembly.



C

D

Е

F

Н

Α

Ν

M

K

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[VQ25DE, VQ35DE]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Idle Speed

Condition	Specification
No load (in P or N position)	600 ± 50 rpm
Ignition Timing	INFOID:000000003856890
Condition	Specification
No load (in P or N position)	12 ± 5° BTDC
Calculated Load Value	INFOID:000000003856891

Condition	Specification (Using CONSULT-III or GST)
At idle	10 – 35 %
At 2,500 rpm	10 – 35 %

Mass Air Flow Sensor

INFOID:0000000003856892

Supply voltage	Battery voltage (11 – 14 V)
Output voltage at idle (in N position)	0.9 – 1.2 V*
Mass air flow (Using CONSULT-III or GST)	2.0 – 6.0 g·m/sec at idle* 7.0 – 20.0 g·m/sec at 2,500 rpm*

^{*:} Engine is warmed up to normal operating temperature and running under no load.